



**HIRSCHMANN**

A **BELDEN** BRAND

# Reference Manual

**Command Line Interface**

**Industrial ETHERNET (Gigabit) Switch**

**RS20/RS30/RS40, MS20/MS30, OCTOPUS, PowerMICE,  
RSR20/RSR30, MACH 100, MACH 1000, MACH 4000**

**L2P Rel. 8.0**

The naming of copyrighted trademarks in this manual, even when not specially indicated, should not be taken to mean that these names may be considered as free in the sense of the trademark and tradename protection law and hence that they may be freely used by anyone.

© 2013 Hirschmann Automation and Control GmbH

Manuals and software are protected by copyright. All rights reserved. The copying, reproduction, translation, conversion into any electronic medium or machine scannable form is not permitted, either in whole or in part. An exception is the preparation of a backup copy of the software for your own use. For devices with embedded software, the end-user license agreement on the enclosed CD applies

The performance features described here are binding only if they have been expressly guaranteed in the contract. This publication has been created by Hirschmann Automation and Control GmbH according to the best of our knowledge. Hirschmann reserves the right to change the contents of this manual without prior notice. Hirschmann can give no guarantee in respect of the correctness or accuracy of the details in this publication.

Hirschmann can accept no responsibility for damages, resulting from the use of the network components or the associated operating software. In addition, we refer to the conditions of use specified in the license contract.

Printed in Germany 4/26/13

Hirschmann Automation and Control GmbH  
Stuttgarter Str. 45-51  
72654 Neckartenzlingen  
Germany  
Tel.: +49 1805 141538

05-05/2013

# Content

<b>About this Manual</b>	21
Maintenance	22
<b>1 Command Structure</b>	<b>23</b>
1.1 Format	24
1.1.1 Command	25
1.1.2 Parameters	25
1.1.3 Values	25
1.1.4 Conventions	27
1.1.5 Annotations	28
1.1.6 Special keys	29
1.1.7 Special characters in scripts	30
1.1.8 Secrets in scripts	32
<b>2 Quick Start up</b>	<b>35</b>
2.1 Quick Starting the Switch	36
2.2 System Info and System Setup	37
<b>3 Mode-based CLI</b>	<b>43</b>
3.1 Mode-based Topology	44
3.2 Mode-based Command Hierarchy	45
3.3 Flow of Operation	47
3.4 “No” Form of a Command	49
3.4.1 Support for “No” Form	49
3.4.2 Behavior of Command Help (“?”)	49
<b>4 CLI Commands: Base</b>	<b>51</b>
4.1 System Information and Statistics	52
4.1.1 show	52
4.1.2 show address-conflict	52
4.1.3 show arp switch	53
4.1.4 show bridge address-learning	53
4.1.5 show bridge address-relearn-detect	54

4.1.6	show bridge aging-time	54
4.1.7	show bridge duplex-mismatch-detect	55
4.1.8	show bridge fast-link-detection	55
4.1.9	show bridge framesize	55
4.1.10	show bridge vlan-learning	56
4.1.11	bridge framesize	56
4.1.12	show config-watchdog	57
4.1.13	show device-status	57
4.1.14	show authentication	58
4.1.15	show eventlog	59
4.1.16	show interface	60
4.1.17	show interface ethernet	62
4.1.18	show interface switchport	69
4.1.19	show interface utilization	70
4.1.20	show logging	71
4.1.21	show mac-addr-table	72
4.1.22	show signal-contact	73
4.1.23	show slot	75
4.1.24	show running-config	76
4.1.25	show sysinfo	77
4.1.26	show temperature	80
4.1.27	utilization alarm-threshold	80
4.2	Debug Commands	81
4.2.1	debug tcpdump help	81
4.2.2	debug tcpdump start cpu	81
4.2.3	debug tcpdump start cpu filter	82
4.2.4	debug tcpdump stop	82
4.2.5	debug tcpdump filter show	83
4.2.6	debug tcpdump filter list	83
4.2.7	debug tcpdump filter delete	84
4.3	Management VLAN Commands	85
4.3.1	network mgmt_vlan	85
4.4	Class of Service (CoS) Commands	86
4.4.1	classofservice dot1p-mapping	87
4.4.2	classofservice ip-dscp-mapping	88
4.4.3	classofservice trust	89
4.4.4	show classofservice dot1p-mapping	90
4.4.5	show classofservice ip-dscp-mapping	91
4.4.6	show classofservice trust	92

4.4.7	vlan port priority all	92
4.4.8	vlan priority	93
4.4.9	dvlan-tunnel ethertype	94
4.4.10	mode dvlan-tunnel	95
4.4.11	show dvlan-tunnel	96
4.5	Link Aggregation(802.3ad) Commands	97
4.5.1	link-aggregation staticcapability	97
4.5.2	show link-aggregation brief	98
4.6	Management Commands	99
4.6.1	telnet	99
4.6.2	transport input telnet	100
4.6.3	transport output telnet	101
4.6.4	session-limit	102
4.6.5	session-timeout	103
4.6.6	bridge address-learning	103
4.6.7	bridge address-relearn detect operation	104
4.6.8	bridge address-relearn detect threshold	104
4.6.9	bridge aging-time	105
4.6.10	bridge fast-link-detection	106
4.6.11	bridge duplex-mismatch-detect operation	106
4.6.12	bridge vlan-learning	107
4.6.13	digital-input	107
4.6.14	digital-output	109
4.6.15	show digital-input	112
4.6.16	show digital-input config	113
4.6.17	show digital-input all	114
4.6.18	show digital-input <slot/input>	115
4.6.19	show digital-output	116
4.6.20	show digital-output config	117
4.6.21	show digital-output all	118
4.6.22	show digital-output <slot/output>	119
4.6.23	ethernet-ip	120
4.6.24	iec61850-mms	121
4.6.25	show iec61850-mms	122
4.6.26	network javascriptmode	123
4.6.27	network mgmt-access add	124
4.6.28	network mgmt-access delete	124
4.6.29	network mgmt-access modify	125
4.6.30	network mgmt-access operation	126
4.6.31	network mgmt-access status	126

4.6.32	network parms	127
4.6.33	network protocol	127
4.6.34	network priority	128
4.6.35	profinetio	129
4.6.36	serial timeout	130
4.6.37	set prompt	130
4.6.38	show ethernet-ip	131
4.6.39	show network	131
4.6.40	show network mgmt-access	133
4.6.41	show profinetio	134
4.6.42	show serial	134
4.6.43	show snmp-access	135
4.6.44	show snmpcommunity	136
4.6.45	show snmptrap	137
4.6.46	show telnet	138
4.6.47	show telnetcon	139
4.6.48	show trapflags	140
4.6.49	snmp-access global	141
4.6.50	snmp-access version	142
4.6.51	snmp-access version v3-encryption	143
4.6.52	snmp-server	144
4.6.53	snmp-server community	145
4.6.54	snmp-server contact	146
4.6.55	snmp-server community ipaddr	147
4.6.56	snmp-server community ipmask	148
4.6.57	snmp-server community mode	149
4.6.58	snmp-server community ro	150
4.6.59	snmp-server community rw	150
4.6.60	snmp-server location	150
4.6.61	snmp-server sysname	151
4.6.62	snmp-server enable traps	151
4.6.63	snmp-server enable traps chassis	152
4.6.64	snmp-server enable traps l2redundancy	153
4.6.65	snmp-server enable traps linkmode	154
4.6.66	snmp-server enable traps multiusers	155
4.6.67	snmp-server enable traps port-sec	156
4.6.68	snmp-server enable traps stpmode	157
4.6.69	snmptrap	158
4.6.70	snmptrap ipaddr	159
4.6.71	snmptrap mode	160
4.6.72	snmptrap snmpversion	161

4.6.73	telnetcon maxsessions	162
4.6.74	telnetcon timeout	163
4.7	Syslog Commands	164
4.7.1	logging buffered	164
4.7.2	logging buffered wrap	165
4.7.3	logging cli-command	166
4.7.4	logging console	167
4.7.5	logging host	168
4.7.6	logging host reconfigure	169
4.7.7	logging host remove	169
4.7.8	logging snmp-requests get operation	169
4.7.9	logging snmp-requests set operation	170
4.7.10	logging snmp-requests get severity	170
4.7.11	logging snmp-requests set severity	171
4.7.12	logging syslog	171
4.7.13	logging syslog port	172
4.8	Scripting Commands	173
4.8.1	script apply	173
4.8.2	script delete	174
4.8.3	script list	174
4.8.4	script show	175
4.8.5	script validate	175
4.9	Device Configuration Commands	177
4.9.1	addport	177
4.9.2	adminmode	178
4.9.3	auto-disable reason	179
4.9.4	auto-disable timer	180
4.9.5	auto-negotiate	181
4.9.6	auto-negotiate all	182
4.9.7	cable-crossing	183
4.9.8	media-module	184
4.9.9	deleteport	185
4.9.10	deleteport all	185
4.9.11	dip-switch operation	186
4.9.12	macfilter	187
4.9.13	macfilter adddest	188
4.9.14	macfilter adddest all	189
4.9.15	mac notification (Global Config)	190
4.9.16	mac notification (Interface Config)	191

4.9.17	monitor session <session-id>	192
4.9.18	monitor session <session-id> mode	194
4.9.19	monitor session <session-id> source/destination	195
4.9.20	link-aggregation	196
4.9.21	link-aggregation adminmode	197
4.9.22	link-aggregation linktrap	198
4.9.23	link-aggregation name	199
4.9.24	rmon-alarm add	199
4.9.25	rmon-alarm delete	200
4.9.26	rmon-alarm enable	200
4.9.27	rmon-alarm disable	201
4.9.28	rmon-alarm modify mib-variable	201
4.9.29	rmon-alarm modify thresholds	202
4.9.30	rmon-alarm modify interval	202
4.9.31	rmon-alarm modify sample-type	203
4.9.32	rmon-alarm modify startup-alarm	203
4.9.33	rmon-alarm modify rising-event	204
4.9.34	rmon-alarm modify falling-event	204
4.9.35	set garp timer join	205
4.9.36	set garp timer leave	206
4.9.37	set garp timer leaveall	207
4.9.38	set gmrp adminmode	208
4.9.39	set gmrp interfacemode	209
4.9.40	set gmrp interfacemode	210
4.9.41	set gmrp forward-all-groups	211
4.9.42	set gmrp forward-unknown	212
4.9.43	set igmp	213
4.9.44	set igmp	214
4.9.45	set igmp aging-time-unknown	214
4.9.46	set igmp automatic-mode	215
4.9.47	set igmp forward-all	216
4.9.48	set igmp forward-unknown	217
4.9.49	set igmp static-query-port	218
4.9.50	set igmp groupmembershipinterval	219
4.9.51	set igmp interfacemode	220
4.9.52	set igmp lookup-interval-unknown	220
4.9.53	set igmp lookup-resp-time-unknown	221
4.9.54	set igmp maxresponse	222
4.9.55	set igmp querier max-response-time	223
4.9.56	set igmp querier protocol-version	223
4.9.57	set igmp querier status	224



4.9.58	set igmp querier tx-interval	224
4.9.59	set igmp query-ports-to-filter	225
4.9.60	set pre-login-banner text	226
4.9.61	selftest ramtest	226
4.9.62	selftest reboot-on-hdxerror	227
4.9.63	selftest reboot-on-error	228
4.9.64	show auto-disable brief	229
4.9.65	show auto-disable reasons	230
4.9.66	show dip-switch	231
4.9.67	show garp	232
4.9.68	show gmrp configuration	232
4.9.69	show igmpsnooping	233
4.9.70	show mac-filter-table gmrp	235
4.9.71	show mac-filter-table igmpsnooping	236
4.9.72	show mac-filter-table multicast	237
4.9.73	show mac-filter-table static	238
4.9.74	show mac-filter-table staticfiltering	239
4.9.75	show mac-filter-table stats	240
4.9.76	show mac notification	240
4.9.77	show monitor session	242
4.9.78	show port	243
4.9.79	show link-aggregation	244
4.9.80	show rmon-alarm	245
4.9.81	show selftest	246
4.9.82	show storm-control	247
4.9.83	show storm-control limiters port	248
4.9.84	show vlan	248
4.9.85	show vlan brief	251
4.9.86	show vlan port	251
4.9.87	show voice vlan	253
4.9.88	show voice vlan interface	254
4.9.89	shutdown	255
4.9.90	shutdown all	256
4.9.91	snmp trap link-status	257
4.9.92	snmp trap link-status all	258
4.9.93	spanning-tree bpdumigrationcheck	259
4.9.94	speed	260
4.9.95	storm-control broadcast	261
4.9.96	storm-control egress-limiting	261
4.9.97	storm-control ingress-limiting	262
4.9.98	storm-control ingress-mode	262

4.9.99	storm-control broadcast (port-related)	263
4.9.100	storm-control egress-limit	263
4.9.101	storm-control ingress-limit	264
4.9.102	storm-control ingress-mode	264
4.9.103	storm-control flowcontrol	265
4.9.104	storm-control flowcontrol per port	266
4.9.105	vlan	267
4.9.106	vlan0-transparent-mode	268
4.9.107	vlan acceptframe	269
4.9.108	vlan database	270
4.9.109	vlan ingressfilter	271
4.9.110	vlan name	272
4.9.111	vlan participation	273
4.9.112	vlan participation all	274
4.9.113	vlan port acceptframe all	275
4.9.114	vlan port ingressfilter all	276
4.9.115	vlan port pvid all	277
4.9.116	vlan port tagging all	278
4.9.117	vlan pvid	279
4.9.118	vlan tagging	280
4.9.119	voice vlan (Global Config Mode)	281
4.9.120	voice vlan <id>	282
4.9.121	voice vlan dot1p	283
4.9.122	voice vlan none	283
4.9.123	voice vlan untagged	284
4.9.124	voice vlan auth	284
4.10	User Account Management Commands	285
4.10.1	disconnect	285
4.10.2	show loginsession	286
4.10.3	show users	287
4.10.4	users defaultlogin	288
4.10.5	users login <user>	289
4.10.6	users access	290
4.10.7	users name	291
4.10.8	users passwd	292
4.10.9	users snmpv3 accessmode	293
4.10.10	users snmpv3 authentication	294
4.10.11	users snmpv3 encryption	295
4.11	System Utilities	296
4.11.1	address-conflict	296

4.11.2	boot skip-aca-on-boot	297
4.11.3	show boot skip-aca-on-boot	297
4.11.4	cablestatus	298
4.11.5	clear eventlog	298
4.11.6	traceroute	299
4.11.7	clear arp-table-switch	299
4.11.8	clear config	300
4.11.9	clear config factory	300
4.11.10	clear counters	300
4.11.11	clear hiper-ring	301
4.11.12	clear igmpsnooping	301
4.11.13	clear mac-addr-table	302
4.11.14	clear pass	302
4.11.15	clear link-aggregation	303
4.11.16	clear signal-contact	303
4.11.17	clear traplog	304
4.11.18	clear ring-coupling	304
4.11.19	clear vlan	304
4.11.20	config-watchdog	305
4.11.21	copy	305
4.11.22	device-status connection-error	314
4.11.23	device-status monitor	315
4.11.24	logout	316
4.11.25	ping	316
4.11.26	signal-contact connection-error	317
4.11.27	signal-contact	317
4.11.28	temperature	319
4.11.29	reboot	320
4.11.30	show reboot	321
4.11.31	reload	322
4.11.32	show reload	323
4.12	LLDP - Link Layer Discovery Protocol	324
4.12.1	show lldp	324
4.12.2	show lldp config	324
4.12.3	show lldp config chassis	325
4.12.4	show lldp config chassis admin-state	325
4.12.5	show lldp config chassis notification-interval	325
4.12.6	show lldp config chassis re-init-delay	326
4.12.7	show lldp config chassis tx-delay	326
4.12.8	show lldp config chassis tx-hold-mult	326

4.12.9	show lldp config chassis tx-interval	327
4.12.10	show lldp config port	328
4.12.11	show lldp config port tlv	329
4.12.12	show lldp med	330
4.12.13	show lldp med interface	331
4.12.14	show lldp med local-device detail	332
4.12.15	show lldp med remote-device	333
4.12.16	show lldp med remote-device detail	334
4.12.17	show lldp remote-data	334
4.12.18	lldp	336
4.12.19	lldp config chassis admin-state	337
4.12.20	lldp config chassis notification-interval	337
4.12.21	lldp config chassis re-init-delay	338
4.12.22	lldp config chassis tx-delay	338
4.12.23	lldp config chassis tx-hold-mult	339
4.12.24	lldp chassis tx-interval	339
4.12.25	clear lldp config all	340
4.12.26	lldp admin-state	340
4.12.27	lldp fdb-mode	341
4.12.28	lldp hm-mode	341
4.12.29	lldp max-neighbors	342
4.12.30	lldp med	343
4.12.31	lldp med all	344
4.12.32	lldp med confignotification	344
4.12.33	lldp med confignotification all	345
4.12.34	lldp med faststartrepeatcount	346
4.12.35	lldp med transmit-tlv	347
4.12.36	lldp med transmit-tlv all	348
4.12.37	lldp notification	349
4.12.38	lldp tlv link-aggregation	349
4.12.39	lldp tlv mac-phy-config-state	349
4.12.40	lldp tlv max-frame-size	350
4.12.41	lldp tlv mgmt-addr	350
4.12.42	lldp tlv pnio	350
4.12.43	lldp tlv pnio-alias	351
4.12.44	lldp tlv pnio-mrp	351
4.12.45	lldp tlv port-desc	351
4.12.46	lldp tlv port-vlan	352
4.12.47	lldp tlv gmrp	352
4.12.48	lldp tlv igmp	352
4.12.49	lldp tlv portsec	353

4.12.50	lldp tlv ptp	353
4.12.51	lldp tlv protocol	353
4.12.52	lldp tlv sys-cap	354
4.12.53	lldp tlv sys-desc	354
4.12.54	lldp tlv sys-name	354
4.12.55	lldp tlv vlan-name	355
4.12.56	name	355
4.13	SNTP - Simple Network Time Protocol	356
4.13.1	show sntp	356
4.13.2	show sntp anycast	358
4.13.3	show sntp client	358
4.13.4	show sntp operation	359
4.13.5	show sntp server	360
4.13.6	show sntp status	360
4.13.7	show sntp time	361
4.13.8	no sntp	361
4.13.9	sntp anycast address	362
4.13.10	sntp anycast transmit-interval	362
4.13.11	sntp anycast vlan	363
4.13.12	sntp client accept-broadcast	363
4.13.13	sntp client disable-after-sync	364
4.13.14	sntp client offset	364
4.13.15	sntp client request-interval	365
4.13.16	no sntp client server	365
4.13.17	sntp client server primary	366
4.13.18	sntp client server secondary	367
4.13.19	sntp client threshold	368
4.13.20	sntp operation	369
4.13.21	sntp server disable-if-local	370
4.13.22	sntp time system	370
4.14	PTP - Precision Time Protocol	371
4.14.1	show ptp	371
4.14.2	show ptp configuration	374
4.14.3	show ptp operation	374
4.14.4	show ptp port	375
4.14.5	show ptp status	376
4.14.6	ptp clock-mode	377
4.14.7	ptp operation	378
4.14.8	ptp sync-lower-bound	378
4.14.9	ptp sync-upper-bound	379

4.14.10	ptp v1 preferred-master	379
4.14.11	ptp v1 re-initialize	380
4.14.12	ptp v1 subdomain-name	380
4.14.13	ptp v1 sync-interval	381
4.14.14	ptp v2bc priority1	382
4.14.15	ptp v2bc priority2	382
4.14.16	ptp v2bc domain	383
4.14.17	ptp v2bc utc-offset	383
4.14.18	ptp v2bc utc-offset-valid	383
4.14.19	ptp v2bc vlan	384
4.14.20	ptp v2bc vlan-priority	384
4.14.21	ptp v1 burst	385
4.14.22	ptp v1 operation	385
4.14.23	ptp v2bc operation	386
4.14.24	ptp v2bc announce-interval	386
4.14.25	ptp v2bc announce-timeout	387
4.14.26	ptp v2bc sync-interval	387
4.14.27	ptp v2bc delay-mechanism	387
4.14.28	ptp v2bc pdelay-interval	388
4.14.29	ptp v2bc network-protocol	388
4.14.30	ptp v2bc v1-compatibility-mode	388
4.14.31	ptp v2bc asymmetry	389
4.14.32	ptp v2tc asymmetry	389
4.14.33	ptp v2tc delay-mechanism	389
4.14.34	ptp v2tc management	390
4.14.35	ptp v2tc multi-domain-mode	390
4.14.36	ptp v2tc network-protocol	391
4.14.37	ptp v2tc operation	391
4.14.38	ptp v2tc pdelay-interval	392
4.14.39	ptp v2tc primary-domain	392
4.14.40	ptp v2tc profile	393
4.14.41	ptp v2tc syntonization	393
4.14.42	ptp v2tc vlan	394
4.14.43	ptp v2tc power-tlv-check	394
4.14.44	ptp v2tc vlan-priority	395
4.14.45	ptp v2tc sync-local-clock	395
4.15	PoE - Power over Ethernet	396
4.15.1	show inlinepower	396
4.15.2	show inlinepower port	396
4.15.3	inlinepower (Global Config)	397

4.15.4	inlinepower (Interface Config)	398
4.15.5	clear inlinepower	398
4.16	PoE+ - Power over Ethernet Plus	399
4.16.1	show inlinepower slot	399
4.16.2	inlinepower budget slot	400
4.16.3	inlinepower threshold slot	401
4.16.4	inlinepower trap slot	401
4.17	Port monitor	402
4.17.1	show port-monitor	403
4.17.2	show port-monitor <slot/port>	404
4.17.3	show port-monitor brief	405
4.17.4	show port-monitor crc-fragment	406
4.17.5	show port-monitor link-flap	406
4.17.6	port-monitor (Global Config)	407
4.17.7	port-monitor (Interface Config)	407
4.17.8	port-monitor action	408
4.17.9	port-monitor condition overload-detection polling-interval (Global Config)	409
4.17.10	port-monitor condition overload-detection (Interface Config)	409
4.17.11	show port-monitor overload-detection	411
4.17.12	port-monitor condition link-flap (Global Config)	412
4.17.13	port-monitor condition link-flap (Interface Config)	412
4.17.14	port-monitor condition crc-fragment (Global Config)	413
4.17.15	port-monitor condition crc-fragment (Interface Config)	413
<b>5</b>	<b>CLI Commands: Switching</b>	<b>415</b>
5.1	Spanning Tree Commands	417
5.1.1	show spanning-tree	417
5.1.2	show spanning-tree interface	420
5.1.3	show spanning-tree mst detailed	421
5.1.4	show spanning-tree mst port detailed	422
5.1.5	show spanning-tree mst port summary	425
5.1.6	show spanning-tree mst summary	426
5.1.7	show spanning-tree summary	427
5.1.8	show spanning-tree vlan	428
5.1.9	spanning-tree	429
5.1.10	spanning-tree auto-edgeport	430
5.1.11	spanning-tree bpduguard	431

5.1.12	spanning-tree configuration name	432
5.1.13	spanning-tree configuration revision	433
5.1.14	spanning-tree edgeport	434
5.1.15	spanning-tree forceversion	435
5.1.16	spanning-tree forward-time	436
5.1.17	spanning-tree guard loop	437
5.1.18	spanning-tree guard none	438
5.1.19	spanning-tree guard root	439
5.1.20	spanning-tree hello-time	440
5.1.21	spanning-tree hold-count	441
5.1.22	spanning-tree max-age	442
5.1.23	spanning-tree max-hops	443
5.1.24	spanning-tree mst	444
5.1.25	spanning-tree mst priority	446
5.1.26	spanning-tree mst vlan	447
5.1.27	spanning-tree mst instance	448
5.1.28	spanning-tree port mode	449
5.1.29	spanning-tree port mode all	450
5.1.30	spanning-tree stp-mrp-mode	451
5.1.31	spanning-tree tcnguard	452
5.2	MRP	453
5.2.1	show mrp	453
5.2.2	show mrp current-domain	454
5.2.3	mrp current-domain	455
5.2.4	mrp delete-domain	457
5.2.5	mrp new-domain	457
5.2.6	arc	458
5.2.7	show arc	459
5.3	HIPER-Ring	461
5.3.1	show hiper-ring	462
5.3.2	hiper-ring	463
5.3.3	hiper-ring mode	463
5.3.4	hiper-ring port primary	464
5.3.5	hiper-ring port secondary	464
5.3.6	hiper-ring recovery-delay	465
5.4	Fast-HIPER-Ring	466
5.4.1	show fast-hiper-ring (MACH1000, RSR20/RSR30)	467
5.4.2	show fast-hiper-ring current-id (MACH1000, RSR20/RSR30)	468



5.4.3	fast-hiper-ring	469
5.5	Redundant Coupling	471
5.5.1	show ring-coupling	472
5.5.2	ring-coupling	474
5.5.3	ring-coupling config	475
5.5.4	ring-coupling net-coupling	476
5.5.5	ring-coupling operation	476
5.5.6	ring-coupling port	477
5.5.7	ring-coupling redundancy-mode	477
5.6	Port Security	478
5.6.1	show port-sec mode	478
5.6.2	show port-sec port	478
5.6.3	port-sec mode	479
5.6.4	port-sec action	480
5.6.5	port-sec allowed-ip	481
5.6.6	port-sec allowed-ip add	481
5.6.7	port-sec allowed-ip remove	482
5.6.8	port-sec allowed-mac	482
5.6.9	port-sec allowed-mac add	483
5.6.10	port-sec allowed-mac remove	483
5.6.11	clear port-sec	484
5.7	DHCP Relay Commands	485
5.7.1	dhcp-relay	486
5.7.2	dhcp-relay	487
5.7.3	show dhcp-relay	488
5.8	DHCP Server Commands	490
5.8.1	DHCP server configuration example	490
5.8.2	show dhcp-server	492
5.8.3	show dhcp-server operation	493
5.8.4	show dhcp-server port	493
5.8.5	show dhcp-server pool	494
5.8.6	dhcp-server addr-probe	494
5.8.7	dhcp-server operation	495
5.8.8	dhcp-server pool add <id>	495
5.8.9	dhcp-server pool modify <id> mode	496
5.8.10	dhcp-server pool modify <id> option	498
5.8.11	dhcp-server pool modify leasetime	499
5.8.12	dhcp-server pool modify <id> hirschmann-device	499
5.8.13	dhcp-server pool enable	500

5.8.14	dhcp-server pool disable	500
5.8.15	dhcp-server pool delete	500
5.9	Sub-Ring Commands	501
5.9.1	show sub-ring	501
5.9.2	sub-ring <id> mode	503
5.9.3	sub-ring <id> operation	504
5.9.4	sub-ring <id> protocol	504
5.9.5	sub-ring <id> port	505
5.9.6	sub-ring <id> ring-name	505
5.9.7	sub-ring <id> vlan	506
5.9.8	sub-ring <id> mrp-domainID	507
5.9.9	sub-ring delete-ring	508
5.9.10	sub-ring new-ring	508
<b>6</b>	<b>CLI Commands: Security</b>	<b>509</b>
6.1	Security Commands	511
6.1.1	authentication login	511
6.1.2	authorization network radius	513
6.1.3	clear dot1x statistics	513
6.1.4	clear radius statistics	514
6.1.5	dot1x defaultlogin	514
6.1.6	dot1x dynamic-vlan enable	515
6.1.7	dot1x guest-vlan	516
6.1.8	dot1x initialize	517
6.1.9	dot1x login	517
6.1.10	dot1x mac-auth-bypass	518
6.1.11	dot1x max-req	519
6.1.12	dot1x max-users	520
6.1.13	dot1x port-control	521
6.1.14	dot1x port-control all	522
6.1.15	dot1x re-authenticate	523
6.1.16	dot1x re-authentication	523
6.1.17	dot1x safe-vlan	524
6.1.18	dot1x system-auth-control	525
6.1.19	dot1x timeout	525
6.1.20	dot1x timeout guest-vlan-period	527
6.1.21	dot1x unauthenticated-vlan	528
6.1.22	dot1x user	529
6.1.23	ip ssh protocol	530
6.1.24	radius accounting mode	531

6.1.25	radius server host	531
6.1.26	radius server key	533
6.1.27	radius server msgauth	533
6.1.28	radius server primary	534
6.1.29	radius server retransmit	535
6.1.30	radius server timeout	536
6.1.31	show radius accounting	536
6.1.32	show authentication	539
6.1.33	show authentication users	540
6.1.34	show dot1x	540
6.1.35	show dot1x users	545
6.1.36	show dot1x clients	546
6.1.37	show ip ssh	547
6.1.38	show radius	548
6.1.39	show radius statistics	549
6.1.40	show users authentication	551
6.1.41	users login	552
6.2	HTTP Commands	553
6.2.1	ip http secure-port	553
6.2.2	ip http secure-protocol	554
6.2.3	ip http server	555
6.2.4	show ip http	556
6.2.5	ip https server	557
6.2.6	ip https port	558
6.2.7	ip https certgen	558
6.2.8	show ip https	559
<b>7</b>	<b>Appendix- VLAN Example</b>	561
7.1	SOLUTION 1	563
7.2	SOLUTION 2	565
<b>8</b>	<b>Glossary</b>	567
<b>9</b>	<b>Index</b>	583
<b>10</b>	<b>Further support</b>	591



## About this Manual

The "GUI" reference manual contains detailed information on using the graphical user interface (web-based interface) to operate the individual functions of the device.

The "Command Line Interface" reference manual contains detailed information on using the Command Line Interface to operate the individual functions of the device.

The "Installation" user manual contains a device description, safety instructions, a description of the display, and the other information that you need to install the device.

The "Basic Configuration" user manual contains the information you need to start operating the device. It takes you step by step from the first startup operation through to the basic settings for operation in your environment.

The "Redundancy Configuration" user manual contains the information you need to select a suitable redundancy procedure and configure that procedure.

The "Industry Protocols" user manual describes how the device is connected by means of a communication protocol commonly used in the industry, such as EtherNet/IP or PROFINET IO.

The HiVision Network Management Software provides you with additional options for smooth configuration and monitoring:

- ▶ Simultaneous configuration of multiple devices
- ▶ Graphic interface with network layout
- ▶ Auto-topology recognition
- ▶ Event log
- ▶ Event handling
- ▶ Client/server structure
- ▶ Browser interface
- ▶ ActiveX control for SCADA integration
- ▶ SNMP/OPC gateway.

## **Maintenance**

Hirschmann are continually working on improving and developing their software. You should regularly check whether there is a new version of the software that provides you with additional benefits. You will find software information and downloads on the product pages of the Hirschmann website.

# 1 Command Structure

The Command Line Interface (CLI) syntax, conventions and terminology are described in this section. Each CLI command is illustrated using the structure outlined below.

# 1.1 Format

Commands are followed by values, parameters, or both.

## ■ Example 1

```
network parms <ipaddr> <netmask> [gateway]
```

- ▶ network parms  
is the command name.
- ▶ <ipaddr> <netmask>  
are the required values for the command.
- ▶ [gateway]  
is the optional value for the command.

## ■ Example 2

```
snmp-server location <loc>
```

- ▶ snmp-server location  
is the command name.
- ▶ <loc>  
is the required parameter for the command.

## ■ Example 3

```
clear vlan
```

- ▶ clear vlan  
is the command name.



## 1.1.1 Command

The text in courier font is to be typed exactly as shown.

## 1.1.2 Parameters

Parameters are order dependent.

Parameters may be mandatory values, optional values, choices, or a combination.

- ▶ `<parameter>`. The `<>` angle brackets indicate that a mandatory parameter is to be entered in place of the brackets and text inside them.
- ▶ `[parameter]`. The `[]` square brackets indicate that an optional parameter may be entered in place of the brackets and text inside them.
- ▶ `choice1 | choice2`. The `|` indicates that only one of the parameters should be entered.
- ▶ The `{ }` curly braces indicate that a parameter must be chosen from the list of choices.

## 1.1.3 Values

### **macaddr**

The MAC address format is six hexadecimal numbers separated by colons, for example 00:06:29:32:81:40.

### **areaid**

Area IDs may be entered in dotted-decimal notation (for example, 0.0.0.1). An area ID of 0.0.0.0 is reserved for the backbone. Area IDs have the same form as IP addresses, but are distinct from IP addresses. The IP network address of the

sub-netted network may be used for the area ID.

**slot/port**

Valid slot and port number separated by forward slashes. For example, 1/1 represents slot number 1 and port number 1.

**logical slot/port**

Logical slot and port number. This is applicable in the case of a link-aggregation (LAG) and vlan router interfaces (9/x). The operator can use the logical slot/port to configure the link-aggregation.

## 1.1.4 Conventions

Network addresses are used to define a link to a remote host, workstation or network. Network addresses are shown using the following syntax:

Address Type	Format	Range
ipaddr	192.168.11.110	0.0.0.0 to 255.255.255.255 (decimal)
macaddr	A7:C9:89:DD:A9:B3	hexadecimal digit pairs

*Table 1: Network Address Syntax*

Double quotation marks such as "System Name with Spaces" set off user defined strings. If the operator wishes to use spaces as part of a name parameter then it must be enclosed in double quotation marks.

Empty strings ("" ) are not valid user defined strings.

Command completion finishes spelling the command when enough letters of a command are typed to uniquely identify the command word. The command may be executed by typing <enter> (command abbreviation) or the command word may be completed by typing the <tab> or <space bar> (command completion).

The value 'Err' designates that the requested value was not internally accessible.

The value of '-----' designates that the value is unknown.

## 1.1.5 Annotations

The CLI allows the user to type single-line annotations at the command prompt for use when writing test or configuration scripts and for better readability. The exclamation point (!) character flags the beginning of a comment. The comment flag character can begin a word anywhere on the command line and all input following this character is ignored. Any command line that begins with the character '!' is recognized as a comment line and ignored by the parser.

Some examples are provided below:

```
! Script file for setting the CLI prompt
set prompt example-switch
! End of the script file
```

## 1.1.6 Special keys

The following list of special keys may be helpful to enter command lines.

BS	delete previous character
Ctrl-A	go to beginning of line
Ctrl-E	go to end of line
Ctrl-F	go forward one character
Ctrl-B	go backward one character
Ctrl-D	delete current character
Ctrl-H	display command history or retrieve a command
Ctrl-U, X	delete to beginning of line
Ctrl-K	delete to end of line
Ctrl-W	delete previous word
Ctrl-T	transpose previous character
Ctrl-P	go to previous line in history buffer
Ctrl-R	rewrites or pastes the line
Ctrl-N	go to next line in history buffer
Ctrl-Y	print last deleted character
Ctrl-Q	enables serial flow
Ctrl-S	disables serial flow
Ctrl-Z	return to root command prompt
Tab, <SPACE>	command-line completion
Exit	go to next lower command prompt
?	list choices

## 1.1.7 Special characters in scripts

Some of the configuration parameters are strings that can contain special characters. When the switch creates a script from the running configuration (by use of the command `#show running-config <scriptname.cli>`), these special characters are written to the script with a so-called escape character preceding them. This ensures that when applying the script, these characters are regarded as a normal part of the configuration parameter, not having the special meaning they usually have.

Character (plain)	Meaning, when entered in the CLI
!	Begin of a comment, ! and the rest of the line will be ignored
"	Begin or end of a string that may contain space characters
'	Begin or end of a string that may contain space characters
?	Shows possible command keywords or parameters
\	The backslash is used as an escape character to mask characters that normally have a special meaning

*Tab. 2: Special characters*

Character (escaped)	Meaning, when entered in the CLI
\!	! becomes part of the string
\"	" becomes part of the string
\'	' becomes part of the string
\?	? becomes part of the string
\\	\ becomes part of the string

*Tab. 3: Special characters escaped*

The commands with strings that may contain these special characters are listed below.

**Note:** Not every string is allowed to contain special characters. The string that is output with the escape characters (if necessary) is shown as "...".

Command	Note
!System Description "..."	"At the beginning of the script
!System Version "..."	"At the beginning of the script

*Tab. 4: Commands in Privileged Exec mode*

Command	Note
snmp-server location "..."	
snmp-server contact "..."	
snmp-server community "..."	
snmp-server community ipaddr <ip> "..."	
snmp-server community ipmask <ip> "..."	
snmp-server community ro "..."	
snmp-server community rw "..."	
no snmp-server community mode "..."	
no snmp-server community "..."	
link-aggregation "..."	
spanning-tree configuration name "..."	
ptp subdomain-name "..."	

*Tab. 5: Commands in Global Config mode*

Command	Note
name "..."	

*Tab. 6: Commands in Interface Config mode*

Command	Note
vlan name <n> "..."	

*Tab. 7: Commands in VLAN Database mode*

When a device creates a script, a human-readable header is included that lists the special characters and the escape characters:

```
!Parameter string escape handling \, 1
!Characters to be preceded with escape char (\): \, !, ", ', ?
```

## 1.1.8 Secrets in scripts

A configuration may include secrets (e. g., passwords). When creating a script, these secrets are written to it in a scrambled form, not in clear text. These secrets may be up to 31 characters long. The format for a scrambled secret is: ":v1:<scrambled secret>:" (without the quotes ("), they were added for readability). v1 denotes the scrambling method (v1 in this case), the value of the scrambled secret is a 64-digit hex string.

The following commands produce scrambled secrets (if necessary):

Command	Note
radius server key acct <ip> <password>	
radius server key auth <ip> <password>	
users passwd <username> <password>	
users snmpv3 encryption <username> des <password>	

*Tab. 8: Commands in Global Config mode*

Applying or validating a script requires the following conditions for a scrambled secret, else it will be considered invalid (usually only relevant if a script is edited manually):



- ▶ string must not be longer than 64 hex digits
- ▶ string must only contain the digits 0-9 and the characters A-F (or a-f)
- ▶ string length must be even



## **2 Quick Start up**

The CLI Quick Start up details procedures to quickly become acquainted with the software.

## 2.1 Quick Starting the Switch

- ▶ Read the device Installation Guide for the connectivity procedure. In-band connectivity allows access to the software locally or from a remote workstation. The device must be configured with IP information (IP address, subnet mask, and default gateway).
- ▶ Turn the Power on.
- ▶ Allow the device to load the software until the login prompt appears. The device's initial state is called the default mode.
- ▶ When the prompt asks for operator login, execute the following steps:
  - ▶ Type the word `admin` in the login area. Since a number of the Quick Setup commands require administrator account rights, we recommend logging into an administrator account. Press the enter key.
  - ▶ Enter the state on delivery password `private`.
  - ▶ Press the enter key
  - ▶ The CLI User EXEC prompt will be displayed.  
User EXEC prompt:  
`(Hirschmann Product) >`
  - ▶ Use “enable” to switch to the Privileged EXEC mode from User EXEC.  
Privileged EXEC prompt:  
`(Hirschmann Product) #`
  - ▶ Use “configure” to switch to the Global Config mode from Privileged EXEC.  
Global Config prompt:  
`(Hirschmann Product) (Config)#`
  - ▶ Use “exit” to return to the previous mode.

## 2.2 System Info and System Setup

This chapter informs you about:

- ▶ Quick Start up Software Version Information
- ▶ Quick Start up Physical Port Data
- ▶ Quick Start up User Account Management
- ▶ Quick Start up IP Address
- ▶ Quick Start up Uploading from Switch to Out-of-Band PC (Only XMODEM)
- ▶ Quick Start up Downloading from Out-of-Band PC to Switch (Only XMODEM)
- ▶ Quick Start up Downloading from TFTP Server
- ▶ Quick Start up Factory Defaults

## ■ Quick Start up Physical Port Data

Command	Details
<code>show port all</code> (in Privileged EXEC)	<p>Displays the Ports</p> <p>slot/port</p> <p>Type - Indicates if the port is a special type of port</p> <p>Admin Mode - Selects the Port Control Administration State</p> <p>Physical Mode - Selects the desired port speed and duplex mode</p> <p>Physical Status - Indicates the port speed and duplex mode</p> <p>Link Status - Indicates whether the link is up or down</p> <p>Link Trap - Determines whether or not to send a trap when link status changes</p> <p>LACP Mode - Displays whether LACP is enabled or disabled on this port.</p>

*Table 9: Quick Start up Physical Port Data*

## ■ Quick Start up User Account Management

Command	Details
<code>show users</code> (in Privileged EXEC)	<p>Displays all of the users that are allowed to access the switch</p> <p>Access Mode - Shows whether the user is able to change parameters on the switch(Read/Write) or is only able to view them (Read Only).</p> <p>As a factory default, the 'admin' user has Read/Write access and the 'user' user has Read Only access. There can only be one Read/Write user and up to five Read Only users.</p>
<code>show login session</code> (in User EXEC)	Displays all of the login session information

*Table 10: Quick Start up User Account Management*

Command	Details
<pre>users passwd &lt;user- name&gt;</pre> (in Global Config)	<p>Allows the user to set passwords or change passwords needed to login</p> <p>A prompt will appear after the command is entered requesting the users old password. In the absence of an old password leave the area blank. The operator must press enter to execute the command.</p> <p>The system then prompts the user for a new password then a prompt to confirm the new password. If the new password and the confirmed password match a message will be displayed.</p> <p>User password should not be more than eight characters in length.</p> <p>Make sure, that the passwords of the users differ from each other. If two or more users try to choose the same password, the CLI will display an error message.</p>
<pre>copy system:running- config nvram:startup-config</pre> (in Privileged EXEC)	<p>This will save passwords and all other changes to the device.</p> <p>If you do not save the configuration by doing this command, all configurations will be lost when a power cycle is performed on the switch or when the switch is reset.</p>
<pre>logout</pre> (in User EXEC and Privileged EXEC)	<p>Logs the user out of the switch</p>

*Table 10: Quick Start up User Account Management*

## ■ Quick Start up IP Address

To view the network parameters the operator can access the device by the following three methods.

- ▶ Simple Network Management Protocol - SNMP
- ▶ Telnet
- ▶ Web Browser

**Note:** After configuring the network parameters it is advisable to execute the command `'copy system:running-config nvram:startup-config'` to ensure that the configurations are not lost.

Command	Details
<pre>show network (in User EXEC)</pre>	<p>Displays the Network Configurations</p> <p>IP Address - IP Address of the switch Default IP is 0.0.0.0</p> <p>Subnet Mask - IP Subnet Mask for the switch Default is 0.0.0.0</p> <p>Default Gateway - The default Gateway for this switch Default value is 0.0.0.0</p> <p>Burned in MAC Address - The Burned in MAC Address used for in-band connectivity</p> <p>Network Configurations Protocol (BOOTP/DHCP) - Indicates which network protocol is being used Default is DHCP</p> <p>Network Configurations Protocol HiDiscovery - Indicates the status of the HiDiscovery protocol. Default is read-write</p> <p>Management VLAN Id - Specifies VLAN id</p> <p>Web Mode - Indicates whether HTTP/Web is enabled.</p> <p>JavaScript Mode - Indicates whether java mode is enabled. When the user accesses the switch's graphical user interface (web interface) and JavaScript Mode is enabled, the switch's web server will deliver a HTML page that contains JavaScript. Some browsers do not support JavaScript. In this case, a HTML page without JavaScript is necessary. In this case, set JavaScript Mode to disabled. Default: enabled.</p>
<pre>network parms &lt;ipaddr&gt; &lt;net- mask&gt; [gateway] (in Privileged EXEC)</pre>	<p>Sets the IP Address, subnet mask and gateway of the router. The IP Address and the gateway must be on the same subnet.</p> <p>IP Address range from 0.0.0.0 to 255.255.255.255</p>

*Table 11: Quick Start up IP Address*



Command	Details
	Subnet Mask range from 0.0.0.0 to 255.255.255.255
	Gateway Address range from 0.0.0.0 to 255.255.255.255

*Table 11: Quick Start up IP Address*

### ■ Quick Start up Downloading from TFTP Server

Before starting a TFTP server download, the operator must complete the Quick Start up for the IP Address.

Command	Details
<code>copy &lt;url&gt; {nvram:startup-config   system:image}</code>	Sets the destination (download) datatype to be an image (system:image) or a configuration file (nvram:startup-config). The URL must be specified as: <code>tftp://ipAddr/filepath/fileName</code> . The nvram:startup-config option downloads the configuration file using tftp and system:image option downloads the code file.

*Table 12: Quick Start up Downloading from TFTP Server*

### ■ Quick Start up Factory Defaults

Command	Details
<code>clear config</code> (in Privileged EXEC Mode)	Enter yes when the prompt pops up to clear all the configurations made to the switch.
<code>copy system:running-config nvram:startup-config</code>	Enter yes when the prompt pops up that asks if you want to save the configurations made to the switch.
<code>reboot</code> (or cold boot the switch) (in Privileged EXEC Mode)	Enter yes when the prompt pops up that asks if you want to reset the system. This is the users choice either reset the switch or cold boot the switch, both work effectively.

*Table 13: Quick Start up Factory Defaults*



## 3 Mode-based CLI

The CLI groups all the commands in appropriate modes according to the nature of the command. A sample of the CLI command modes are described below. Each of the command modes support specific software commands.

- ▶ User Exec Mode
- ▶ Privileged Exec Mode
- ▶ Global Config Mode
- ▶ Vlan Mode
- ▶ Interface Config Mode
- ▶ Line Config Mode

The Command Mode table captures the command modes, the prompts visible in that mode and the exit method from that mode.

Command Mode	Access Method	Prompt	Exit or Access Next Mode
User Exec Mode	This is the first level of access. Perform basic tasks and list system information	(Hirschmann Product) >	Enter Logout command
Privileged Exec Mode	From the User Exec Mode, enter the enable command	(Hirschmann Product) #	To exit to the User Exec mode, enter exit or press Ctrl-Z.
VLAN Mode	From the Privileged User Exec mode, enter the vlan database command	(Hirschmann Product) (Vlan) #	To exit to the Privileged Exec mode, enter the exit command, or press Ctrl-Z to switch to User Exec mode.
Global Config Mode	From the Privileged Exec mode, enter the configure command	(Hirschmann Product) (Config) #	To exit to the Privileged Exec mode, enter the exit command, or press Ctrl-Z to switch to user exec mode.
Interface Config Mode	From the Global Configuration mode, enter the interface <slot/port> command	(Hirschmann Product) (Interface- "if number") #	To exit to the Global Config mode enter exit. To return to user EXEC mode enter ctrl-Z.
Line Config Mode	From the Global Configuration mode, enter the lineconfig command	(Hirschmann Product) (line) #	To exit to the Global Config mode enter exit. To return to User Exec mode enter ctrl-Z.

Table 14: Command Mode

## 3.1 Mode-based Topology

The CLI tree is built on a mode concept where the commands are available according to the interface. Some of the modes are depicted in the following figure.




Fig. 1: Mode-based CLI

## 3.2 Mode-based Command Hierarchy

The CLI is divided into various modes. The Commands in one mode are not available until the operator switches to that particular mode, with the exception of the User Exec mode commands. The User Exec mode commands may also be executed in the Privileged Exec mode.

The commands available to the operator at any point in time depend upon the mode. Entering a question mark (?) at the CLI prompt, displays a list of the available commands and descriptions of the commands.

The CLI provides the following modes:

### User Exec Mode

When the operator logs into the CLI, the User Exec mode is the initial mode. The User Exec mode contains a limited set of commands. The command prompt shown at this level is:

```
Command Prompt: (Hirschmann Product)>
```

### Privileged Exec Mode

To have access to the full suite of commands, the operator must enter the Privileged Exec mode. Privileged users authenticated by login are able to enter the Privileged EXEC mode. From Privileged Exec mode, the operator can issue any Exec command, enter the VLAN mode or enter the Global Configuration mode . The command prompt shown at this level is:

```
Command Prompt: (Hirschmann Product)#
```

### VLAN Mode

This mode groups all the commands pertaining to VLANs. The command prompt shown at this level is:

```
Command Prompt: (Hirschmann Product) (VLAN) #
```

### Global Config Mode

This mode permits the operator to make modifications to the running configuration. General setup commands are grouped in this mode. From the Global Configuration mode, the operator can enter the System Configuration mode, the Physical Port Configuration mode, the

Interface Configuration mode, or the Protocol Specific modes specified below. The command prompt at this level is:

```
Command Prompt: (Hirschmann Product) (Config) #
```

From the Global Config mode, the operator may enter the following configuration modes:

### Interface Config Mode

Many features are enabled for a particular interface. The Interface commands enable or modify the operation of an interface.

In this mode, a physical port is set up for a specific logical connection operation. The Interface Config mode provides access to the router interface configuration commands. The command prompt at this level is:

```
Command Prompt: (Hirschmann Product) (Interface  
<slot/port>) #
```

The resulting prompt for the interface configuration command entered in the Global Configuration mode is shown below:

```
(Hirschmann Product) (Config) # interface 2/1  
(Hirschmann Product) (Interface 2/1) #
```

### Line Config Mode

This mode allows the operator to configure the console interface. The operator may configure the interface from the directly connected console or the virtual terminal used with Telnet. The command prompt at this level is:

```
Command Prompt: (Hirschmann Product) (Line) #
```

### MAC Access-List Config Mode

Use the MAC Access-List Config mode to create a MAC Access-List and to enter the mode containing Mac Access-List configuration commands.

```
(Hirschmann Product) (Config) # mac-access-list  
extended <name>
```

```
Command Prompt: (Hirschmann Product) (Config mac-  
access-list) #
```

## 3.3 Flow of Operation

This section captures the flow of operation for the CLI:

- ▶ The operator logs into the CLI session and enters the User Exec mode. In the User Exec mode the `(Hirschmann Product) (exec)>` prompt is displayed on the screen.

The parsing process is initiated whenever the operator types a command and presses <ENTER>. The command tree is searched for the command of interest. If the command is not found, the output message indicates where the offending entry begins. For instance, command node A has the command "show spanning-tree" but the operator attempts to execute the command "show arpp brief" then the output message would be  
`(Hirschmann Product) (exec)> show sspanning-tree^.`  
`(Hirschmann Product)%Invalid input detected at '^' marker.` If the operator has given an invalid input parameter in the command, then the message conveys to the operator an invalid input was detected. The layout of the output is depicted below:

```
(Hirschmann Product) (exec) #show sspanning-tree
                               ^
(Hirschmann Product) Invalid input detected at '^' marker.
```

*Fig. 2: Syntax Error Message*

After all the mandatory parameters are entered, any additional parameters entered are treated as optional parameters. If any of the parameters are not recognized a syntax error message will be displayed.

- ▶ After the command is successfully parsed and validated, the control of execution goes to the corresponding CLI callback function.

- ▶ For mandatory parameters, the command tree extends till the mandatory parameters make the leaf of the branch. The callback function is only invoked when all the mandatory parameters are provided. For optional parameters, the command tree extends till the mandatory parameters and the optional parameters make the leaf of the branch. However, the call back function is associated with the node where the mandatory parameters are fetched. The call back function then takes care of the optional parameters.
- ▶ Once the control has reached the callback function, the callback function has complete information about the parameters entered by the operator.



## 3.4 “No” Form of a Command

“No” is a specific form of an existing command and does not represent a new or distinct command. Only the configuration commands are available in the “no” form. The behavior and the support details of the “no” form is captured as part of the mapping sheets.

### 3.4.1 Support for “No” Form

Almost every configuration command has a “no” form. In general, use the no form to reverse the action of a command or reset a value back to the default. For example, the `no shutdown interface` configuration command reverses the shutdown of an interface. Use the command without the keyword “no” to re-enable a disabled feature or to enable a feature that is disabled by default.

### 3.4.2 Behavior of Command Help (“?”)

The “no” form is treated as a specific form of an existing command and does not represent a new or distinct command. However, the behavior of the “?” and help text differ for the “no” form (the help message shows only options that apply to the “no” form).

- ▶ The help message is the same for all forms of the command. The help string may be augmented with details about the “no” form behavior.
- ▶ For the `(no interface?)` and `(no inte?)` cases of the “?”, the options displayed are identical to the case when the “no” token is not specified as in `(interface)` and `(inte?)`.



## 4 CLI Commands: Base

This chapter provides detailed explanation of the Switching commands. The commands are divided into five functional groups:

- ▶ Show commands display switch settings, statistics, and other information.
- ▶ Configuration commands configure features and options of the switch. For every configuration command, there is a show command that displays the configuration setting.
- ▶ Copy commands transfer or save configuration and informational files to and from the switch.
- ▶ Clear commands clear
  - some  
(e.g. the "clear arp-table-switch" command which clears the agent's ARP table) or
  - all  
(e.g. the "clear config" command which resets the whole configuration to the factory defaults)

This chapter includes the following configuration types:

- ▶ System information and statistics commands
- ▶ Management commands
- ▶ Device configuration commands
- ▶ User account management commands
- ▶ Security commands
- ▶ System utilities
- ▶ Link Layer Discovery Protocol Commands
- ▶ Simple Network Time Protocol Commands
- ▶ Precision Time Protocol Commands
- ▶ Power over Ethernet Commands

## 4.1 System Information and Statistics

### 4.1.1 show

This command displays the interface's configuration.

#### Format

```
show [all]
```

#### Mode

```
Interface Config
```

#### all

Show all the running configuration parameters on this interface. The configuration parameters will be displayed even if their value is the default value.

### 4.1.2 show address-conflict

This command displays address-conflict settings.

#### Format

```
show address-conflict
```

#### Mode

```
Privileged EXEC and User EXEC
```

### 4.1.3 show arp switch

This command displays the Address Resolution Protocol cache of the switch.

#### Format

```
show arp switch
```

#### Mode

Privileged EXEC and User EXEC

### 4.1.4 show bridge address-learning

This command displays the address-learning setting. The setting can be enable or disable.

#### Format

```
show bridge address-learning
```

#### Mode

Privileged EXEC and User EXEC

### 4.1.5 show bridge address-relearn-detect

This command displays the Bridge Address Relearn Detection setting and the Bridge Address Relearn Threshold.

#### Format

```
show bridge address-relearn-detect
```

#### Mode

Privileged EXEC and User EXEC

#### Bridge Address Relearn Detection

Setting can be enable or disable.

#### Bridge Address Relearn Threshold

The threshold can be 1 to 1024.

### 4.1.6 show bridge aging-time

This command displays the timeout for address aging.

#### Format

```
show bridge aging-time
```

#### Mode

Privileged EXEC and User EXEC

### 4.1.7 **show bridge duplex-mismatch-detect**

This command displays the Bridge Duplex Mismatch Detection setting (Enabled or Disabled).

**Format**

```
show bridge duplex-mismatch-detect
```

**Mode**

```
Privileged EXEC and User EXEC
```

### 4.1.8 **show bridge fast-link-detection**

This command displays the Bridge Fast Link Detection setting.

**Format**

```
show bridge fast-link-detection
```

**Mode**

```
Privileged EXEC and User EXEC
```

### 4.1.9 **show bridge framesize**

This command displays the maximum size of frame (packet size) setting.

**Format**

```
show bridge framesize
```

**Mode**

```
Privileged EXEC and User EXEC
```

### 4.1.10 show bridge vlan-learning

This command displays the bridge vlan-learning mode.

#### Format

```
show bridge vlan-learning
```

#### Mode

Privileged EXEC and User EXEC

### 4.1.11 bridge framesize

Activation of long frames. Configure 1522 or 1632<sup>1)</sup> or 9022<sup>2)</sup> as maximum size of frame (packet size).

#### Default

```
1522
```

#### Format

```
bridge framesize { 1522 | 16321) | 90222) }
```

#### Mode

Global Config

#### bridge framesize 1522

Configure 1522 as maximum size of frame (packet size).

#### bridge framesize 1632 <sup>1)</sup>

Configure 1632 <sup>1)</sup> as maximum size of frame (packet size).

#### bridge framesize 9022 <sup>1)</sup>

Configure 9022 <sup>2)</sup> as maximum size of frame (packet size, jumbo frames).

<sup>1)</sup> On MACH4000, MACH100, MACH1000 and PowerMICE: 1552

<sup>2)</sup> Available for the MACH104 and MACH1040 devices.



### 4.1.12 show config-watchdog

Activating the watchdog enables you to return automatically to the last configuration after a set time period has elapsed. This gives you back your access to the Switch.

#### Format

```
show config-watchdog
```

#### Mode

Privileged EXEC and User EXEC

### 4.1.13 show device-status

The signal device status is for displaying

- ▶ the monitoring functions of the switch,
- ▶ the device status trap setting.

#### Format

```
show device-status  
[monitor|state|trap]
```

#### Mode

Privileged EXEC and User EXEC

#### Device status monitor

Displays the possible monitored events and which of them are monitored:

- the detected failure of at least one of the supply voltages.
- the removal of the ACA

- the removal of a media module
- the temperature limits
- the defective link status of at least one port. With the switch, the indication of link status can be masked by the management for each port. Link status is not monitored in the delivery condition.
- the loss of Redundancy guarantee.

Ring/network coupling:

- The following conditions are reported in Stand-by mode:
- interrupted control line
- partner device running in Stand-by mode.

HIPER-Ring:

- The following condition is reported in RM mode additionally:
- Ring redundancy guaranteed. Ring redundancy is not monitored in the delivery condition.

### Device status state

`Error` The current device status is error.

`No Error` The current device status is no error.

### Device status trap

`enabled` A trap is sent if the device status changes.

`disabled` No trap is sent if the device status changes.

## 4.1.14 show authentication

This command displays users assigned to authentication login lists.

### Format

```
show authentication [users <listname>]
```

### Mode

Privileged EXEC and User EXEC

### 4.1.15 show eventlog

This command displays the event log, which contains error messages from the system. The event log is not cleared on a system reset.

**Format**

```
show eventlog
```

**Mode**

Privileged EXEC and User EXEC

**File**

The file in which the event originated.

**Line**

The line number of the event

**Task Id**

The task ID of the event.

**Code**

The event code.

**Time**

The time this event occurred.

**Note:** Event log information is retained across a switch reset.

## 4.1.16 show interface

This command displays a summary of statistics for a specific port or a count of all CPU traffic based upon the argument.

### Format

```
show interface {<slot/port> |  
                ethernet{<slot/port>|switchport} |  
                switchport}
```

### Mode

Privileged EXEC and User EXEC

The display parameters, when the argument is '`<slot/port>`', is as follows :

#### Packets Received Without Error

The total number of packets (including broadcast packets and multi-cast packets) received by the processor.

#### Packets Received With Error

The number of inbound packets that contained errors preventing them from being deliverable to a higher-layer protocol.

#### Broadcast Packets Received

The total number of packets received that were directed to the broadcast address. Note that this does not include multicast packets.

#### Packets Transmitted Without Error

The total number of packets transmitted out of the interface.

#### Transmit Packets Errors

The number of outbound packets that could not be transmitted because of errors.

#### Collisions Frames

The best estimate of the total number of collisions on this Ethernet segment.

#### Time Since Counters Last Cleared

The elapsed time, in days, hours, minutes, and seconds since the statistics for this port were last cleared.

The display parameters, when the argument is 'switchport', is as follows :

**Packets Received Without Error**

The total number of packets (including broadcast packets and multi-cast packets) received by the processor.

**Broadcast Packets Received**

The total number of packets received that were directed to the broadcast address. Note that this does not include multicast packets.

**Packets Received With Error**

The number of inbound packets that contained errors preventing them from being deliverable to a higher-layer protocol.

**Packets Transmitted Without Error**

The total number of packets transmitted out of the interface.

**Broadcast Packets Transmitted**

The total number of packets that higher-level protocols requested to be transmitted to the Broadcast address, including those that were discarded or not sent.

**Transmit Packet Errors**

The number of outbound packets that could not be transmitted because of errors.

**Address Entries Currently In Use**

The total number of Forwarding Database Address Table entries now active on the switch, including learned and static entries.

**VLAN Entries Currently In Use**

The number of VLAN entries presently occupying the VLAN table.

**Time Since Counters Last Cleared**

The elapsed time, in days, hours, minutes, and seconds since the statistics for this switch were last cleared.

## 4.1.17 show interface ethernet

This command displays detailed statistics for a specific port or for all CPU traffic based upon the argument.

### Format

```
show interface ethernet {<slot/port> | switchport}
```

### Mode

Privileged EXEC and User EXEC

The display parameters, when the argument is '<slot/port>', are as follows :

### Packets Received

**Octets Received** - The total number of octets of data (including those in bad packets) received on the network (excluding framing bits but including Frame Check Sequence (FCS) octets). This object can be used as a reasonable estimate of ethernet utilization. If greater precision is desired, the etherStatsPkts and etherStatsOctets objects should be sampled before and after a common interval. ----- The result of this equation is the value Utilization which is the percent utilization of the ethernet segment on a scale of 0 to 100 percent.

**Packets Received < 64 Octets** - The total number of packets (including bad packets) received that were < 64 octets in length (excluding framing bits but including FCS octets).

**Packets Received 64 Octets** - The total number of packets (including bad packets) received that were 64 octets in length (excluding framing bits but including FCS octets).

**Packets Received 65-127 Octets** - The total number of packets (including bad packets) received that were between 65 and 127 octets in length inclusive (excluding framing bits but including FCS octets).

**Packets Received 128-255 Octets** - The total number of packets (including bad packets) received that were between 128 and 255 octets in length inclusive (excluding framing bits but including FCS octets).

**Packets Received 256-511 Octets** - The total number of packets (including bad packets) received that were between 256 and 511 octets in length inclusive (excluding framing bits but including FCS octets).

**Packets Received 512-1023 Octets** - The total number of packets (including bad packets) received that were between 512 and 1023

octets in length inclusive (excluding framing bits but including FCS octets).

**Packets Received 1024-1518 Octets** - The total number of packets (including bad packets) received that were between 1024 and 1518 octets in length inclusive (excluding framing bits but including FCS octets).

**Packets Received 1519-1522 Octets** - The total number of packets (including bad packets) received that were between 1519 and 1522 octets in length inclusive (excluding framing bits but including FCS octets).

**Packets Received > 1522 Octets** - The total number of packets received that were longer than 1522 octets (excluding framing bits, but including FCS octets) and were otherwise well formed.

### **Packets Received Successfully**

**Total** - The total number of packets received that were without errors.

**Unicast Packets Received** - The number of subnetwork-unicast packets delivered to a higher-layer protocol.

**Multicast Packets Received** - The total number of good packets received that were directed to a multicast address. Note that this number does not include packets directed to the broadcast address.

**Broadcast Packets Received** - The total number of good packets received that were directed to the broadcast address. Note that this does not include multicast packets.

### **Packets Received with MAC Errors**

**Total** - The total number of inbound packets that contained errors preventing them from being deliverable to a higher-layer protocol.

**Jabbers Received** - The total number of packets received that were longer than 1518 octets (excluding framing bits, but including FCS octets), and had either a bad Frame Check Sequence (FCS) with an integral number of octets (FCS Error) or a bad FCS with a non-integral number of octets (Alignment Error). Note that this definition of jabber is different than the definition in IEEE-802.3 section 8.2.1.5 (10BASE5) and section 10.3.1.4 (10BASE2). These documents define jabber as the condition where any packet exceeds 20 ms. The allowed range to detect jabber is between 20 ms and 150 ms.

**Fragments/Undersize Received** - The total number of packets received that were less than 64 octets in length (excluding framing bits but including FCS octets).

**Alignment Errors** - The total number of packets received that had a length (excluding framing bits, but including FCS octets) of between 64 and 1518 octets, inclusive, but had a bad Frame Check Sequence (FCS) with a non-integral number of octets.

**Rx FCS Errors** - The total number of packets received that had a length (excluding framing bits, but including FCS octets) of between 64 and 1518 octets, inclusive, but had a bad Frame Check Sequence (FCS) with an integral number of octets

**Overruns** - The total number of frames discarded as this port was overloaded with incoming packets, and could not keep up with the inflow.

### Received Packets not forwarded

**Total** - A count of valid frames received which were discarded (i.e. filtered) by the forwarding process.

**Local Traffic Frames** - The total number of frames dropped in the forwarding process because the destination address was located off of this port.

**802.3x Pause Frames Received** - A count of MAC Control frames received on this interface with an opcode indicating the PAUSE operation. This counter does not increment when the interface is operating in half-duplex mode.

**Unacceptable Frame Type** - The number of frames discarded from this port due to being an unacceptable frame type.

**VLAN Membership Mismatch** - The number of frames discarded on this port due to ingress filtering.

**VLAN Viable Discards** - The number of frames discarded on this port when a lookup on a particular VLAN occurs while that entry in the VLAN table is being modified, or if the VLAN has not been configured.

**Multicast Tree Viable Discards** - The number of frames discarded when a lookup in the multicast tree for a VLAN occurs while that tree is being modified.

**Reserved Address Discards** - The number of frames discarded that are destined to an IEEE 802.1 reserved address and are not supported by the system.

**Broadcast Storm Recovery** - The number of frames discarded that are destined for FF:FF:FF:FF:FF:FF when Broadcast Storm Recovery is enabled.

**CFI Discards** - The number of frames discarded that have CFI bit set and the addresses in RIF are in non-canonical format.



**Upstream Threshold** - The number of frames discarded due to lack of cell descriptors available for that packet's priority level.

### **Packets Transmitted Octets**

**Total Bytes** - The total number of octets of data (including those in bad packets) transmitted into the network (excluding framing bits but including FCS octets). This object can be used as a reasonable estimate of ethernet utilization. If greater precision is desired, the etherStatsPkts and etherStatsOctets objects should be sampled before and after a common interval. -----

**Packets Transmitted 64 Octets** - The total number of packets (including bad packets) transmitted that were 64 octets in length (excluding framing bits but including FCS octets).

**Packets Transmitted 65-127 Octets** - The total number of packets (including bad packets) transmitted that were between 65 and 127 octets in length inclusive (excluding framing bits but including FCS octets).

**Packets Transmitted 128-255 Octets** - The total number of packets (including bad packets) transmitted that were between 128 and 255 octets in length inclusive (excluding framing bits but including FCS octets).

**Packets Transmitted 256-511 Octets** - The total number of packets (including bad packets) transmitted that were between 256 and 511 octets in length inclusive (excluding framing bits but including FCS octets).

**Packets Transmitted 512-1023 Octets** - The total number of packets (including bad packets) transmitted that were between 512 and 1023 octets in length inclusive (excluding framing bits but including FCS octets).

**Packets Transmitted 1024-1518 Octets** - The total number of packets (including bad packets) transmitted that were between 1024 and 1518 octets in length inclusive (excluding framing bits but including FCS octets).

**Packets Transmitted 1519-1522 Octets** - The total number of packets (including bad packets) transmitted that were between 1519 and 1522 octets in length inclusive (excluding framing bits but including FCS octets).

**Max Info** - The maximum size of the Info (non-MAC) field that this port will receive or transmit.

## Packets Transmitted Successfully

**Total** - The number of frames that have been transmitted by this port to its segment.

**Unicast Packets Transmitted** - The total number of packets that higher-level protocols requested be transmitted to a subnetwork-unicast address, including those that were discarded or not sent.

**Multicast Packets Transmitted** - The total number of packets that higher-level protocols requested be transmitted to a Multicast address, including those that were discarded or not sent.

**Broadcast Packets Transmitted** - The total number of packets that higher-level protocols requested be transmitted to the Broadcast address, including those that were discarded or not sent.

## Transmit Errors

**Total Errors** - The sum of Single, Multiple, and Excessive Collisions.

**Tx FCS Errors** - The total number of packets transmitted that had a length (excluding framing bits, but including FCS octets) of between 64 and 1518 octets, inclusive, but had a bad Frame Check Sequence (FCS) with an integral number of octets

**Oversized** - The total number of frames that exceeded the max permitted frame size. This counter has a max increment rate of 815 counts per sec. at 10 Mb/s.

**Underrun Errors** - The total number of frames discarded because the transmit FIFO buffer became empty during frame transmission.

## Transmit Discards

**Total Discards** - The sum of single collision frames discarded, multiple collision frames discarded, and excessive frames discarded.

**Single Collision Frames** - A count of the number of successfully transmitted frames on a particular interface for which transmission is inhibited by exactly one collision.

**Multiple Collision Frames** - A count of the number of successfully transmitted frames on a particular interface for which transmission is inhibited by more than one collision.

**Excessive Collisions** - A count of frames for which transmission on a particular interface is discontinued due to excessive collisions.

**Port Membership** - The number of frames discarded on egress for this port due to egress filtering being enabled.

**VLAN Viable Discards** - The number of frames discarded on this port when a lookup on a particular VLAN occurs while that entry in the VLAN table is being modified, or if the VLAN has not been configured.

### Protocol Statistics

**BPDUs received** - The count of BPDUs (Bridge Protocol Data Units) received in the spanning tree layer.

**BPDUs Transmitted** - The count of BPDUs (Bridge Protocol Data Units) transmitted from the spanning tree layer.

**802.3x Pause Frames Received** - A count of MAC Control frames received on this interface with an opcode indicating the PAUSE operation. This counter does not increment when the interface is operating in half-duplex mode.

**GVRP PDU's Received** - The count of GVRP PDU's received in the GARP layer.

**GMRP PDU's received** - The count of GMRP PDU's received in the GARP layer.

**GMRP PDU's Transmitted** - The count of GMRP PDU's transmitted from the GARP layer.

**GMRP Failed Registrations** - The number of times attempted GMRP registrations could not be completed.

**STP BPDUs Transmitted** - Spanning Tree Protocol Bridge Protocol Data Units sent

**STP BPDUs Received** - Spanning Tree Protocol Bridge Protocol Data Units received

**RST BPDUs Transmitted** - Rapid Spanning Tree Protocol Bridge Protocol Data Units sent

**RSTP BPDUs Received** - Rapid Spanning Tree Protocol Bridge Protocol Data Units received

**MSTP BPDUs Transmitted** - Multiple Spanning Tree Protocol Bridge Protocol Data Units sent

**MSTP BPDUs Received** - Multiple Spanning Tree Protocol Bridge Protocol Data Units received

### Dot1x Statistics

**EAPOL Frames Received**- The number of valid EAPOL frames of any type that have been received by this authenticator.

**EAPOL Frames Transmitted** - The number of EAPOL frames of any type that have been transmitted by this authenticator.

### Time Since Counters Last Cleared

The elapsed time, in days, hours, minutes, and seconds since the statistics for this port were last cleared.

The display parameters, when the argument is 'switchport, are as follows :

**Octets Received** - The total number of octets of data received by the processor (excluding framing bits but including FCS octets).

**Total Packets Received Without Error**- The total number of packets (including broadcast packets and multicast packets) received by the processor.

**Unicast Packets Received** - The number of subnetwork-unicast packets delivered to a higher-layer protocol.

**Multicast Packets Received** - The total number of packets received that were directed to a multicast address. Note that this number does not include packets directed to the broadcast address.

**Broadcast Packets Received** - The total number of packets received that were directed to the broadcast address. Note that this does not include multicast packets.

**Receive Packets Discarded** - The number of inbound packets which were chosen to be discarded even though no errors had been detected to prevent their being deliverable to a higher-layer protocol. A possible reason for discarding a packet could be to free up buffer space.

**Octets Transmitted** - The total number of octets transmitted out of the interface, including framing characters.

**Packets Transmitted without Errors** - The total number of packets transmitted out of the interface.

**Unicast Packets Transmitted** - The total number of packets that higher-level protocols requested be transmitted to a subnetwork-unicast address, including those that were discarded or not sent.

**Multicast Packets Transmitted** - The total number of packets that higher-level protocols requested be transmitted to a Multicast address, including those that were discarded or not sent.

**Broadcast Packets Transmitted** - The total number of packets that higher-level protocols requested be transmitted to the Broadcast address, including those that were discarded or not sent.

**Transmit Packets Discarded** - The number of outbound packets which were chosen to be discarded even though no errors had been detected to prevent their being deliverable to a higher-layer protocol. A possible reason for discarding a packet could be to free up buffer space.

**Most Address Entries Ever Used** - The highest number of Forwarding Database Address Table entries that have been learned by this switch since the most recent reboot.

**Address Entries in Use** - The number of Learned and static entries in the Forwarding Database Address Table for this switch.

**Maximum VLAN Entries** - The maximum number of Virtual LANs (VLANs) allowed on this switch.

**Most VLAN Entries Ever Used** - The largest number of VLANs that have been active on this switch since the last reboot.

**Static VLAN Entries** - The number of presently active VLAN entries on this switch that have been created statically.

**Dynamic VLAN Entries** - The number of presently active VLAN entries on this switch that have been created by GVRP registration.

**VLAN Deletes** - The number of VLANs on this switch that have been created and then deleted since the last reboot.

#### **Time Since Counters Last Cleared**

The elapsed time, in days, hours, minutes, and seconds, since the statistics for this switch were last cleared.

### **4.1.18 show interface switchport**

This command displays data concerning the internal port to the management agent.

#### **Format**

```
show interface switchport
```

#### **Mode**

```
Privileged EXEC and User EXEC
```

## 4.1.19 show interface utilization

This command displays the utilization statistics for the entire device.

### Format

```
show interface utilization
```

### Mode

```
Global Config
```

### Interface

Display port number in <slot/port> notation.

### Utilization

Display the utilization on this port.

Possible values: 0..100.00%

### Lower threshold

Display the lower threshold setting for the utilization statistics on this port.

Possible values: 0..100.00%

### Upper threshold

Display the upper threshold setting for the utilization statistics on this port.

Possible values: 0..100.00%

### Alarm condition

Display the alarm condition setting for the utilization statistics on this port.

Possible values: true, false

## 4.1.20 show logging

This command displays the trap log maintained by the switch. The trap log contains a maximum of 256 entries that wrap.

### Format

```
show logging [buffered | hosts | traplogs |  
snmp-requests]
```

### Mode

Privileged EXEC and User EXEC

### buffered

Display buffered (in-memory) log entries.

### hosts

Display logging hosts.

### traplogs

Display trap records.

### snmp-requests

Display logging SNMP requests and severity level.

## 4.1.21 show mac-addr-table

This command displays the forwarding database entries. If the command is entered with no parameter, the entire table is displayed. This is the same as entering the optional *all* parameter. Alternatively, the administrator can enter a MAC Address to display the table entry for the requested MAC address and all entries following the requested MAC address.

**Note:** This command displays only learned unicast addresses. For other addresses use the command `show mac-filter-table`.

See “[show mac-filter-table gmrp](#)” on page 235.

### Format

```
show mac-addr-table [<macaddr> <1-4042> | all]
```

### Mode

Privileged EXEC and User EXEC

### Mac Address

A unicast MAC address for which the switch has forwarding and or filtering information. The format is 6 or 8 two-digit hexadecimal numbers that are separated by colons, for example 01:23:45:67:89:AB.

### Slot/Port

The port which this address was learned.

### if Index

This object indicates the ifIndex of the interface table entry associated with this port.

### Status

The status of this entry. The meanings of the values are:

**Learned** The value of the corresponding instance was learned by observing the source MAC addresses of incoming traffic, and is currently in use.

**Management** The value of the corresponding instance (system MAC address) is also the value of an existing instance of `dot1dStaticAddress`.



## 4.1.22 show signal-contact

The signal contact is for displaying

- ▶ the manual setting and the current state of the signal contact,
- ▶ the monitoring functions of the switch,
- ▶ the signal-contacts trap setting.

### Format

```
show signal-contact
    [1|2|all [mode|monitor|state|trap]]
```

### Mode

Privileged EXEC and User EXEC

### Signal contact mode

**Auto** The signal contact monitors the functions of the switch which makes it possible to perform remote diagnostics.

A break in contact is reported via the zero-potential signal contact (relay contact, closed circuit).

**Device Status** The signal contact monitors the device-status.

**Manual** This command gives you the option of remote switching the signal contact.

### Signal contact monitor

Displays the possible monitored events and which of them are monitored:

- the detected failure of at least one of the supply voltages.
- the removal of the ACA
- the removal of a media module
- the temperature limits
- the defective link status of at least one port. With the switch, the indication of link status can be masked by the management for each port. Link status is not monitored in the delivery condition.
- the loss of Redundancy guarantee.

Ring/network coupling:

- The following conditions are reported in Stand-by mode:
- interrupted control line
- partner device running in Stand-by mode.

HIPER-Ring:

- The following condition is reported in RM mode additionally:
- Ring redundancy guaranteed. Ring redundancy is not monitored in the delivery condition.

**Signal contact manual setting**

`closed` The signal contact's manual setting is closed.

`open` The signal contact's manual setting is open.

**Signal contact operating state**

`closed` The signal contact is currently closed.

`open` The signal contact is currently open.

**Signal contact trap**

`enabled` A trap is sent if the signal contact state changes.

`disabled` No trap is sent if the signal contact state changes.

**Note:** To show the signal contact's port related settings, use the command `show port {<slot/port> | all}` (see [“show port” on page 243](#)).

### 4.1.23 show slot

This command is used to display information about slot(s).  
For [slot] enter the slot ID.

**Format**

```
show slot [slot]
```

**Mode**

Privileged EXEC, Global Config

**Slot**

Display the number of the media module slot.

**Status**

`Full` The media module slot is equipped with a module.

`Empty` The media module slot is not equipped.

**Admin State**

**Note:** This feature is available for MS20/MS30, PowerMICE, MACH102 and MACH4000 devices.

`Enable` The media module slot is logically enabled.

`Disable` The media module slot is logically disabled.

**Configured Card Model ID**

Display the type of the media module.

**Card Description**

Display the type of the media module.

**Product Code**

Display the type of the media module.

**Pluggable**

`Yes` The module is pluggable.

`No` The module is not pluggable.

## 4.1.24 show running-config

This command is used to display the current setting of different protocol packages supported on the switch. This command displays only those parameters, the values of which differ from default value. The output is displayed in the script format, which can be used to configure another switch with the same configuration.

### Format

```
show running-config [all | <scriptname>]
```

### Mode

Privileged EXEC

### all

Show all the running configuration on the switch. All configuration parameters will be output even if their value is the default value.

### <scriptname>

Script file name for writing active configuration.

**Note:** Make sure that the file extension is .cli, that the file name does not exceed 16 characters, does not start with a dot (.) and does not contain a directory.

## 4.1.25 show sysinfo

This command displays switch information.

### Format

```
show sysinfo
```

### Mode

Privileged EXEC and User EXEC

### Alarm

Displays the latest present Alarm for a signal contact.

### System Description

Text used to identify this switch.

### System Name

Name used to identify the switch.

### System Location

Text used to identify the location of the switch. May be up to 31 alpha-numeric characters. The factory default is blank.

### System Contact

Text used to identify a contact person for this switch. May be up to 31 alpha-numeric characters. The factory default is blank.

### System UpTime

The time in days, hours and minutes since the last switch reboot.

### System Date and Time

The system clock's date and time in local time zone.

### System IP Address

The system's IP address.

### Boot Software Release

The boot code's version number.

### Boot Software Build Date

The boot code's build date.

### Operating system Software Release

The operating system's software version number.

### Operating system Software Build Date

The operating system's software build date.

**Running Software Release**

The operating system's software version number.

**Running Software Build Date**

The operating system's software build date.

**Stored Software Release**

The stored operating system's software version number.

**Stored Software Build Date**

The stored operating system's software build date.

**Backup Software Release**

The backup operating system's software version number.

**Backup Software Build Date**

The backup operating system's software build date.

**Backplane Hardware Revision**

The hardware's revision number.

**Backplane Hardware Description**

The hardware's device description.

**Serial Number (Backplane)**

The hardware's serial number.

**Base MAC Address (Backplane)**

The hardware's base MAC address.

**Number of MAC Addresses (Backplane)**

The number of hardware MAC addresses.

**Configuration state**

The state of the actual configuration.

**Configuration signature**

The signature (watermark) of the stored configuration. The signature changes each time the configuration is saved.

**Auto Config Adapter, State**

The Auto Configuration Adapter's state.

**Auto Config Adapter, Serial Number**

The Auto Configuration Adapter's serial number (if present and operative).

**Fan Status**

The status of the MACH4000 fan.

**Power Supply Information**

The status of the power supplies.

**Media Module Information**

The description of each media module

- Description: media module type,
  - Serial Number of the media modul (if available),
- SFP Information:
- SFP Part ID: SFP type (if available),
  - SFP Serial No. of the SFP module (if available),
  - SFP Supported: yes/no,
  - SFP Temperature (°C, F),
  - SFP Tx Pwr, SFP transmit power (dBm / mW),
  - SFP Rx Pwr, SFP receive power (dBm / mW),
  - SFP Rx Pwr State: ok/warning/alarm.

**CPU Utilization**

The utilization of the central processing unit.

**Average CPU Utilization**

The average utilization of the central processing unit.

**Flashdisk**

Free memory on flashdisk (in Kbytes).

## 4.1.26 show temperature

**Note:** The command is available for RS20/RS30/RS40, MS20/MS30, RSR20/RSR30, MACH100, MACH1000, PowerMICE, MACH4000 and OCTOPUS devices.

This command displays the lower and upper temperature limit for sending a trap.

### Format

```
show temperature
```

### Mode

Privileged EXEC and User EXEC

## 4.1.27 utilization alarm-threshold

Use this command to add the alarm threshold value for monitoring bandwidth utilization of the interface.

### Format

```
utilization alarm-threshold  
    {lower <0..10000> | upper <0..10000>}
```

### Mode

Interface Config

### lower

Enter lower utilization alarm threshold in the range of 0..10000 where 10000 represents 100%.

### upper

Enter upper utilization alarm threshold in the range of 0..10000 where 10000 represents 100%.



## 4.2 Debug Commands

### 4.2.1 debug tcpdump help

Run diagnostics commands. With the TCP dump you run a packet analyzer for capturing network traffic.

This command displays the supported options and expressions for the tcpdump command.

#### Format

```
debug tcpdump help
```

#### Mode

Privileged EXEC

### 4.2.2 debug tcpdump start cpu

Run diagnostics commands. With the TCP dump you run a packet analyzer for capturing network traffic.

This command starts a capture on the CPU interface with the options and expressions in the <command> parameter.

Without the <command> parameter this command starts a capture on the CPU interface using default options and no explicit filtering.

#### Format

```
debug tcpdump start cpu <command>
```

#### Mode

Privileged EXEC

### 4.2.3 **debug tcpdump start cpu filter**

Run diagnostics commands. With the TCP dump you run a packet analyzer for capturing network traffic.

This command starts a capture on the CPU interface with the options and expressions in the filter file.

#### **Format**

```
debug tcpdump start cpu filter <capturefilter>
```

#### **Mode**

Privileged EXEC

### 4.2.4 **debug tcpdump stop**

Run diagnostics commands. With the TCP dump you run a packet analyzer for capturing network traffic.

This command stops a running capture on the CPU interface.

#### **Format**

```
debug tcpdump stop
```

#### **Mode**

Privileged EXEC

### 4.2.5 debug tcpdump filter show

Run diagnostics commands. With the TCP dump you run a packet analyzer for capturing network traffic.

This command shows a saved filter file stored in flash memory.

#### Format

```
debug tcpdump filter show <capturefilter>
```

#### Mode

Privileged EXEC

### 4.2.6 debug tcpdump filter list

Run diagnostics commands. With the TCP dump you run a packet analyzer for capturing network traffic.

This command lists all saved filter files stored in flash memory.

#### Format

```
debug tcpdump filter list
```

#### Mode

Privileged EXEC

## 4.2.7 debug tcpdump filter delete

Run diagnostics commands. With the TCP dump you run a packet analyzer for capturing network traffic.

This command removes a saved filter file from the flash memory.

### Format

```
debug tcpdump filter delete <capturefilter>
```

### Mode

Privileged EXEC

## 4.3 Management VLAN Commands

### 4.3.1 network mgmt\_vlan

This command configures the Management VLAN ID. If you enter the VLAN ID "0", the agent can be accessed by all VLANs.

**Default**

1

**Format**

```
network mgmt_vlan <0-4042>
```

**Mode**

Privileged EXEC

## 4.4 Class of Service (CoS) Commands

This chapter provides a detailed explanation of the QoS CoS commands. The following commands are available.

The commands are divided into these different groups:

- ▶ Configuration Commands are used to configure features and options of the switch. For every configuration command there is a show command that will display the configuration setting.
- ▶ Show commands are used to display device settings, statistics and other information.

**Note:** The 'Interface Config' mode only affects a single interface, whereas the 'Global Config' mode is applied to all interfaces.

### 4.4.1 classofservice dot1p-mapping

This command maps an 802.1p priority to an internal traffic class for a device when in 'Global Config' mode. The number of available traffic classes may vary with the platform. Userpriority and trafficclass can both be the range from 0-7. The command is only available on platforms that support priority to traffic class mapping on a 'per-port' basis, and the number of available traffic classes may vary with the platform.

#### Format

```
classofservice dot1p-mapping
    <userpriority> <trafficclass>
```

#### Mode

Global Config or Interface Config

#### userpriority

Enter the 802.1p priority (0-7).

#### trafficclass

Enter the traffic class to map the 802.1p priority (0-3).

#### ■ no classofservice dot1p-mapping

This command restores the default mapping of the 802.1p priority to an internal traffic class.

#### Format

```
no classofservice dot1p-mapping
```

#### Modes

Global Config or Interface Config

## 4.4.2 classofservice ip-dscp-mapping

This command maps an IP DSCP value to an internal traffic class. The <ipdscp> value is specified as either an integer from 0 to 63, or symbolically through one of the following keywords: af11, af12, af13, af21, af22, af23, af31, af32, af33, af41, af42, af43, be, cs0, cs1, cs2, cs3, cs4, cs5, cs6, cs7, ef.

### Format

```
classofservice ip-dscp-mapping
                        <ipdscp> <trafficclass>
```

### Mode

Global Config

### ipdscp

Enter the IP DSCP value in the range of 0 to 63 or an IP DSCP keyword (af11, af12, af13, af21, af22, af23, af31, af32, af33, af41, af42, af43, be, cs0, cs1, cs2, cs3, cs4, cs5, cs6, cs7, ef).

### trafficclass

Enter the traffic class to map the 802.1p priority (0-3).

### ■ no classofservice ip-dscp-mapping

This command restores the default mapping of the IP DSCP value to an internal traffic class.

### Format

```
no classofservice dot1p-mapping
```

### Modes

Global Config



### 4.4.3 classofservice trust

This command sets the class of service trust mode of an interface. The mode can be set to trust one of the Dot1p (802.1p) or IP DSCP packet markings.

**Note:** In `trust ip-dscp` mode the switch modifies the vlan priority for outgoing frames according to

– the DSCP mapping and VLAN mapping table

(PowerMICE, MACH1000, MACH4000)

– the a fix mapping table

(see Reference Manual „GUI Graphical User Interface“ (Web-based Interface) for further details).

#### Format

```
classofservice trust dot1p | ip-dscp
```

#### Mode

Global Config or

Interface Config (PowerMICE, MACH1000, MACH4000)

#### ■ no classofservice trust

This command sets the interface mode to untrusted, i.e. the packet priority marking is ignored and the default port priority is used instead.

#### Format

```
no classofservice trust
```

#### Modes

Global Config or

Interface Config (PowerMICE, MACH1000, MACH4000)

### 4.4.4 show classofservice dot1p-mapping

This command displays the current 802.1p priority mapping to internal traffic classes for a specific interface. The slot/port parameter is required on platforms that support priority to traffic class mapping on a 'per-port' basis.

Platforms that support priority to traffic class mapping on a per-port basis:

**Format**

```
show classofservice dot1p-mapping
```

Platforms that do not support priority to traffic class mapping on a per-port basis:

**Format**

```
Show classofservice dot1p-mapping
```

**Mode**

```
Privileged EXEC and User EXEC
```

### 4.4.5 **show classofservice ip-dscp-mapping**

This command displays the current IP DSCP mapping to internal traffic classes for the global configuration settings.

**Format**

```
show classofservice ip-dscp-mapping [<slot/port>]
```

**Mode**

Privileged EXEC

The following information is repeated for each user priority.

**IP DSCP**

The IP DSCP value.

**Traffic Class**

The traffic class internal queue identifier to which the IP DSCP value is mapped.

**slot/port**

Valid slot and port number separated by forward slashes.

## 4.4.6 show classofservice trust

This command displays the current trust mode for the specified interface. The slot/port parameter is optional. If specified, the trust mode of the interface is displayed. If omitted, the most recent global configuration settings are displayed.

### Format

```
show classofservice trust [slot/port]
```

### Mode

Privileged EXEC

### Class of Service Trust Mode

The current trust mode: Dot1p, IP DSCP, or Untrusted.

### Untrusted Traffic Class

The traffic class used for all untrusted traffic. This is only displayed when the COS trust mode is set to 'untrusted'.

### slot/port

Valid slot and port number separated by forward slashes.

## 4.4.7 vlan port priority all

This command configures the port priority assigned for untagged packets for all ports presently plugged into the device. The range for the priority is 0-7. Any subsequent per port configuration will override this configuration setting.

### Format

```
vlan port priority all <priority>
```

### Mode

Global Config

### 4.4.8 vlan priority

This command configures the default 802.1p port priority assigned for untagged packets for a specific interface. The range for the priority is 0-7

**Default**

0

**Format**

```
vlan priority <priority>
```

**Mode**

Interface Config

## 4.4.9 **dvlan-tunnel etherType**

**Note:** This command is available for the RS20/RS30/RS40, RSB20, MS20/MS30, RSR20/RSR30, MACH100, MACH104, MACH1000, MACH1040, MACH4002-24G/48G (XG), OCTOPUS, OS20/OS30 devices.

This command configures the etherType for all core ports. The etherType may have the values of 802.1q, vMAN or custom. The configured etherType is used for VLAN classification on all ports which are configured as core ports.

### **Default**

```
802.1Q
```

### **Format**

```
dvlan-tunnel etherType  
                {802.1Q | vman | custom <0-65535>}
```

### **Mode**

```
Global Config
```

### **802.1Q**

Configure the etherType as 0x8100.

### **custom**

Custom configure the etherType for the DVlan tunnel.

Range for the optional value of the custom etherType: 0 to 65535.

### **vman**

Configure the etherType as 0x88A8.

## 4.4.10 mode dvlan-tunnel

**Note:** This command is available for the RS20/RS30/RS40, RSB20, MS20/MS30, RSR20/RSR30, MACH100, MACH104, MACH1000, MACH1040, MACH4002-24G/48G (XG), OCTOPUS, OS20/OS30 devices.

Use this command to configure the port either as core port or access port.

### Default

Disabled

### Format

```
mode dvlan-tunnel {access | core}
```

### Mode

Interface Config

### access

Configure this port as a customer port.

### core

Configure this port as a provider network port.

### ■ no mode dvlan-tunnel

Use this command to configure the port as normal switch port and to disable the DVLAN tunneling.

### Default

Disabled

### Format

```
no mode dvlan-tunnel
```

### Mode

Interface Config

## 4.4.11 show dvlan-tunnel

**Note:** This command is available for the RS20/RS30/RS40, RSB20, MS20/MS30, RSR20/RSR30, MACH100, MACH104, MACH1000, MACH1040, MACH4002-24G/48G (XG), OCTOPUS, OS20/OS30 devices.

Use this command to display the DVLAN-Tunnel mode and used ether-type for the specified interface(s).

### Format

```
show dvlan-tunnel [interface {slot/port} | all]
```

### Modes

Privileged EXEC

User EXEC

### <slot/port>

Enter an interface in slot/port format.

### all

Enter 'all' for all interfaces.

### Interface

Display the number of the interface (slot/port).

Possible values (example): 1/1, 1/2, 2/1, 2/2, 2/3.

### Mode

Display the DVLAN-Tunnel mode.

Possible values: normal, ....

### EtherType

Display the used ether-type.

Possible values: 802.1Q, vman, custom.



## 4.5 Link Aggregation(802.3ad) Commands

### 4.5.1 link-aggregation staticcapability

This command enables the support of link-aggregations (static LAGs) on the device. By default, the static capability for all link-aggregations is disabled.

**Default**

disabled

**Format**

```
link-aggregation staticcapability
```

**Mode**

Global Config

**■ no link-aggregation staticcapability**

This command disables the support of static link-aggregations (LAGs) on the device.

**Default**

disabled

**Format**

```
no link-aggregation staticcapability
```

**Mode**

Global Config

## 4.5.2 show link-aggregation brief

This command displays the static capability of all link-aggregations (LAGs) on the device as well as a summary of individual link-aggregations.

### Format

```
show link-aggregation brief
```

### Mode

Privileged EXEC and User EXEC

### Static Capability

This field displays whether or not the device has static capability enabled.

For each link-aggregation the following information is displayed:

### Name

This field displays the name of the link-aggregation.

### Link State

This field indicates whether the link is up or down.

### Mbr Ports

This field lists the ports that are members of this link-aggregation, in <slot/port> notation.

### Max. num. of LAGs

Displays the maximum number of concurrently configured link aggregations on this device.

### Slot no. for LAGs

Displays the slot number for all configured link aggregations on this device.

## 4.6 Management Commands

These commands manage the switch and show current management settings.

### 4.6.1 telnet

This command establishes a new outbound telnet connection to a remote host. The host value must be a valid IP address. Valid values for port should be a valid decimal integer in the range of 0 to 65535, where the default value is 23. If [debug] is used, the current telnet options enabled is displayed. The optional line parameter sets the outbound telnet operational mode as 'linemode', where by default, the operational mode is 'character mode'. The echo option enables local echo and only takes effect when the local switch is accessed via the serial connection (V.24).

#### Format

```
telnet <host> <port> [debug] [line] [echo]
```

#### Mode

```
Privileged EXEC and User EXEC
```

## 4.6.2 transport input telnet

This command regulates new telnet sessions. If sessions are enabled, new telnet sessions can be established until there are no more sessions available. If sessions are disabled, no new telnet sessions are established. An established session remains active until the session is ended or an abnormal network error ends the session.

### Default

enabled

### Format

```
transport input telnet
```

### Mode

Line Config

### ■ no transport input telnet

This command disables telnet sessions. If sessions are disabled, no new telnet sessions are established.

### Format

```
no transport input telnet
```

### Mode

Line Config

### 4.6.3 transport output telnet

This command regulates new outbound telnet connections. If enabled, new outbound telnet sessions can be established until it reaches the maximum number of simultaneous outbound telnet sessions allowed.

If disabled, no new outbound telnet session can be established. An established session remains active until the session is ended or an abnormal network error ends it.

#### Default

enabled

#### Format

```
transport output telnet
```

#### Mode

Line Config

#### ■ no transport output telnet

This command disables new outbound telnet connections. If disabled, no new outbound telnet connection can be established.

#### Format

```
no transport output telnet
```

#### Mode

Line Config

## 4.6.4 session-limit

This command specifies the maximum number of simultaneous outbound telnet sessions. A value of 0 indicates that no outbound telnet session can be established.

### Default

4

### Format

```
session-limit <0-5>
```

### Mode

Line Config

### ■ no session-limit

This command sets the maximum number of simultaneous outbound telnet sessions to the default value.

### Format

```
no session-limit
```

### Mode

Line Config

### 4.6.5 session-timeout

This command sets the telnet session timeout value. The timeout value unit of time is minutes.

**Default**

5

**Format**

```
session-timeout <1-160>
```

**Mode**

Line Config

**■ no session-timeout**

This command sets the telnet session timeout value to the default. The timeout value unit of time is minutes.

**Format**

```
no session-timeout
```

**Mode**

Line Config

### 4.6.6 bridge address-learning

To enable you to observe the data at all the ports, the Switch allows you to disable the learning of addresses. When the learning of addresses is disabled, the Switch transfers all the data from all ports to all ports. The default value is enable.

**Format**

```
bridge address-learning {disable|enable}
```

**Mode**

Global Config

### 4.6.7 bridge address-relearn detect operation

This command enables or disables Bridge Address Relearn Detection. The default value is disable.

**Default**

Disabled

**Format**

```
bridge address-relearn detect operation  
{disable|enable}
```

**Mode**

Global Config

### 4.6.8 bridge address-relearn detect threshold

This command defines the value of relearned addresses to signal address relearn threshold exceeded.

The default relearn threshold is 1. Possible values to configure threshold count are 1 to 1024.

**Default**

1

**Format**

```
bridge address-relearn-detect threshold <value>
```

**Mode**

Global Config

**value**

1 to 1024



### 4.6.9 bridge aging-time

This command configures the forwarding database address aging timeout in seconds.

**Default**

30

**Format**

```
bridge aging-time <10-630>
```

**Mode**

Global Config

**Seconds**

The <seconds> parameter must be within the range of 10 to 630 seconds.

**■ no bridge aging-time**

This command sets the forwarding database address aging timeout to 30 seconds.

**Format**

```
no bridge aging-time
```

**Mode**

Global Config

### 4.6.10 bridge fast-link-detection

This command enables or disables the Bridge Fast Link Detection.

#### Default

Enabled

#### Format

```
bridge fast-link-detection {disable|enable}
```

#### Mode

Global Config

### 4.6.11 bridge duplex-mismatch-detect operation

This command enables or disables Bridge Duplex Mismatch Detection.

Reasons for Duplex Mismatch can be:

- A local port is configured to fix full-duplex.
- A port is configured to auto-negotiation and has negotiated HalfDuplex-Mode.

Duplex Mismatch can be excluded, when the local port is configured to auto-negotiation and duplex mode is negotiated to full-duplex.

**Note:** If counters and configuration settings indicate a Duplex Mismatch, the reason can also be a bad cable and/or EMI.

#### Default

Enabled

#### Format

```
bridge duplex-mismatch-detect operation  
{disable|enable}
```

#### Mode

Global Config

## 4.6.12 bridge vlan-learning

With "independent" you set the Shared VLAN Learning mode to Independent. The switch will treat equal MAC source addresses from different VLANs as separate addresses.

With "shared" you set the Shared VLAN Learning mode to Shared. The switch will treat equal MAC source addresses from different VLANs as the same address.

### Format

```
bridge vlan-learning {independent|shared}
```

### Mode

```
Global Config
```

## 4.6.13 digital-input

This command configures the MICE IO-Module digital inputs.

### Format

```
digital-input
  admin-state {enable | disable}
  refresh-interval <refresh-interval>
  log-event {all | <slot/input>} {enable|disable}
  snmp-trap {all | <slot/input>} {enable|disable}
```

### Mode

```
Global Config
```

### admin-state

This command enables or disables the polling task for digital inputs of the MICE IO-Module. When disabled, no event logging or SNMP traps will work. Default: `disable`.

`disable` Disable the IO-Module digital inputs admin state.

`enable` Enable the IO-Module digital inputs admin state.

### refresh-interval

This command configures the digital inputs refresh interval. Each input configured for event logging or SNMP traps is polled with this interval.

`<refresh-interval>` The refresh interval is in the range of 1..10 seconds. Default: 1.

### log-event

This command enables or disables the event logging of input status changes for one or all digital inputs. Default: `disable`.

The input state will be checked according to the interval set with `IO-<refresh-interval>`.

`all` Configure the IO-Module event logging for all digital inputs.

`<slot/input>` Configure the IO-Module event logging for a single digital input.

`disable` Disable event logging for digital input status changes.

`enable` Enable event logging for digital input status changes.

### snmp-trap

This command enables or disables the sending of SNMP traps in case of input status changes for one or all digital inputs. Default: `disable`.

The trap will be sent to all SNMP trap receivers configured with `snmptrap`.

The input state will be checked according to the interval set with `IO-<refresh-interval>`.

`all` Configure the IO-Module SNMP trap for all digital inputs.

`<slot/input>` Configure the IO-Module SNMP trap for a single digital input.

`disable` Disable SNMP traps for digital input status changes.

`enable` Enable SNMP traps for digital input status changes.

## 4.6.14 digital-output

This command configures the IO-Module digital outputs.

### Format

```
digital-output
  admin-state {enable | disable}
  refresh-interval <refresh-interval>
  retry-count <refresh-interval>
  log-event {all | <slot/output>} {enable|disable}
  snmp-trap {all | <slot/output>} {enable|disable}
  mirror all | <slot>/<output> {disable |
                                from <IPAddress> <slot>/<input>}
```

### Mode

Global Config

### admin-state

This command enables or disables the polling task for digital outputs of the MICE IO-Module. When disabled, no event logging or SNMP traps will work. Default: `disable`.

`disable` Disable the IO-Module digital outputs admin state.  
`enable` Enable the IO-Module digital outputs admin state.

### refresh-interval

This command configures the IO-Module digital outputs refresh interval. Each output configured for input mirroring is refreshed (input is polled) with this interval.

`<refresh-interval>` The refresh interval is in the range of 1..10 seconds. Default: 1.

### retry-count

This command configures the number of retry counts for setting digital outputs of the MICE IO-Module. Each output configured for input mirroring is set to the default value (low) when after the number of configured retries no SNMP get request was answered.

`<refresh-interval>` The refresh interval is in the range of 1..10 seconds. Default: 1.

### log-event

This command enables or disables the event logging of output status changes for one or all digital outputs. Default: `disable`.

The output state will be checked according to the interval set with IO-

`<refresh-interval>`.

Configure the IO-Module event logging for one or all digital outputs.

`all` Configure the IO-Module event logging for all digital outputs.

`<slot/output>` Configure the IO-Module event logging for a single digital output.

`disable` Disable event logging for digital output status changes.

`enable` Enable event logging for digital output status changes.

### **snmp-trap**

This command enables or disables the sending of SNMP traps in case of output status changes for one or all digital outputs. Default:

`disable`.

The trap will be sent to all SNMP trap receivers configured with `snmptrap`.

The output state will be checked according to the interval set with `IO-`

`<refresh-interval>`.

`all` Configure the IO-Module SNMP trap for all digital outputs.

`<slot/output>` Configure the IO-Module SNMP trap for a single digital output.

`disable` Disable SNMP traps for digital output status changes.

`enable` Enable SNMP traps for digital output status changes.

## mirror

Configure the IO-Module mirroring for one or all digital outputs. This command determines the input mirrored to the currently selected output.

To disable mirroring, the following commands are equivalent:

```
digital-output mirror 1/2 disable
```

```
digital-output mirror 1/2 from 0.0.0.0 1/1
```

**<all>**: Configure the IO-Module mirroring for all digital outputs.

**<slot/output>**: Configure the IO-Module mirroring for a single digital output. The **<slot>** value determines the IO-module slot number on the device with the selected IP address.

**disable**: Disable the IO-Module mirroring for a single digital output.

**from**: Enable the IO-Module mirroring for a single digital output from **<IP-address>** **<slot/input>**

**<IPaddress>**: The IP address value determines the IP address used for reading the input value. Use IP address 127.0.0.1 or the system IP address to mirror inputs from a local IO module. When IP address is 0.0.0.0 no input is mirrored to the output (the output value is set to 'low'). Default: 0.0.0.0.

**<slot/input>**: The **<input>** value determines the input number on this device. Default: 1/1.

## 4.6.15 show digital-input

This command shows the input value or configuration from all available digital inputs of the MICE I/O Module.

### Format

```
show digital-input
```

### Mode

```
Global Config
```

### Digital Input System Information:

#### Admin State

Show the IO-Module digital inputs Admin State.  
Possible values: Disabled, Enabled.

#### Refresh Interval [s]

Show the IO-Module digital inputs Refresh Interval in seconds.  
Value range: 1-10.

### Digital Input Information:

#### Input

Show numbers of the IO-Module digital input.  
Possible values (example): 1/1, 1/2, 1/3, 1/4,  
3/1, 3/2, 3/3, 3/4

#### Value

Show the value of the IO-Module digital inputs.  
Possible values: Not available, High, Low.

#### Log-Event

Show if Event logging is enabled or disabled for the IO-Module digital inputs.  
Possible values: Disabled, Enabled.

#### SNMP-trap

Show if SNMP traps are enabled or disabled for the IO-Module digital inputs.  
Possible values: Disabled, Enabled.



## 4.6.16 show digital-input config

This command shows the IO-Module digital inputs global configuration.

### Format

```
show digital-input config
```

### Mode

```
Global Config
```

### Digital Input System Information:

#### Admin State

Show the IO-Module digital inputs Admin State.  
Possible values: Disabled, Enabled.

#### Refresh Interval [s]

Show the IO-Module digital inputs Refresh Interval in seconds.  
Value range: 1-10.

## 4.6.17 show digital-input all

This command shows the IO-Module value or configuration for all inputs.

### Format

```
show digital-input all {all | config | value}
```

### Mode

Global Config

### all

Show the IO-Module configuration and value for all inputs

### config

Show the IO-Module configuration for all inputs.

### value

Show the IO-Module value for all inputs.

### Digital Input Information:

#### Input

Show numbers of the IO-Module digital input.

Possible values (example): 1/1, 1/2, 1/3, 1/4,  
3/1, 3/2, 3/3, 3/4

#### Value

Show the value of the IO-Module digital inputs.

Possible values: Not available, High, Low.

#### Log-Event

Show if Event logging is enabled or disabled for the IO-Module digital inputs. Possible values: Disabled, Enabled.

#### SNMP-trap

Show if SNMP traps are enabled or disabled for the IO-Module digital inputs. Possible values: Disabled, Enabled.

## 4.6.18 show digital-input <slot/input>

This command shows the IO-Module value or configuration for a single input.

### Format

```
show digital-input <slot/input>
                               {all | config | value}
```

### Mode

Global Config

### all

Show the IO-Module configuration and value for one input.

### config

Show the IO-Module configuration for one input.

### value

Show the IO-Module value for one input.

### Digital Input <slot/input> Value

Show the value of the IO-Module digital input.

Possible values: Not available, High, Low.

### Digital Input <slot/input> Log-Event

Show if Event logging is enabled or disabled for the IO-Module digital input. Possible values: Disabled, Enabled.

### Digital Input <slot/input> SNMP-trap

Show if SNMP traps are enabled or disabled for the IO-Module digital input. Possible values: Disabled, Enabled.

## 4.6.19 show digital-output

This command shows the output value or configuration from all available digital outputs of the MICE I/O Module.

### Format

```
show digital-output
```

### Mode

```
Global Config
```

### Digital output System Information:

#### Admin State

Show the IO-Module digital outputs Admin State.  
Possible values: Disabled, Enabled.

#### Refresh Interval [s]

Show the IO-Module digital outputs Refresh Interval in seconds.  
Value range: 1-10.

#### Retry Count

Show the value of the IO-Module digital outputs Retry count.  
Value range: 1-10.

### Digital output Information:

#### Output

Show numbers of the IO-Module digital output.  
Possible values (example): 1/1, 1/2, 1/3, 1/4,  
3/1, 3/2, 3/3, 3/4

#### Value

Show the value of the IO-Module digital outputs.  
Possible values: Not available, High, Low.

#### Log-Event

Show if Event logging is enabled or disabled for the IO-Module digital outputs.  
Possible values: Disabled, Enabled.

#### SNMP-trap

Show if SNMP traps are enabled or disabled for the IO-Module digital outputs.  
Possible values: Disabled, Enabled.

**Mirror from IP**

Show the IP address used for reading the input value.  
Possible values: None, a.b.c.d (valid IP address).

**Input**

Show the input number of the device used for reading the input value.  
Possible values (example): 1/1, 1/2, 1/3, 1/4,  
3/1, 3/2, 3/3, 3/4

## 4.6.20 show digital-output config

This command shows the IO-Module digital outputs global configuration.

**Format**

```
show digital-output config
```

**Mode**

```
Global Config
```

**Digital output System Information:****Admin State**

Show the IO-Module digital outputs Admin State.  
Possible values: Disabled, Enabled.

**Refresh Interval [s]**

Show the IO-Module digital outputs Refresh Interval in seconds.  
Value range: 1-10.

**Retry Count**

Show the value of the IO-Module digital outputs Retry count.  
Value range: 1-10.

## 4.6.21 show digital-output all

This command shows the IO-Module value or configuration for all outputs.

### Format

```
show digital-output all {all | config | value}
```

### Mode

Global Config

### all

Show the IO-Module configuration and value for all outputs

### config

Show the IO-Module configuration for all outputs.

### value

Show the IO-Module value for all outputs.

### Digital output Information:

#### output

Show numbers of the IO-Module digital output.

Possible values (example): 1/1, 1/2, 1/3, 1/4,  
3/1, 3/2, 3/3, 3/4

#### Value

Show the value of the IO-Module digital outputs.

Possible values: Not available, High, Low.

#### Log-Event

Show if Event logging is enabled or disabled for the IO-Module digital outputs. Possible values: Disabled, Enabled.

#### SNMP-trap

Show if SNMP traps are enabled or disabled for the IO-Module digital outputs. Possible values: Disabled, Enabled.

#### Mirror from IP

Show the IP address used for reading the input value.

Possible values: None, a.b.c.d (valid IP address).

#### Input

Show the input number of the device used for reading the input value.

Possible values (example): 1/1, 1/2, 1/3, 1/4,  
3/1, 3/2, 3/3, 3/4

## 4.6.22 show digital-output <slot/output>

This command shows the IO-Module value or configuration for a single output.

### Format

```
show digital-output <slot/output>
                               {all | config | value}
```

### Mode

Global Config

### all

Show the IO-Module configuration and value for one output.

### config

Show the IO-Module configuration for one output.

### value

Show the IO-Module value for one output.

### Digital output <slot/output> Value

Show the value of the IO-Module digital output.

Possible values: Not available, High, Low, Invalid.

### Digital output <slot/output> Log-Event

Show if Event logging is enabled or disabled for the IO-Module digital output. Possible values: Disabled, Enabled.

### Digital output <slot/output> SNMP-trap

Show if SNMP traps are enabled or disabled for the IO-Module digital output. Possible values: Disabled, Enabled.

### Digital Output <slot/output> Mirror from IP

Show the IP address used for reading the input value.

Possible values: Not configured, a.b.c.d (valid IP address).

### 4.6.23 ethernet-ip

This command controls the EtherNet/IP function on the switch. Detailed information you can find in the User Manual Industrial Protocols.

#### Default

depends on the order code (standard = disable)

#### Format

```
ethernet-ip admin-state {enable | disable}
```

#### Mode

Global Config

#### Admin-state

`disable`: Disables the EtherNet/IP function on this device.

**Note:** The relevant MIB objects are still accessible.

`enable`: Enables the EtherNet/IP function on this device.



## 4.6.24 iec61850-mms

**Note:** This command is available for the RSR20/RSR30 and MACH1000 devices.

This command is used to configure the IEC61850 MMS server functionality on this device.

### Default

disable

### Format

```
iec61850-mms { admin-state {enable | disable} |  
               write-access {enable | disable} }
```

### Mode

Global Config

### Admin-state

**Disable:** Disables the IEC61850 MMS Server functionality on this device. This is the default.

**Note:** The relevant MIB objects are still accessible.

**Enable:** Enables the IEC61850 MMS Server functionality on this device.

### Write-access

**Disable:** Disables the write-access of the IEC61850 MMS Server on this device. This is the default.

**Enable:** Enables the write-access of the IEC61850 MMS Server on this device.

**Note:** Write-Access via the IEC61850 MMS Server will be non authenticated. This could be a possible security risk.

## 4.6.25 show iec61850-mms

**Note:** This command is available for the RSR20/RSR30 and MACH1000 devices.

This command is used to show the IEC61850 MMS server settings on this device.

### Default

disable

### Format

```
show iec61850-mms
```

### Mode

Global Config

### IEC61850 MMS Server Admin State

Display the IEC61850 MMS Server Admin State.

Possible values: Enable, Disable

### IEC61850 MMS Server Write-Access State

Show the IEC61850 MMS Server Write-Access State.

Possible values: Enable, Disable

## 4.6.26 network javascriptmode

When the user accesses the switch's graphical user interface (web-based interface), the switch's web server will deliver a HTML page that contains JavaScript.

### Default

enabled

### Format

```
network javascriptmode
```

### Mode

Privileged EXEC

### ■ no network javascriptmode

When the user accesses the switch's graphical user interface (web-based interface), the switch's web server will deliver a HTML page that contains no JavaScript.

### Format

```
no network javascriptmode
```

### Mode

Privileged EXEC

### 4.6.27 network mgmt-access add

This command is used to configure the restricted management access feature (RMA).

It creates a new empty entry at the <index> (if you enter the command with parameter <index>) or at the next free index (if you enter the command without parameter <index>).

#### Format

```
network mgmt-access add [index]
```

#### Mode

```
Global Config
```

#### [index]

Index of the entry in the range 1..16.

### 4.6.28 network mgmt-access delete

This command is used to configure the restricted management access feature (RMA).

It deletes an existing entry with <index>.

#### Format

```
network mgmt-access delete <index>
```

#### Mode

```
Global Config
```

#### <index>

Index of the entry in the range 1..16.

## 4.6.29 network mgmt-access modify

This command is used to configure the restricted management access feature (RMA).

The command modifies an existing rule with <index> to change IP address, net mask and allowed services.

### Format

```
network mgmt-access modify <index>
                                { ip <address> |
                                  mask <netmask> |
                                  http {enable | disable} |
                                  snmp {enable | disable} |
                                  telnet {enable | disable} |
                                  ssh {enable |disable } }
```

### Mode

Global Config

### <index>

Index of the entry in the range 1..16.

### <ip>

Configure IP address which should have access to management

### <mask>

Configure network mask to allow a subnet for management access.

### <http>

Configure if HTTP is allowed to have management access.

### <snmp>

Configure if SNMP is allowed to have management access.

### <telnet>

Configure if TELNET is allowed to have management access.

### <ssh>

Configure if SSH is allowed to have management access.

### enable

Allow the service to have management access.

### disable

Do not allow the service to have management access.

### 4.6.30 network mgmt-access operation

This command is used to configure the restricted management access feature (RMA).

It enables or disables the service to have management access. The default value is disable.

#### Format

```
network mgmt-access operation {disable|enable}
```

#### Mode

Global Config

#### enable

Enable the restricted management access function globally.

#### disable

Disable the restricted management access function globally.

### 4.6.31 network mgmt-access status

This command is used to configure the restricted management access feature (RMA).

It activates/deactivates an existing rule with <index>.

#### Format

```
network mgmt-access status <index>
                                {enable | disable}
```

#### Mode

Global Config

#### <index>

Index of the entry in the range 1..16.

#### enable

Allow the service to have management access.

#### disable

Do not allow the service to have management access.

### 4.6.32 network parms

This command sets the IP Address, subnet mask and gateway of the router. The IP Address and the gateway must be on the same subnet.

#### Format

```
network parms <ipaddr> <netmask> [gateway]
```

#### Mode

```
Privileged EXEC
```

### 4.6.33 network protocol

This command specifies the network configuration protocol to be used. If you modify this value, change is effective immediately after you saved your changes.

The parameter `bootp` indicates that the switch periodically sends requests to a Bootstrap Protocol (BootP) server or a DHCP server until a response is received.

`none` indicates that the switch should be manually configured with IP information.

Independently of the BootP and DHCP settings, HiDiscovery can be configured as an additional protocol.

#### Default

```
DHCP
```

#### Format

```
network protocol {none | bootp | dhcp | hidiscovery  
{off | read-only | read-write}}
```

#### Mode

```
Privileged EXEC
```

## 4.6.34 network priority

This command configures the VLAN priority or the IP DSCP value for outgoing management packets. The <ipdscp> is specified as either an integer from 0-63, or symbolically through one of the following keywords:

af11,af12,af13,af21,af22,af23,af31,af32,af33,af41,af42,af43,be,cs0, cs1, cs2,cs3,cs4,cs5,cs6,cs7,ef.

### Default

0 for both values

### Format

```
network priority {dot1p-vlan <0-7> |  
ip-dscp <ipdscp> }
```

### Mode

Privileged EXEC

### ■ no network priority

This command sets the VLAN priority or the IP DSCP value for outgoing management packets to default which means VLAN priority 0 or IP DSCP value 0 (Best effort).

### Format

```
no network priority {dot1p-vlan | ip-dscp }
```

### Mode

Privileged EXEC



### 4.6.35 profinetio

This command controls the PROFINET IO function on the switch. Detailed information you can find in the User Manual Industrial Protocols.

#### Default

depends on the order code (standard = disable)

#### Format

```
profinetio admin-state {enable | disable}
```

#### Mode

Global Config

#### Admin-state

`disable` Disables the PROFINET IO function on this device.

**Note:** The relevant MIB objects are still accessible.

`enable` Enables the PROFINET IO function on this device.

## 4.6.36 serial timeout

This command specifies the maximum connect time (in minutes) without console activity. A value of 0 indicates that a console can be connected indefinitely. The time range is 0 to 160.

### Default

5

### Format

```
serial timeout <0-160>
```

### Mode

Line Config

### ■ no serial timeout

This command sets the maximum connect time without console activity (in minutes) back to the default value.

### Format

```
no serial timeout
```

### Mode

Line Config

## 4.6.37 set prompt

This command changes the name of the prompt. The length of name may be up to 64 alphanumeric characters.

### Format

```
set prompt <prompt string>
```

### Mode

Privileged EXEC

### 4.6.38 show ethernet-ip

This command displays the admin state of the EtherNet/IP function.

#### Format

```
show ethernet-ip
```

#### Mode

Privileged EXEC and User EXEC

### 4.6.39 show network

This command displays configuration settings associated with the switch's network interface. The network interface is the logical interface used for in-band connectivity with the switch via any of the switch's front panel ports. The configuration parameters associated with the switch's network interface do not affect the configuration of the front panel ports through which traffic is switched or routed.

#### Format

```
show network
```

#### Mode

Privileged EXEC and User EXEC

#### System IP Address

The IP address of the interface. The factory default value is 0.0.0.0

#### Subnet Mask

The IP subnet mask for this interface. The factory default value is 0.0.0.0

#### Default Gateway

The default gateway for this IP interface. The factory default value is 0.0.0.0

#### Burned In MAC Address

The burned in MAC address used for in-band connectivity.

**Network Configuration Protocol (BootP/DHCP)**

Indicates which network protocol is being used. The options are  
`bootp` | `dhcp` | `none`.

**DHCP Client ID (same as SNMP System Name)**

Displays the DHCP Client ID.

**Network Configuration Protocol HiDiscovery**

Indicates in which way the HiDiscovery protocol is being used. The options are `off` | `read-only` | `read-write`.

**Management VLAN ID**

Specifies the management VLAN ID.

**Management VLAN Priority**

Specifies the management VLAN Priority.

**Management VLAN IP-DSCP Value**

Specifies the management VLAN IP-DSCP value.

**Java Script Mode**

Specifies if the Switch will use Java Script to start the Management Applet. The factory default is enabled.

## 4.6.40 show network mgmt-access

This command displays the operating status and entries for restricted management access (RMA).

### Format

```
show network mgmt-access
```

### Mode

Privileged EXEC and User EXEC

### Operation

Indicates whether the operation for RMA is enabled or not.  
The options are `Enabled` | `Disabled`.

### ID

Index of the entry for restricted management access (1 to max. 16).

### IP Address

The IP address which should have access to management.  
The factory default value is 0.0.0.0.

### Netmask

The network mask to allow a subnet for management access.  
The factory default value is 0.0.0.0.

### HTTP

Indicates whether HTTP is allowed to have management access or not. The options are `Yes` | `No`.

### SNMP

Indicates whether SNMP is allowed to have management access or not. The options are `Yes` | `No`.

### TELNET

Indicates whether TELNET is allowed to have management access or not. The options are `Yes` | `No`.

### SSH

Indicates whether SSH is allowed to have management access or not. The options are `Yes` | `No`.

### Active

Indicates whether the feature is active or not. The options are `[x]` | `[ ]`.

### 4.6.41 show profinetio

This command displays the admin state of the PROFINET IO function.

**Format**

```
show profinetio
```

**Mode**

Privileged EXEC and User EXEC

### 4.6.42 show serial

This command displays serial communication settings for the switch.

**Format**

```
show serial
```

**Mode**

Privileged EXEC and User EXEC

**Serial Port Login Timeout (minutes)**

Specifies the time, in minutes, of inactivity on a Serial port connection, after which the Switch will close the connection. Any numeric value between 0 and 160 is allowed, the factory default is 5. A value of 0 disables the timeout.

### **4.6.43 show snmp-access**

This command displays SNMP access information related to global and SNMP version settings. SNMPv3 is always enabled.

**Format**

```
show snmp-access
```

**Mode**

```
Privileged EXEC
```

## 4.6.44 show snmpcommunity

This command displays SNMP community information. Six communities are supported. You can add, change, or delete communities. The switch does not have to be reset for changes to take effect.

The SNMP agent of the switch complies with SNMP Version 1 (for more about the SNMP specification, see the SNMP RFCs). The SNMP agent sends traps through TCP/IP to an external SNMP manager based on the SNMP configuration (the trap receiver and other SNMP community parameters).

### Format

```
show snmpcommunity
```

### Mode

Privileged EXEC

### SNMP Community Name

The community string to which this entry grants access. A valid entry is a case-sensitive alphanumeric string of up to 32 characters. Each row of this table must contain a unique community name.

### Client IP Address -

An IP address (or portion thereof) from which this device will accept SNMP packets with the associated community. The requesting entity's IP address is ANDed with the Subnet Mask before being compared to the IP Address. Note that if the Subnet Mask is set to 0.0.0.0, an IP Address of 0.0.0.0 matches all IP addresses. The default value is 0.0.0.0

### Client IP Mask -

A mask to be ANDed with the requesting entity's IP address before comparison with IP Address. If the result matches with IP Address then the address is an authenticated IP address. For example, if the IP Address = 9.47.128.0 and the corresponding Subnet Mask = 255.255.255.0 a range of incoming IP addresses would match, i.e. the incoming IP Address could equal 9.47.128.0 - 9.47.128.255. The default value is 0.0.0.0

### Access Mode

The access level for this community string.

### Status

The status of this community access entry.



## 4.6.45 show snmptrap

This command displays SNMP trap receivers. Trap messages are sent across a network to an SNMP Network Manager. These messages alert the manager to events occurring within the switch or on the network. Six trap receivers are simultaneously supported.

### Format

```
show snmptrap
```

### Mode

Privileged EXEC

### SNMP Trap Name

The community string of the SNMP trap packet sent to the trap manager. This may be up to 32 alphanumeric characters. This string is case sensitive.

### IP Address

The IP address to receive SNMP traps from this device. Enter four numbers between 0 and 255 separated by periods.

### Status

A pull down menu that indicates the receiver's status (enabled or disabled) and allows the administrator/user to perform actions on this user entry:

**Enable** - send traps to the receiver

**Disable** - do not send traps to the receiver.

**Delete** - remove the table entry.

## 4.6.46 show telnet

This command displays outbound telnet settings.

### Format

```
show telnet
```

### Mode

Privileged EXEC and User EXEC

### Outbound Telnet Connection Login Timeout (minutes)

This object indicates the number of minutes a remote connection session is allowed to remain inactive before being logged off. May be specified as a number from 1 to 160. The factory default is 5.

### Maximum Number of Outbound Telnet Sessions

This object indicates the number of simultaneous outbound connection sessions allowed. The factory default is 5.

### Allow New Outbound Telnet Sessions

Indicates that new outbound telnet sessions will not be allowed when set to no. The factory default value is yes.

## 4.6.47 show telnetcon

This command displays inbound telnet settings.

### Format

```
show telnetcon
```

### Mode

Privileged EXEC and User EXEC

### Telnet Connection Login Timeout (minutes)

This object indicates the number of minutes a remote connection session is allowed to remain inactive before being logged off. May be specified as a number from 1 to 160. The factory default is 4.

### Maximum Number of Remote Telnet Sessions

This object indicates the number of simultaneous remote connection sessions allowed. The factory default is 2 (4 for version L2P).

### Allow New Telnet Sessions

Indicates that new telnet sessions will not be allowed when set to no. The factory default value is yes.

## 4.6.48 show trapflags

This command displays trap conditions. Configure which traps the switch should generate by enabling or disabling the trap condition. If a trap condition is enabled and the condition is detected, the switch's SNMP agent sends the trap to all enabled trap receivers. The switch does not have to be reset to implement the changes. Cold and warm start traps are always generated and cannot be disabled.

### Format

```
show trapflags
```

### Mode

Privileged EXEC and User EXEC

### Authentication Flag

May be enabled or disabled. The factory default is enabled. Indicates whether authentication failure traps will be sent.

### Chassis

Indicates whether traps that are related to the chassis functionality of the switch will be sent. These functions include the signal contacts, the ACA, temperature limits exceeded, changes in the module map, addition or removal of SFP modules, status of power supply has changed and the LLDP and Sntp features. May be enabled or disabled.

Default: enabled.

### Layer 2 Redundancy

Indicates whether traps that are related to the layer 2 redundancy features of the switch will be sent. The HiPER-Ring and the Redundant Coupling will tell you with these traps when the main line has become inoperative or returned. May be enabled or disabled.

Default: enabled.

### Link Up/Down Flag

May be enabled or disabled. The factory default is enabled. Indicates whether link status traps will be sent.

### Multiple Users Flag

May be enabled or disabled. The factory default is enabled. Indicates whether a trap will be sent when the same user ID is logged into the switch more than once at the same time (either via telnet or serial port).

**Port Security (MAC, IP and 802.1X)**

Enable/disable sending port security event traps (for MAC/IP port security as well as for 802.1X).

**Spanning Tree Flag**

May be enabled or disabled. The factory default is enabled. Indicates whether spanning tree traps will be sent.

## 4.6.49 snmp-access global

This command configures the global SNMP access setting (for all SNMP versions).

**Format**

```
snmp-access global {disable|enable|read-only}
```

**Mode**

```
Global Config
```

**disable**

Disable SNMP access to this switch, regardless of the SNMP version used.

**enable**

Enable SNMP read and write access to this switch, regardless of the SNMP version used.

**read-only**

Enable SNMP read-only access to this switch (disable write access), regardless of the SNMP version used.

## 4.6.50 snmp-access version

This command configures the SNMP version specific access mode for SNMPv1 and SNMPv2.

### Format

```
snmp-access version {all|v1|v2} {disable|enable}
```

### Mode

Global Config

#### all

Enable or disable SNMP access by all protocol versions (v1 and v2).

#### v1

Enable or disable SNMP access by v1.

#### v2

Enable or disable SNMP access by v2.

## 4.6.51 snmp-access version v3-encryption

Use this command to activate/deactivate SNMPv3 data encryption.

### Format

```
snmp-access version v3-encryption  
                {readonly | readwrite} {enable | disable}
```

### Mode

Global Config

### disable

Disable SNMP access to this switch by SNMPv3 protocol version.

### enable

Enable SNMP read and write access to this switch by SNMPv3 protocol version.

### readonly

Enable SNMP read-only access to this switch (disable write access) by SNMPv3 protocol version.

### readwrite

Enable SNMP read-write access to this switch (enable write access) by SNMPv3 protocol version.

## 4.6.52 snmp-server

This command sets the name and the physical location of the switch, and the organization responsible for the network. The range for name, location and contact is from 0 to 64 alphanumeric characters.

### Default

None

### Format

```
snmp-server
{community <name> |
 ipaddr <ipaddr> <name> |
 ipmask <ipmask> <name> |
 mode <name> |
 ro <name> |
 rw <name> |
 contact <con> |
 enable traps { chassis | l2redundancy |
  linkmode | multiusers | port-sec | stpmode }
 location <loc> |
 sysname <name> }
```

### Mode

Global Config



### 4.6.53 snmp-server community

This command adds a new SNMP community name. A community name is a name associated with the switch and with a set of SNMP managers that manage it with a specified privileged level. The length of name can be up to 32 case-sensitive characters.

**Note:** Community names in the SNMP community table must be unique. When making multiple entries using the same community name, the first entry is kept and processed and all duplicate entries are ignored.

#### Default

Two default community names: Public and Private. You can replace these default community names with unique identifiers for each community. The default values for the remaining four community names are blank.

#### Format

```
snmp-server community <name>
```

#### Mode

```
Global Config
```

#### ■ no snmp-server community

This command removes this community name from the table. The name is the community name to be deleted.

#### Format

```
no snmp-server community <name>
```

#### Mode

```
Global Config
```

## 4.6.54 snmp-server contact

This command adds a new SNMP server contact.

### Format

```
snmp-server contact <con>
```

### Mode

Global Config

### con

Enter system contact up to 63 characters in length.

If the name contains spaces, enclose it in quotation marks (").

### ■ no snmp-server contact

This command removes this SNMP server contact from the table.

<con> is the SNMP server contact to be deleted.

### Format

```
no snmp-server contact <con>
```

### Mode

Global Config

## 4.6.55 snmp-server community ipaddr

This command sets a client IP address for an SNMP community. The address is the associated community SNMP packet sending address and is used along with the client IP mask value to denote a range of IP addresses from which SNMP clients may use that community to access the device. A value of 0.0.0.0 allows access from any IP address. Otherwise, this value is ANDed with the mask to determine the range of allowed client IP addresses. The name is the applicable community name.

### Default

0.0.0.0

### Format

```
snmp-server community ipaddr <ipaddr> <name>
```

### Mode

Global Config

### ■ no snmp-server community ipaddr

This command sets a client IP address for an SNMP community to 0.0.0.0. The name is the applicable community name.

### Format

```
no snmp-server community ipaddr <name>
```

### Mode

Global Config

## 4.6.56 snmp-server community ipmask

This command sets a client IP mask for an SNMP community. The address is the associated community SNMP packet sending address and is used along with the client IP address value to denote a range of IP addresses from which SNMP clients may use that community to access the device. A value of 255.255.255.255 will allow access from only one station, and will use that machine's IP address for the client IP Address. A value of 0.0.0.0 will allow access from any IP address. The name is the applicable community name.

### Default

0.0.0.0

### Format

```
snmp-server community ipmask <ipmask> <name>
```

### Mode

Global Config

### ■ no snmp-server community ipmask

This command sets a client IP mask for an SNMP community to 0.0.0.0. The name is the applicable community name. The community name may be up to 32 alphanumeric characters.

### Format

```
no snmp-server community ipmask <name>
```

### Mode

Global Config

### 4.6.57 snmp-server community mode

This command activates an SNMP community. If a community is enabled, an SNMP manager associated with this community manages the switch according to its access right. If the community is disabled, no SNMP requests using this community are accepted. In this case the SNMP manager associated with this community cannot manage the switch until the Status is changed back to Enable.

#### Default

The default private and public communities are enabled by default. The four undefined communities are disabled by default.

#### Format

```
snmp-server community mode <name>
```

#### Mode

```
Global Config
```

#### ■ no snmp-server community mode

This command deactivates an SNMP community. If the community is disabled, no SNMP requests using this community are accepted. In this case the SNMP manager associated with this community cannot manage the switch until the Status is changed back to Enable.

#### Format

```
no snmp-server community mode <name>
```

#### Mode

```
Global Config
```

### 4.6.58 snmp-server community ro

This command restricts access to switch information. The access mode is read-only (also called public).

**Format**

```
snmp-server community ro <name>
```

**Mode**

```
Global Config
```

### 4.6.59 snmp-server community rw

This command restricts access to switch information. The access mode is read/write (also called private).

**Format**

```
snmp-server community rw <name>
```

**Mode**

```
Global Config
```

### 4.6.60 snmp-server location

This command configures the system location.

**Format**

```
snmp-server location <system location>
```

**Mode**

```
Global Config
```

### 4.6.61 snmp-server sysname

This command configures the system name.

#### Format

```
snmp-server sysname <system name>
```

#### Mode

```
Global Config
```

### 4.6.62 snmp-server enable traps

This command enables the Authentication Trap Flag.

#### Default

```
enabled
```

#### Format

```
snmp-server enable traps
```

#### Mode

```
Global Config
```

#### ■ no snmp-server enable traps

This command disables the Authentication Trap Flag.

#### Format

```
no snmp-server enable traps
```

#### Mode

```
Global Config
```

### 4.6.63 snmp-server enable traps chassis

Configures whether traps that are related to the chassis functionality of the switch will be sent. These functions include the signal contacts, the ACA, temperature limits exceeded, changes in the module map, addition or removal of SFP modules, status of power supply has changed and the LLDP and SNMP features. May be enabled or disabled.

Default: enabled.

#### Default

enabled

#### Format

```
snmp-server enable traps chassis
```

#### Mode

Global Config

### ■ no snmp-server enable traps chassis

This command disables chassis traps for the entire switch.

#### Format

```
no snmp-server enable traps chassis
```

#### Mode

Global Config



## 4.6.64 snmp-server enable traps l2redundancy

Indicates whether traps that are related to the layer 2 redundancy features of the switch will be sent. The HiPER-Ring and the Redundant Coupling will tell you with these traps when the main line has become inoperative or returned. May be enabled or disabled.

Default: enabled.

### Default

enabled

### Format

```
snmp-server enable traps l2redundancy
```

### Mode

Global Config

### ■ no snmp-server enable traps l2redundancy

This command disables layer 2 redundancy traps for the entire switch.

### Format

```
no snmp-server enable traps l2redundancy
```

### Mode

Global Config

### 4.6.65 snmp-server enable traps linkmode

This command enables Link Up/Down traps for the entire switch. When enabled, link traps are sent only if the Link Trap flag setting associated with the port is enabled (see 'snmp trap link-status' command).

**Default**

enabled

**Format**

```
snmp-server enable traps linkmode
```

**Mode**

Global Config

**■ no snmp-server enable traps linkmode**

This command disables Link Up/Down traps for the entire switch.

**Format**

```
no snmp-server enable traps linkmode
```

**Mode**

Global Config

### 4.6.66 snmp-server enable traps multiusers

This command enables Multiple User traps. When the traps are enabled, a Multiple User Trap is sent when a user logs in to the terminal interface (EIA 232 (serial port) or telnet) and there is an existing terminal interface session.

**Default**

enabled

**Format**

```
snmp-server enable traps multiusers
```

**Mode**

Global Config

**■ no snmp-server enable traps multiusers**

This command disables Multiple User traps.

**Format**

```
no snmp-server enable traps multiusers
```

**Mode**

Global Config

## 4.6.67 snmp-server enable traps port-sec

This command enables port security traps. When the traps are enabled, a Port Security Trap is sent if a port security event occurs (applies to MAC/IP Port Security as well as to 802.1X Port Security).

### Default

enabled

### Format

```
snmp-server enable traps port-sec
```

### Mode

Global Config

### ■ no snmp-server enable traps port-sec

This command disables Port Security traps.

### Format

```
no snmp-server enable traps port-sec
```

### Mode

Global Config

### 4.6.68 snmp-server enable traps stpmode

This command enables the sending of new root traps and topology change notification traps.

**Default**

enabled

**Format**

```
snmp-server enable traps stpmode
```

**Mode**

Global Config

**■ no snmp-server enable traps stpmode**

This command disables the sending of new root traps and topology change notification traps.

**Format**

```
no snmp-server enable traps stpmode
```

**Mode**

Global Config

## 4.6.69 snmptrap

This command adds an SNMP trap name. The maximum length of name is 32 case-sensitive alphanumeric characters.

### Default

The default name for the six undefined community names is Delete.

### Format

```
snmptrap <name> <ipaddr> [snmpversion snmpv1]
```

### Mode

Global Config

### ■ no snmptrap

This command deletes trap receivers for a community.

### Format

```
no snmptrap <name> <ipaddr>
```

### Mode

Global Config

## 4.6.70 snmptrap ipaddr

This command assigns an IP address to a specified community name. The maximum length of name is 32 case-sensitive alphanumeric characters.

**Note:** IP addresses in the SNMP trap receiver table must be unique. If you make multiple entries using the same IP address, the first entry is retained and processed. All duplicate entries are ignored.

### Format

```
snmptrap ipaddr <name> <ipaddr> <ipaddrnew>
```

### Mode

```
Global Config
```

### ipaddr

Enter the old IP Address.

### ipaddrnew

Enter the new IP Address.

## 4.6.71 snmptrap mode

This command activates or deactivates an SNMP trap. Enabled trap receivers are active (able to receive traps). Disabled trap receivers are inactive (not able to receive traps).

### Format

```
snmptrap mode <name> <ipaddr>
```

### Mode

```
Global Config
```

### ■ no snmptrap mode

This command deactivates an SNMP trap. Disabled trap receivers are inactive (not able to receive traps).

### Format

```
no snmptrap mode <name> <ipaddr>
```

### Mode

```
Global Config
```



## 4.6.72 snmptrap snmpversion

This command configures SNMP trap version for a specified community.

### Format

```
snmptrap snmpversion <name> <ipAddr>
      {snmpv1 | snmpv2}
```

### Mode

Global Config

### name

Enter the community name.

### ipAddr

Enter the IP Address.

### snmpv1

Use SNMP v1 to send traps.

### snmpv2

Use SNMP v2 to send traps.

### 4.6.73 telnetcon maxsessions

Configure the number of remote telnet connections allowed.

**Default**

5

**Format**

```
telnetcon maxsessions <0-5>
```

**Mode**

Privileged EXEC

**■ no telnetcon maxsessions**

This command sets the maximum number of telnet connection sessions that can be established to the default value.

**Format**

```
no telnetcon maxsessions
```

**Mode**

Privileged EXEC

## 4.6.74 telnetcon timeout

This command sets the telnet connection session timeout value, in minutes. A session is active as long as the session has not been idle for the value set. The time is a decimal value from 1 to 160.

### Default

5

### Format

```
telnetcon timeout <1-160>
```

### Mode

Privileged EXEC

### ■ no telnetcon timeout

This command sets the telnet connection session timeout value to the default.

Changing the timeout value for active sessions does not become effective until the session is reaccessed. Also, any keystroke activates the new timeout duration.

### Format

```
no telnetcon timeout
```

### Mode

Privileged EXEC

## 4.7 Syslog Commands

This section provides a detailed explanation of the Syslog commands. The commands are divided into two functional groups:

- ▶ Show commands display spanning tree settings, statistics, and other information.
- ▶ Configuration Commands configure features and options of the device. For every configuration command there is a show command that displays the configuration setting.

### 4.7.1 logging buffered

This command enables logging to an in-memory log where up to 128 logs are kept.

#### Default

enabled

#### Format

logging buffered

#### Mode

Global Config

#### ■ no logging buffered

This command disables logging to in-memory log.

#### Format

no logging buffered

## 4.7.2 logging buffered wrap

This command enables wrapping of in-memory logging when full capacity reached. Otherwise when full capacity is reached, logging stops.

### Default

```
wrap
```

### Format

```
logging buffered wrap
```

### Mode

```
Privileged EXEC
```

### ■ no logging buffered wrap

This command disables wrapping of in-memory logging and configures logging to stop when capacity is full.

### Format

```
no logging buffered wrap
```

### 4.7.3 logging cli-command

This command enables the CLI command Logging feature. The Command Logging component enables the switch software to log all Command Line Interface (CLI) commands issued on the system.

**Default**

disabled

**Format**

logging cli-command

**Mode**

Global Config

**■ no logging cli-command**

This command disables the CLI command Logging feature.

**Format**

no logging cli-command

## 4.7.4 logging console

This command enables logging to the console. The <severitylevel> value is specified as either an integer from 0 to 7 or symbolically through one of the following keywords: emergency (0), alert (1), critical (2), error (3), warning (4), notice (5), informational (6), debug (7).

### Default

```
disabled; alert
```

### Format

```
logging console [severitylevel] | <[0-7]>
```

### Mode

```
Global Config
```

### severitylevel | [0-7]

Enter Logging Severity Level (emergency|0, alert|1, critical|2, error|3, warning|4, notice|5, info|6, debug|7).

**Note:** Selecting a lower severity level (larger number) will include all messages from higher severity levels (smaller numbers).

Possible severity levels: see Table 15

### ■ no logging console

This command disables logging to the console.

### Format

```
no logging console
```

## 4.7.5 logging host

This command enables logging to a host where up to eight hosts can be configured.

### Default

```
Port - 514; Level - Critical;
```

### Format

```
logging host <hostaddress>
    [<port> [<severitylevel>]]
```

### Mode

```
Global Config
```

Severity number	Severity name	Meaning
0	emergency	Minimum severity to be logged is 0. This is the highest level and will result in all other messages of lower levels not being logged.
1	alert	Minimum severity to be logged is 1.
2	critical	Minimum severity to be logged is 2.
3	error	Minimum severity to be logged is 3.
4	warning	Minimum severity to be logged is 4.
5	notice	Minimum severity to be logged is 5.
6	info	Minimum severity to be logged is 6.
7	debug	Minimum severity to be logged is 7. This is the lowest level and will result in messages of all levels being logged.

*Tab. 15: Possible severity levels*



### 4.7.6 logging host reconfigure

The Logging Host Index for which to change the IP Address.

**Format**

```
logging host reconfigure <hostindex> <hostaddress>
```

**Mode**

```
Global Config
```

### 4.7.7 logging host remove

The Logging Host Index to be removed.

**Format**

```
logging host remove <hostindex>
```

**Mode**

```
Global Config
```

### 4.7.8 logging snmp-requests get operation

This command enables or disables the logging of SNMP GET requests.

**Default**

```
Disabled
```

**Format**

```
logging snmp-requests get operation  
{ enable | disable }
```

**Mode**

```
Global Config
```

### 4.7.9 logging snmp-requests set operation

This command enables or disables the logging of SNMP SET requests.

#### Default

Disabled

#### Format

```
logging snmp-requests set operation
{ enable | disable }
```

#### Mode

Global Config

### 4.7.10 logging snmp-requests get severity

With this command you can define the severity level of logging SNMP GET requests.

#### Default

Disabled

#### Format

```
logging snmp-requests get severity <level|[0-7]>
```

#### Mode

Global Config

#### level | [0-7]

Enter Logging Severity Level (emergency|0, alert|1, critical|2, error|3, warning|4, notice|5, info|6, debug|7).

**Note:** Selecting a lower severity level (larger number) will include all messages from higher severity levels (smaller numbers).

### 4.7.11 logging snmp-requests set severity

With this command you can define the severity level of logging SNMP SET requests.

#### Default

Disabled

#### Format

```
logging snmp-requests set severity <level|[0-7]>
```

#### Mode

Global Config

#### level | [0-7]

Enter Logging Severity Level (emergency|0, alert|1, critical|2, error|3, warning|4, notice|5, info|6, debug|7).

**Note:** Selecting a lower severity level (larger number) will include all messages from higher severity levels (smaller numbers).

### 4.7.12 logging syslog

This command enables syslog logging.

#### Default

disabled

#### Format

```
logging syslog
```

#### Mode

Global Config

#### ■ no logging syslog

This command disables syslog logging.

#### Format

```
no logging syslog
```

### 4.7.13 logging syslog port

Enter the port number of the syslog server.

**Default**

514

**Format**

```
logging syslog port <portid>
```

**Mode**

Global Config

## 4.8 Scripting Commands

Configuration Scripting allows the user to generate text-formatted script files representing the current configuration. These configuration script files can be uploaded to a PC and edited, downloaded to the system and applied to the system. Configuration scripts can be applied to one or more switches with no/minor modifications.

Use the `show running-config` command to capture the running configuration into a script. Use the `copy` command to transfer the configuration script to and from the switch.

Scripts are intended to be used on systems with default configuration but users are not prevented from applying scripts on systems with non-default configurations.

### Note:

- ▶ The file extension must be “.cli”.
- ▶ A maximum of ten scripts are allowed on the switch.
- ▶ The combined size of all script files on the switch shall not exceed 1024 KB.

### 4.8.1 script apply

This command applies the commands in the script to the switch. We recommend that the system have default configurations but users are not prevented from applying scripts on systems with non-default configurations. The `<scriptname>` parameter is the name of the script to apply.

#### Format

```
script apply <scriptname>
```

#### Mode

```
Privileged EXEC
```

## 4.8.2 script delete

This command deletes a specified script where the <scriptname> parameter is the name of the script to be deleted. The 'all' option deletes all the scripts present on the switch.

### Format

```
script delete {<scriptname> | all}
```

### Mode

Privileged EXEC

## 4.8.3 script list

This command lists all scripts present on the switch as well as the remaining available space.

### Format

```
script list [aca]
```

### Mode

Privileged EXEC

### Configuration Script

Name of the script.

Without the optional ACA parameter: Listing of the scripts in the switch's flash memory.

With the optional ACA parameter: Listing of the scripts on the external ACA 21-USB.

### Size

Size of the script.

## 4.8.4 script show

This command displays the contents of a script file. The parameter <script-name> is the name of the script file.

### Format

```
script show <scriptname>
```

### Mode

```
Privileged EXEC
```

The format of display is

```
Line <no>: <Line contents>
```

## 4.8.5 script validate

This command validates a script file by parsing each line in the script file where <scriptname> is the name of the script to validate. The validate option is intended to be used as a tool for script development.

Validation identifies potential problems. It may or may not identify all problems with a given script on any given device.

### Format

```
script validate <scriptname>
```

### Mode

```
Privileged EXEC
```





## 4.9 Device Configuration Commands

### 4.9.1 addport

This command adds one port to the Link Aggregation (LAG). The given interface is a logical slot and port number of a configured Link Aggregation.

**Note:** Before adding a port to a Link Aggregation, set the physical mode of the port. See 'speed' command.

#### Format

```
addport <logical slot/port>
```

#### Mode

```
Interface Config
```

## 4.9.2 adminmode

This command enables the whole Link Aggregation as one single port.

**Note:** Before adding a port to a Link Aggregation, set the physical mode of the port. See 'speed' command.

### Format

```
adminmode
```

### Mode

```
Interface Config
```

### ■ no adminmode

This command disables the whole Link Aggregation as one single port.

### Format

```
no adminmode
```

### Mode

```
Interface Config
```

### 4.9.3 auto-disable reason

This command enables the port disabling on this device by reason.

#### Default

Disabled

#### Format

```
auto-disable reason  
    {link-flap | crc-error | overload-detection}
```

#### Mode

Global Config

#### link-flap

Enable the port disabling on this device by link flap.

#### crc-error

Enable the port disabling on this device by CRC error.

#### overload-detection

Enable the port disabling on this device by overload detection.

### ■ no auto-disable reason

This command disables the port disabling on this device by reason.

#### Default

Disabled

#### Format

```
no auto-disable reason  
    {link-flap | crc-error | overload-detection}
```

#### Mode

Global Config

#### link-flap

Disable the port disabling on this device by link flap.

#### crc-error

Disable the port disabling on this device by CRC error.

#### overload-detection

Disable the port disabling on this device by overload detection.

## 4.9.4 auto-disable timer

This command defines the time after which a deactivated port is activated again.

### Default

0

### Format

```
auto-disable timer {0 | 30..2147483}
```

### Mode

Interface Config

### {0 | 30..2147483}

Timer value in seconds after a deactivated port is activated again.

Possible values:

0 The value 0 disables the timer.

30..2147483.

## 4.9.5 auto-negotiate

This command enables automatic negotiation on a port. The default value is enable.

### Format

```
auto-negotiate
```

### Mode

```
Interface Config
```

### ■ no auto-negotiate

This command disables automatic negotiation on a port.

### Format

```
no auto-negotiate
```

### Mode

```
Interface Config
```

## 4.9.6 auto-negotiate all

This command enables automatic negotiation on all ports.  
The default value is `enable`.

### Format

```
auto-negotiate all
```

### Mode

```
Global Config
```

## ■ no auto-negotiate all

This command disables automatic negotiation on all ports.

### Format

```
no auto-negotiate all
```

### Mode

```
Global Config
```

## 4.9.7 cable-crossing

**Note:** This function is available for the RS20/RS30/RS40, MS20/MS30, RSR20/RSR30, MACH1000, PowerMICE and OCTOPUS devices.

Use this command to enable or disable the cable crossing function.

**Note:** The `cable-crossing` settings become effective for a certain port, if `auto-negotiate` is disabled for this port.

The `cable-crossing` settings are irrelevant for a certain port, if `auto-negotiate` is enabled for this port.

### Format

```
cable-crossing {enable|disable}
```

### Mode

```
Interface Config
```

### **cable-crossing enable**

The device swaps the port output and port input of the TP port.

### **cable-crossing disable**

The device does not swap the port output and port input of the TP port.

## 4.9.8 media-module

Use this command to logically configure media modules.

### Default

```
media-module enable all
```

### Format

```
media-module { remove <1-7> |  
                enable { <1-7> | all } |  
                disable { <1-7> | all } }
```

### Mode

```
Global Config
```

### remove

Logically remove a media-module that has already been physically removed.

### <1-7>

Enter the number of a media module that has already been physically removed but is logically still present in the configuration.

### enable

Enable a media-module slot.

### <1-7>

Enter the number of the media module to be enabled.

### all

Enable all media modules on the device.

### disable

Disable a media-module slot.

### <1-7>

Enter the number of the media module to be disabled.

### all

Disable all media modules on the device.



### 4.9.9 deleteport

This command deletes the port from the link-aggregation (LAG). The interface is a logical slot and port number of a configured link aggregation.

**Note:** This command has to be issued in the member port's interface config mode.

#### Format

```
deleteport <logical slot/port>
```

#### Mode

```
Interface Config
```

### 4.9.10 deleteport all

This command deletes all configured ports from the link-aggregation (LAG). The interface is a logical slot and port number of a configured link-aggregation.

#### Format

```
deleteport <logical slot/port> all
```

#### Mode

```
Global Config
```

## 4.9.11 dip-switch operation

**Note:** This command is available for the MICE, PowerMICE and RS20/RS30/RS40 devices.

Use this command to enable/disable the DIP switch configuration.

### Default

disabled

### Format

```
dip-switch operation { enable | disable }
```

### Mode

Global Config

### enable

Enable the DIP switch configuration.

### disable

Disable the DIP switch configuration.  
The device ignores DIP switch settings.

## 4.9.12 macfilter

This command adds a static MAC filter entry for the MAC address <macaddr> on the VLAN <vlanid>. The <macaddr> parameter must be specified as a 6-byte hexadecimal number in the format of b1:b2:b3:b4:b5:b6.

The restricted MAC Addresses are: 00:00:00:00:00:00, 01:80:C2:00:00:00 to 01:80:C2:00:00:0F, 01:80:C2:00:00:20 to 01:80:C2:00:00:21, and FF:FF:FF:FF:FF:FF.

The <vlanid> parameter must identify a valid VLAN (1 to 4042) .

Up to 100 static MAC filters may be created.

### Format

```
macfilter <macaddr> <vlanid>
```

### Mode

```
Global Config
```

### ■ no macfilter

This command removes all filtering restrictions and the static MAC filter entry for the MAC address <macaddr> on the VLAN <vlanid>. The <macaddr> parameter must be specified as a 6-byte hexadecimal number in the format of b1:b2:b3:b4:b5:b6.

The <vlanid> parameter must identify a valid VLAN (1 to 4042).

### Format

```
no macfilter <macaddr> <vlanid>
```

### Mode

```
Global Config
```

### 4.9.13 macfilter adddest

This command adds the interface to the destination filter set for the MAC filter with the given <macaddr> and VLAN of <vlanid>. The <macaddr> parameter must be specified as a 6-byte hexadecimal number in the format of b1:b2:b3:b4:b5:b6.

The <vlanid> parameter must identify a valid VLAN (1-4042).

#### Format

```
macfilter adddest <macaddr> <vlanid>
```

#### Mode

```
Interface Config
```

#### ■ no macfilter adddest

This command removes a port from the destination filter set for the MAC filter with the given <macaddr> and VLAN of <vlanid>. The <macaddr> parameter must be specified as a 6-byte hexadecimal number in the format of b1:b2:b3:b4:b5:b6.

The <vlanid> parameter must identify a valid VLAN (1-4042).

#### Format

```
no macfilter adddest <macaddr> <vlanid>
```

#### Mode

```
Interface Config
```

### 4.9.14 macfilter adddest all

This command adds all interfaces to the destination filter set for the MAC filter with the given <macaddr> and VLAN of <vlanid>. The <macaddr> parameter must be specified as a 6-byte hexadecimal number in the format of b1:b2:b3:b4:b5:b6.

The <vlanid> parameter must identify a valid VLAN (1 to 4042).

#### Format

```
macfilter adddest {all | <macaddr> <vlanid>}
```

#### Mode

```
Global Config
```

#### ■ no macfilter adddest all

This command removes all ports from the destination filter set for the MAC filter with the given <macaddr> and VLAN of <vlanid>. The <macaddr> parameter must be specified as a 6-byte hexadecimal number in the format of b1:b2:b3:b4:b5:b6.

The <vlanid> parameter must identify a valid VLAN (1 to 4042).

#### Format

```
no macfilter adddest [all | <macaddr> <vlanid>]
```

#### Mode

```
Global Config
```

## 4.9.15 mac notification (Global Config)

Use this command to change the settings for MAC address change notification globally on the device. This command enables the sending of MAC notification traps or sets the MAC notification interval in seconds.

### Format

```
mac notification {operation |  
                  interval <0..2147483647> }
```

### Mode

Global Config

### operation

Enable sending of MAC notification traps.

### interval

Set the MAC notification interval.

### <0..2147483647>

MAC notification interval in seconds.

### ■ no mac notification operation

This command disables sending of MAC notification traps globally.

### Format

```
no mac notification operation
```

### Mode

Global Config

## 4.9.16 mac notification (Interface Config)

Use this command to change the settings for MAC address change notification for one port. This command enables MAC notification for this port or sets the mode for which action the device sends a MAC notification.

### Format

```
mac notification {operation |  
                  mode { add | remove | all } }
```

### Mode

Interface Config

### operation

Enable sending of MAC notification traps.

### mode

Set the mode for which action the device sends a MAC notification.

### add

The device sends MAC notification traps when entries are added to the FDB.

### remove

The device sends MAC notification traps when entries are removed from the FDB.

### all

The device sends MAC notification traps when entries are changed in the FDB.

### ■ no mac notification operation

This command disables sending of MAC notification traps for this port.

### Format

```
no mac notification operation
```

### Mode

Interface Config

### 4.9.17 monitor session <session-id>

This command configures a probe port and a monitored port for monitor session (port monitoring). The first slot/port is the source monitored port and the second slot/port is the destination probe port. If this command is executed while port monitoring is enabled, it will have the effect of changing the probe and monitored port values.

#### Format

```
monitor session <session-id>
  [ mode |
    source interface <slot/port>
      [direction { rx | tx | tx/rx } ] |
    destination interface <slot/port> ]
```

#### Mode

Global Config

#### session-id

Session number (currently, session number 1 is supported).

#### mode

Enable/Disable port mirroring session.

**Note:** does not affect the source or destination interfaces.

#### source interface <slot/port>

Configure the source interface (in `slot/port` notation).

#### direction

Configure the direction of the interface.

#### rx

Configure the direction of the interface as rx (receive).

#### tx

Configure the direction of the interface as tx (transmit).

#### rx/tx

Configure the direction of the interface as rx/tx (receive and transmit).

#### destination interface <slot/port>

Configure the probe interface (in `slot/port` notation).



**■ no monitor session <session-id>**

This command removes the monitor session (port monitoring) designation from both the source probe port and the destination monitored port and removes the probe port from all VLANs. The port must be manually re-added to any desired VLANs.

**Format**

```
no monitor session <session-id> [mode]
```

**Mode**

```
Global Config
```

**session-id**

Session number (currently, session number 1 is supported).

### 4.9.18 monitor session <session-id> mode

This command configures the monitor session (port monitoring) mode to enable. The probe and monitored ports must be configured before monitor session (port monitoring) can be enabled. If enabled, the probe port will monitor all traffic received and transmitted on the physical monitored port. It is not necessary to disable port monitoring before modifying the probe and monitored ports.

#### Default

disabled

#### Format

```
monitor session <session-id> mode
```

#### Mode

Global Config

#### session-id

Session number (currently, session number 1 is supported).

### ■ no monitor session <session-id> mode

This command sets the monitor session (port monitoring) mode to disable.

#### Format

```
no monitor session <session-id> mode
```

#### Mode

Global Config

#### session-id

Session number (currently, session number 1 is supported).

### 4.9.19 monitor session <session-id> source/destination

This command allows you to configure and activate the port mirroring function of the switch. Port mirroring is when the data traffic of a source port is copied to a specified destination port. The data traffic at the source port is not influenced by port mirroring. A management tool connected at the specified port, e.g., an RMON probe, can thus monitor the data traffic of the source port.

This command can be called multiple times with different ports to add more than one source port to the session.

It is possible to add/remove ports to/from an active session.

#### Note:

- The device supports a maximum of one session.
- The maximum number of source ports is 8.
- Ports configured as mirror source or destination ports have to be physical ports.

**Note:** In active port mirroring, the specified destination port is used solely for observation purposes.

#### Default

none

#### Format

```
monitor session <session-id> {source | destination}  
interface <slot/port>
```

#### Mode

Global Config

#### session-id

Session number (currently, session number 1 is supported).

**■ no monitor session <session-id> source/destination**

This command resets the monitor session (port monitoring) source/destination. The port will be removed from port mirroring

**Format**

```
no monitor session <session-id> {source | destination} interface
```

**Mode**

Global Config

**session-id**

Session number (currently, session number 1 is supported).

## 4.9.20 link-aggregation

This command configures a new Link Aggregation (LAG) and generates a logical slot/port number for the Link Aggregation. Display this number using the “show link-aggregation”.

**Note:** Before including a port in a Link Aggregation, set the port physical mode. See ‘speed’ command.

**Format**

```
link-aggregation <name>
```

**Mode**

Global Config

## 4.9.21 link-aggregation adminmode

This command enables a Link Aggregation (LAG). The interface is a logical slot/port for a configured Link Aggregation. The option `all` sets every configured Link Aggregation with the same administrative mode setting.

### Format

```
link-aggregation adminmode all
```

### Mode

```
Global Config
```

### ■ no link-aggregation adminmode

This command disables a Link Aggregation (LAG). The interface is a logical slot/port for a configured Link Aggregation. The option `all` sets every configured Link Aggregation with the same administrative mode setting.

### Format

```
no link-aggregation adminmode all
```

### Mode

```
Global Config
```

## 4.9.22 link-aggregation linktrap

This command enables link trap notifications for the link-aggregation (LAG). The interface is a logical slot/port for a configured link-aggregation. The option `all` sets every configured link-aggregation with the same administrative mode setting.

### Default

enabled

### Format

```
link-aggregation linktrap {<logical slot/port> |  
all}
```

### Mode

Global Config

### ■ no link-aggregation linktrap

This command disables link trap notifications for the link-aggregation (LAG). The interface is a logical unit, slot and port slot and port for a configured link-aggregation. The option `all` sets every configured link-aggregation with the same administrative mode setting.

### Format

```
no link-aggregation linktrap {<logical slot/port> |  
all}
```

### Mode

GlobalConfig

### 4.9.23 link-aggregation name

This command defines a name for the link-aggregation (LAG). The interface is a logical slot/port for a configured link-aggregation, and name is an alphanumeric string up to 15 characters. This command is used to modify the name that was associated with the link-aggregation when it was created.

#### Format

```
link-aggregation name {<logical slot/port> | all |  
<name>}
```

#### Mode

Global Config

### 4.9.24 rmon-alarm add

This command adds an RMON alarm.

#### Format

```
rmon-alarm add <index>  
                [<mib-variable>  
                <rising-threshold>  
                <falling-threshold>]
```

#### Mode

Global Config

#### index

Enter the index of the RMON alarm.

#### mib-variable

Enter the MIB variable.

#### rising-threshold

Enter the rising threshold for the RMON alarm.

#### falling-threshold

Enter the falling threshold for the RMON alarm.

### **4.9.25 rmon-alarm delete**

This command deletes an RMON alarm.

#### **Format**

```
rmon-alarm delete <index>
```

#### **Mode**

Global Config

#### **index**

Enter the index of the RMON alarm.

### **4.9.26 rmon-alarm enable**

This command enables an RMON alarm.

#### **Format**

```
rmon-alarm enable <index>
```

#### **Mode**

Global Config

#### **index**

Enter the index of the RMON alarm.



### 4.9.27 rmon-alarm disable

This command disables an RMON alarm.

#### Format

```
rmon-alarm disable <index>
```

#### Mode

Global Config

#### index

Enter the index of the RMON alarm.

### 4.9.28 rmon-alarm modify mib-variable

This command modifies the mib-variable of an RMON alarm.

#### Format

```
rmon-alarm modify <index> mib-variable <mib-variable>
```

#### Mode

Global Config

#### index

Enter the index of the RMON alarm.

#### mib-variable

Enter the MIB variable.

### 4.9.29 rmon-alarm modify thresholds

This command modifies the thresholds of an RMON alarm.

#### Format

```
rmon-alarm modify <index> thresholds  
                    <rising-threshold>  
                    <falling-threshold>
```

#### Mode

Global Config

#### index

Enter the index of the RMON alarm.

#### rising-threshold

Enter the rising threshold for the RMON alarm.

#### falling-threshold

Enter the falling threshold for the RMON alarm.

### 4.9.30 rmon-alarm modify interval

This command modifies the interval of an RMON alarm.

#### Format

```
rmon-alarm modify <index> interval <interval>
```

#### Mode

Global Config

#### index

Enter the index of the RMON alarm.

#### interval

Enter the interval for the RMON alarm.

### 4.9.31 rmon-alarm modify sample-type

This command modifies the sample-type of an RMON alarm.

#### Format

```
rmon-alarm modify <index> sample-type {absolute|delta}
```

#### Mode

Global Config

#### index

Enter the index of the RMON alarm.

#### absolute

Sample-type for RMON alarm is absolute.

#### delta

Sample-type for RMON alarm is delta.

### 4.9.32 rmon-alarm modify startup-alarm

This command modifies the startup-alarm of an RMON alarm.

#### Format

```
rmon-alarm modify <index> startup-alarm  
                    {rising | falling | risingorfalling}
```

#### Mode

Global Config

#### index

Enter the index of the RMON alarm.

#### rising

Start-up alarm if the value is rising.

#### falling

Start-up alarm if the value is falling.

#### risingorfalling

Start-up alarm if the value is rising or falling.

### 4.9.33 rmon-alarm modify rising-event

This command modifies the rising-event of an RMON alarm.

#### Format

```
rmon-alarm modify <index> rising-event  
                    <rising-event-index>
```

#### Mode

Global Config

#### index

Enter the index of the RMON alarm.

#### rising-event-index

Enter the index for the rising event for the RMON alarm.

### 4.9.34 rmon-alarm modify falling-event

This command modifies the falling-event of an RMON alarm.

#### Format

```
rmon-alarm modify <index> falling-event  
                    <falling-event-index>
```

#### Mode

Global Config

#### index

Enter the index of the RMON alarm.

#### falling-event-index

Enter the index for the falling event for the RMON alarm.

### 4.9.35 set garp timer join

This command sets the GVRP join time per port and per GARP. Join time is the interval between the transmission of GARP Protocol Data Units (PDUs) registering (or re-registering) membership for a VLAN or multicast group. This command has an effect only when GVRP is enabled. The time is from 10 to 100 (centiseconds). The value 20 centiseconds is 0.2 seconds.

#### Default

20

#### Format

```
set garp timer join <10-100>
```

#### Mode

Global Config  
Interface Config

#### ■ no set garp timer join

This command sets the GVRP join time per port and per GARP to 20 centiseconds (0.2 seconds). This command has an effect only when GVRP is enabled.

#### Format

```
no set garp-timer join
```

#### Mode

Global Config  
Interface Config

### 4.9.36 set garp timer leave

This command sets the GVRP leave time per port. Leave time is the time to wait after receiving an unregister request for a VLAN or a multicast group before deleting the VLAN entry. This can be considered a buffer time for another station to assert registration for the same attribute in order to maintain uninterrupted service. time is 20 to 600 (centiseconds). The value 60 centiseconds is 0.6 seconds.

**Note:** This command has an effect only when GVRP is enabled.

#### Default

60

#### Format

```
set garp timer leave <20-600>
```

#### Mode

Global Config

Interface Config

#### ■ no set garp timer leave

This command sets the GVRP leave time per port to 60 centiseconds (0.6 seconds).

**Note:** This command has an effect only when GVRP is enabled.

#### Format

```
no set garp timer leave
```

#### Mode

Global Config

Interface Config

### 4.9.37 set garp timer leaveall

This command sets how frequently *Leave All PDUs* are generated per port. A *Leave All PDU* indicates that all registrations will be unregistered. Participants would need to rejoin in order to maintain registration. The value applies per port and per GARP participation. The time may range from 200 to 6000 (centiseconds). The value 1000 centiseconds is 10 seconds.

**Note:** This command has an effect only when GVRP is enabled.

#### Default

1000

#### Format

```
set garp timer leaveall <200-6000>
```

#### Mode

Global Config  
Interface Config

#### ■ no set garp timer leaveall

This command sets how frequently *Leave All PDUs* are generated per port to 1000 centiseconds (10 seconds).

**Note:** This command has an effect only when GVRP is enabled.

#### Format

```
no set garp timer leaveall
```

#### Mode

Global Config  
Interface Config

### 4.9.38 set gmrp adminmode

This command enables GARP Multicast Registration Protocol (GMRP) on the system. The default value is disable.

#### Format

```
set gmrp adminmode
```

#### Mode

```
Privileged EXEC and Global Config
```

### ■ no set gmrp adminmode

This command disables GARP Multicast Registration Protocol (GMRP) on the system.

#### Format

```
no set gmrp adminmode
```

#### Mode

```
Privileged EXEC and Global Config
```



### 4.9.39 set gmrp interfacemode

This command enables GARP Multicast Registration Protocol on a selected interface. If an interface which has GARP enabled is enlisted as a member of a Link Aggregation (LAG), GARP functionality will be disabled on that interface. GARP functionality will subsequently be re-enabled if Link Aggregation (LAG) membership is removed from an interface that has GARP enabled.

#### Default

enabled

#### Format

```
set gmrp interfacemode
```

#### Mode

Interface Config

#### ■ no set gmrp interfacemode

This command disables GARP Multicast Registration Protocol on a selected interface. If an interface which has GARP enabled is enlisted as a member of a Link Aggregation (LAG), GARP functionality will be disabled on that interface. GARP functionality will subsequently be re-enabled if Link Aggregation (LAG) membership is removed from an interface that has GARP enabled.

#### Format

```
no set gmrp interfacemode
```

#### Mode

Interface Config

## 4.9.40 set gmrp interfacemode

This command enables GARP Multicast Registration Protocol on all interfaces. If an interface which has GARP enabled is enabled for routing or is enlisted as a member of a link-aggregation (LAG), GARP functionality will be disabled on that interface. GARP functionality will subsequently be re-enabled if routing is disabled and link-aggregation (LAG) membership is removed from an interface that has GARP enabled.

### Default

disabled

### Format

```
set gmrp interfacemode
```

### Mode

Global Config

### ■ no set gmrp interfacemode

This command disables GARP Multicast Registration Protocol on a selected interface.

### Format

```
no set gmrp interfacemode
```

### Mode

Global Config

### 4.9.41 set gmrp forward-all-groups

This command enables the GMRP Multicast Registration Protocol feature 'Forward All Groups' for all ports.

#### Default

disabled

#### Format

```
set gmrp forward-all-groups
```

#### Mode

Interface Config  
Global Config

#### ■ no set gmrp forward-all-groups

This command disables the GMRP Multicast Registration Protocol feature 'Forward All Groups' for all ports.

#### Format

```
no set gmrp forward-all-groups
```

#### Mode

Interface Config  
Global Config

## 4.9.42 set gmrp forward-unknown

**Note:** This command is available for the devices of the MS20/MS30, RS20/RS30/RS40, MACH102, MACH104, MACH1000, MACH1040, OCTOPUS, RSR20/RSR30 family.

Use this command to configure if the device should forward unknown GMRP multicast packets. The setting can be discard or flood. The default is flood.

### Default

flood

### Format

```
set gmrp forward-unknown {discard | flood}
```

### Mode

Global Config

### discard

The device discards unknown GMRP multicast packets.

### flood

The device floods unknown GMRP multicast packets.

### ■ no set gmrp forward-unknown

This command disables the GMRP Multicast Registration Protocol feature 'Forward Unknown' for all ports.

### Format

```
no set gmrp forward-unknown
```

### Mode

Global Config

### 4.9.43 set igmp

This command enables IGMP Snooping on the system. The default value is disable.

**Note:** The IGMP snooping application supports the following:

- ▶ Global configuration or per interface configuration.
- ▶ Validation of the IP header checksum (as well as the IGMP header checksum) and discarding of the frame upon checksum error.
- ▶ Maintenance of the forwarding table entries based on the MAC address versus the IP address.
- ▶ Flooding of unregistered multicast data packets to all ports in the VLAN.

#### Format

```
set igmp
```

#### Mode

```
Global Config
```

#### ■ no set igmp

This command disables IGMP Snooping on the system.

#### Format

```
no set igmp
```

#### Mode

```
Global Config
```

## 4.9.44 set igmp

This command enables IGMP Snooping on a selected interface.

### Default

enabled

### Format

```
set igmp
```

### Mode

Interface Config

## ■ no set igmp

This command disables IGMP Snooping on a selected interface.

### Format

```
no set igmp
```

### Mode

Interface Config

## 4.9.45 set igmp aging-time-unknown

This command configures the IGMP Snooping aging time for unknown multicast frames (unit: seconds, min.: 3, max.: 3,600, default: 260).

### Format

```
set igmp aging-time-unknown <3-3600>
```

### Mode

Global Config

## 4.9.46 set igmp automatic-mode

If enabled, this port is allowed to be set as static query port automatically, if the LLDP protocol has found a switch or router connected to this port. Use the command's normal form to enable the feature, the 'no' form to disable it.

### Default

disabled

### Format

```
set igmp automatic-mode
```

### Mode

Interface Config

## 4.9.47 set igmp forward-all

This command activates the forwarding of multicast frames to this interface even if the given interface has not received any reports by hosts. N. B.: this applies only to frames that have been learned via IGMP Snooping. The purpose is that an interface (e. g. a HIPER Ring's ring port) may need to forward all such frames even if no reports have been received on it. This enables faster recovery from ring interruptions for multicast frames.

### Default

disabled

### Format

```
set igmp forward-all
```

### Mode

Interface Config

### ■ no set igmp forward-all

This command disables the forwarding of all multicast frames learned via IGMP Snooping on a selected interface.

### Format

```
no set igmp forward-all
```

### Mode

Interface Config



## 4.9.48 set igmp forward-unknown

**Note:** This command is available for MS20/MS30.

This command defines how to handle unknown multicast frames.

### Format

```
set igmp forward-unknown
    { discard | flood | query-ports}
```

### Mode

```
Global Config
```

### discard

Unknown multicast frames will be discarded.

### flood

Unknown multicast frames will be flooded.

### query-ports

Unknown multicast frames will be forwarded only to query ports.

## 4.9.49 set igmp static-query-port

This command activates the forwarding of IGMP membership report frames to this interface even if the given interface has not received any queries. The purpose is that a port may need to forward such frames even if no queries have been received on it (e. g., if a router is connected to the interface that sends no queries).

### Default

disabled

### Format

```
set igmp static-query-port
```

### Mode

Interface Config

### ■ no set igmp

This command disables the unconditional forwarding of IGMP membership report frames to this interface.

### Format

```
no set igmp static-query-port
```

### Mode

Interface Config

### 4.9.50 set igmp groupmembershipinterval

This command sets the IGMP Group Membership Interval time on the system. The Group Membership Interval time is the amount of time in seconds that a switch will wait for a report from a particular group on a particular interface before deleting the interface from the entry. This value must be greater than the IGMP Maximum Response time value. The range is 3 to 3,600 seconds.

#### Default

260

#### Format

```
set igmp groupmembershipinterval <3-3600>
```

#### Mode

Global Config

#### ■ no set igmp groupmembershipinterval

This command sets the IGMP Group Membership Interval time on the system to 260 seconds.

#### Format

```
no set igmp groupmembershipinterval
```

#### Mode

Global Config

### 4.9.51 set igmp interfacemode

This command enables IGMP Snooping on all interfaces. If an interface which has IGMP Snooping enabled is enabled for port-based routing or is enlisted as a member of a link-aggregation (LAG), IGMP Snooping functionality will be disabled on that interface. IGMP Snooping functionality will subsequently be re-enabled if routing is disabled or link-aggregation (LAG) membership is removed from an interface that has IGMP Snooping enabled.

#### Format

```
set igmp interfacemode
```

#### Mode

```
Global Config
```

### ■ no set igmp interfacemode

This command disables IGMP Snooping on all interfaces.

#### Format

```
no set igmp interfacemode
```

#### Mode

```
Global Config
```

### 4.9.52 set igmp lookup-interval-unknown

This command configures the IGMP Snooping lookup response time for unknown multicast frames (unit: seconds, min.: 2, max.: 3,599, default: 125).

#### Format

```
set igmp lookup-interval-unknown <2-3599>
```

#### Mode

```
Global Config
```

#### <2-3599>

Enter the IGMP Snooping lookup response time for unknown multicast frames (unit: seconds, min.: 2, max.: 3,599, default: 125).

### 4.9.53 set igmp lookup-resp-time-unknown

This command configures the IGMP Snooping lookup interval for unknown multicast frames (unit: seconds, min.: 1, max.: 3,598, default: 10).

#### Format

```
set igmp lookup-resp-time-unknown <1-3598>
```

#### Mode

```
Global Config
```

#### <2-3598>

Enter the IGMP Snooping lookup interval for unknown multicast frames (unit: seconds, min.: 1, max.: 3,598, default: 10).

## 4.9.54 set igmp maxresponse

This command sets the IGMP Maximum Response time on the system. The Maximum Response time is the amount of time in seconds that a switch will wait after sending a query in response to a received leave message, before deleting the multicast group received in the leave message. If the switch receives a report in response to the query within the maxresponse time, then the multicast group is not deleted. This value must be less than the IGMP Query Interval time value. The range is 1 to 3,598 seconds.

### Default

10

### Format

```
set igmp maxresponse <1-3598>
```

### Mode

Global Config

**Note:** the IGMP Querier's max. response time was also set. It is always the same value as the IGMP Snooping max. response time.

### ■ no set igmp maxresponse

This command sets the IGMP Maximum Response time on the system to 10 seconds.

### Format

```
no set igmp maxresponse
```

### Mode

Global Config

### 4.9.55 set igmp querier max-response-time

Configure the IGMP Snooping Querier's maximum response time. The range is 1 to 3,598 seconds. The default value is 10 seconds.

**Default**

10

**Format**

```
set igmp querier max-response-time <1-3598>
```

**Mode**

Global Config

**Note:** The IGMP Snooping max. response time was also set. It is always the same value as the IGMP Querier's max. response time.

### 4.9.56 set igmp querier protocol-version

Configure the IGMP Snooping Querier's protocol version (1, 2 or 3).

**Default**

2

**Format**

```
set igmp querier protocol-version {1 | 2 | 3}
```

**Mode**

Global Config

### 4.9.57 set igmp querier status

Configure the IGMP Snooping Querier's administrative status (enable or disable).

**Default**

disable

**Format**

```
set igmp querier status {enable | disable}
```

**Mode**

Global Config

### 4.9.58 set igmp querier tx-interval

Configure the IGMP Snooping Querier's transmit interval. The range is 2 to 3,599 seconds.

**Default**

125

**Format**

```
set igmp querier tx-interval <2-3599>
```

**Mode**

Global Config



### 4.9.59 set igmp query-ports-to-filter

This command enables or disables the addition of query ports to multicast filter portmasks. The setting can be enable or disable.

**Default**

Disable

**Format**

```
set igmp query-ports-to-filter {enable | disable}
```

**Mode**

Global Config

**enable**

Addition of query ports to multicast filter portmasks.

**disable**

No addition of query ports to multicast filter portmasks.

## 4.9.60 set pre-login-banner text

Use this command to set the text for the pre-login banner. The device displays this banner additionally before login in the CLI and before login in the graphical user interface.

### Default

Empty string

### Format

```
set pre-login-banner text <text>
```

### Mode

Privileged Exec

### text

Enter the text for the pre-login banner.

Possible values: Max. 255 characters in the range ASCII code 0x20 (space character, " ") to ASCII code 0x7E (tilde, "~"), except ASCII code 0x25 (percent sign, "%").

Use "\\n" for new line and "\\t" for tab.

## 4.9.61 selftest ramtest

Enable or disable the RAM test for a cold start of the device.

Deactivating the RAM test reduces the booting time for a cold start of the device.

Default: enabled.

### Format

```
selftest ramtest {disable|enable}
```

### Mode

Global Config

### selftest ramtest disable

Disable the ramtest.

### selftest ramtest enable

Enable the ramtest. This is the default.

## 4.9.62 selftest reboot-on-hdxerror

Enable or disable a restart when the device detects a half duplex mismatch error. Default: enabled.

### Format

```
selftest reboot-on-hdxerror {disable|enable}
```

### Mode

```
Global Config
```

### selftest reboot-on-hdxerror disable

Disable the reboot-on-hdxerror function.

### selftest reboot-on-hdxerror enable

Enable the reboot-on-hdxerror function. This is the default.

### 4.9.63 selftest reboot-on-error

Enable or disable a restart due to an undefined software or hardware state.  
Default: disabled.

#### Format

```
selftest reboot-on-error  
                {disable|enable|seriousOnly}
```

#### Mode

Global Config

#### **selftest reboot-on-error disable**

Disable the reboot-on-error function. This is the default.

#### **selftest reboot-on-error enable**

Enable the reboot-on-error function.

#### **selftest reboot-on-error seriousOnly**

The device will only reboot on errors considered to be critical.

**Note:** Duplex mismatch errors are considered to be non-critical. In case of a detected duplex mismatch error, the device will not reboot. Reset the device to restore ports to an usable state.

## 4.9.64 show auto-disable brief

Use this command to display the Auto Disable summary.

### Format

```
show auto-disable brief
```

### Mode

```
Global Config
```

### Intf

Display the number of the interface in slot/port format.

### Error reason

Display the error reason for auto-disable.

Possible values: no error, link-flap, crc-error, overload-detection.

### Component name

Display the name of the component for auto-disable.

### Remaining time(sec.)

Display the remaining time in seconds for auto-disable.

Possible values: 0 | 30..2147483.

### Auto-Disable time(sec.)

Display the time for auto-disable in seconds.

Possible values: 0 | 30..2147483.

### Auto-Disable oper state

Display the operational state of the auto-disable function.

Possible values: active, inactive.

## 4.9.65 show auto-disable reasons

Use this command to display the reasons for port auto-disable on this device.

### Format

```
show auto-disable reasons
```

### Mode

Global Config

### Error reason

Display the error reasons of the port auto-disable function (link-flap, crc-error, overload-detection).

### State

Display the state of the port auto-disable function.  
Possible values: enabled, disabled.

## 4.9.66 show dip-switch

This command displays the DIP switch operation configuration.

### Format

```
show dip-switch
```

### Mode

```
Global Config
```

### DIP Switch operation

This field displays the DIP Switch operation status.

Possible values: Enabled, Disabled

### DIP Switch conflict

This field displays the DIP Switch conflict status.

Possible values: True, False

### DIP Switch Red. Manager

This field displays the DIP Switch Redundancy Manager status.

Possible values: Enabled, Disabled

### DIP Switch Standby

This field displays the DIP Switch Standby status.

Possible values: Enabled, Disabled

### DIP Switch RingPort

**Note:** This command is available for the MICE devices.

This field displays the DIP Switch RingPort numbers.

Possible values: Interface number in slot/port notation.

### DIP Switch SW config

**Note:** This command is available for the MICE devices.

This field displays the DIP Switch SW config status.

Possible values: Enabled, Disabled

### 4.9.67 show garp

This command displays Generic Attributes Registration Protocol (GARP) information.

#### Format

```
show garp
```

#### Mode

Privileged EXEC and User EXEC

#### GMRP Admin Mode

This displays the administrative mode of GARP Multicast Registration Protocol (GMRP) for the system.

### 4.9.68 show gmrp configuration

This command displays Generic Attributes Registration Protocol (GARP) information for one or all interfaces.

#### Format

```
show gmrp configuration {<slot/port> | all}
```

#### Mode

Privileged EXEC and User EXEC

#### Interface

This displays the slot/port of the interface that this row in the table describes.

#### Join Timer

Specifies the interval between the transmission of GARP PDUs registering (or re-registering) membership for an attribute. Current attributes are a VLAN or multicast group. There is an instance of this timer on a per-Port, per-GARP participant basis. Permissible values are 10 to 100 centiseconds (0.1 to 1.0 seconds). The factory default is 20 centiseconds (0.2 seconds). The finest granularity of specification is 1 centisecond (0.01 seconds).



### Leave Timer

Specifies the period of time to wait after receiving an unregister request for an attribute before deleting the attribute. Current attributes are a VLAN or multicast group. This may be considered a buffer time for another station to assert registration for the same attribute in order to maintain uninterrupted service. There is an instance of this timer on a per-Port, per-GARP participant basis. Permissible values are 20 to 600 centiseconds (0.2 to 6.0 seconds). The factory default is 60 centiseconds (0.6 seconds). The finest granularity of specification is 1 centisecond (0.01 seconds).

### LeaveAll Timer

This Leave All Time controls how frequently LeaveAll PDUs are generated. A LeaveAll PDU indicates that all registrations will shortly be deregistered. Participants will need to rejoin in order to maintain registration. There is an instance of this timer on a per-Port, per-GARP participant basis. The Leave All Period Timer is set to a random value in the range of LeaveAllTime to 1.5\*LeaveAllTime. Permissible values are 200 to 6000 centiseconds (2 to 60 seconds). The factory default is 1000 centiseconds (10 seconds). The finest granularity of specification is 1 centisecond (0.01 seconds).

### Port GMRP Mode

Indicates the GMRP administrative mode for the port. It may be enabled or disabled. If this parameter is disabled, Join Time, Leave Time and Leave All Time have no effect. The factory default is disabled.

## 4.9.69 show igmpsnooping

This command displays IGMP Snooping information. Configured information is displayed whether or not IGMP Snooping is enabled. Status information is only displayed when IGMP Snooping is enabled.

### Format

```
show igmpsnooping
```

**Mode**

Privileged EXEC and User EXEC

**Admin Mode**

This indicates whether or not IGMP Snooping is globally enabled on the switch.

**Forwarding of Unknown Frames**

This displays if and how unknown multicasts are forwarded.

The setting can be Discard, Flood or Query Ports.

The default is Query Ports.

**Group Membership Interval**

This displays the IGMP Group Membership Interval. This is the amount of time a switch will wait for a report for a particular group on a particular interface before it sends a query on that interface. This value may be configured.

**Multicast Control Frame Count**

This displays the number of multicast control frames that are processed by the CPU.

**Interfaces Enabled for IGMP Snooping**

This is the list of interfaces on which IGMP Snooping is enabled. Additionally, if a port has a special function, it will be shown to the right of its slot/port number. There are 3 special functions:

Forward All, Static Query Port and Learned Query Port.

**Querier Status (the administrative state).**

This displays the IGMP Snooping Querier's administrative status.

**Querier Mode (the actual state, read only)**

This displays the IGMP Snooping Querier's operating status.

**Querier Transmit Interval**

This displays the IGMP Snooping Querier's transmit interval in seconds.

**Querier Max. Response Time**

This displays the IGMP Snooping Querier's maximum response time in seconds.

**Querier Protocol Version**

This displays the IGMP Snooping Querier's protocol version number.

## 4.9.70 show mac-filter-table gmrp

This command displays the GARP Multicast Registration Protocol (GMRP) entries in the Multicast Forwarding Database (MFDB) table.

### Format

```
show mac-filter-table gmrp
```

### Mode

Privileged EXEC and User EXEC

### Mac Address

A unicast MAC address for which the switch has forwarding and or filtering information. The format is 6 or 8 two-digit hexadecimal numbers that are separated by colons, for example 01:23:45:67:89:AB. In an IVL system the MAC address will be displayed as 8 bytes.

### Type

This displays the type of the entry. Static entries are those that are configured by the end user. Dynamic entries are added to the table as a result of a learning process or protocol.

### Description

The text description of this multicast table entry.

### Interfaces

The list of interfaces that are designated for forwarding (Fwd:) and filtering (Flt:).

## 4.9.71 show mac-filter-table igmpsnooping

This command displays the IGMP Snooping entries in the Multicast Forwarding Database (MFDB) table.

### Format

```
show mac-filter-table igmpsnooping
```

### Mode

Privileged EXEC and User EXEC

### Mac Address

A multicast MAC address for which the switch has forwarding and or filtering information. The format is two-digit hexadecimal numbers that are separated by colons, for example 01:23:45:67:89:AB.

### Type

This displays the type of the entry. Static entries are those that are configured by the end user. Dynamic entries are added to the table as a result of a learning process or protocol.

### Description

The text description of this multicast table entry.

### Interfaces

The list of interfaces that are designated for forwarding (Fwd:) and filtering (Flt:).

## 4.9.72 show mac-filter-table multicast

This command displays the Multicast Forwarding Database (MFDB) information. If the command is entered with no parameter, the entire table is displayed. This is the same as entering the optional `all` parameter. The user can display the table entry for one MAC Address by specifying the MAC address as an optional parameter.

### Format

```
show mac-filter-table multicast  
[<macaddr> <1-4042>]
```

### Mode

Privileged EXEC and User EXEC

### Mac Address

A multicast MAC address for which the switch has forwarding and or filtering information. The format is two-digit hexadecimal numbers that are separated by colons, for example 01:23:45:67:89:AB.

### Type

This displays the type of the entry. Static entries are those that are configured by the end user. Dynamic entries are added to the table as a result of a learning process or protocol.

### Component

The component that is responsible for this entry in the Multicast Forwarding Database. Possible values are IGMP Snooping, GMRP and Static Filtering.

### Description

The text description of this multicast table entry.

### Interfaces

The list of interfaces that are designated for forwarding (Fwd:) and filtering (Flt:).

### Forwarding Interfaces

The resultant forwarding list is derived from combining all the component's forwarding interfaces and removing the interfaces that are listed as the static filtering interfaces.

### 4.9.73 show mac-filter-table static

This command displays the Static MAC Filtering information for all Static MAC Filters. If `all` is selected, all the Static MAC Filters in the system are displayed. If a `macaddr` is entered, a `vlan` must also be entered and the Static MAC Filter information will be displayed only for that MAC address and VLAN.

#### Format

```
show mac-filter-table static {<macaddr> <vlanid> |  
all}
```

#### Mode

Privileged EXEC and User EXEC

#### MAC Address

Is the MAC Address of the static MAC filter entry.

#### VLAN ID

Is the VLAN ID of the static MAC filter entry.

#### Source Port(s)

Indicates the source port filter set's slot and port(s).

#### Destination Port(s)

Indicates the destination port filter set's slot and port(s).

## 4.9.74 show mac-filter-table staticfiltering

This command displays the Static Filtering entries in the Multicast Forwarding Database (MFDB) table.

### Format

```
show mac-filter-table staticfiltering
```

### Mode

Privileged EXEC and User EXEC

### Mac Address

A unicast MAC address for which the switch has forwarding and or filtering information. The format is 6 or 8 two-digit hexadecimal numbers that are separated by colons, for example 01:23:45:67:89:AB.

### Type

This displays the type of the entry. Static entries are those that are configured by the end user. Dynamic entries are added to the table as a result of a learning process or protocol.

### Description

The text description of this multicast table entry.

### Interfaces

The list of interfaces that are designated for forwarding (Fwd:) and filtering (Flt:).

## 4.9.75 show mac-filter-table stats

This command displays the Multicast Forwarding Database (MFDB) statistics.

### Format

```
show mac-filter-table stats
```

### Mode

Privileged EXEC and User EXEC

### Total Entries

This displays the total number of entries that can possibly be in the Multicast Forwarding Database table.

### Most MFDB Entries Ever Used

This displays the largest number of entries that have been present in the Multicast Forwarding Database table. This value is also known as the MFDB high-water mark.

### Current Entries

This displays the current number of entries in the Multicast Forwarding Database table.

## 4.9.76 show mac notification

This command displays the MAC address change notification configuration.

### Format

```
show mac notification
```

### Mode

Privileged EXEC

### MAC notification settings

This table displays the MAC notification settings (status and interval) for the device.



**MAC notification status**

This field displays the status of MAC notification traps for the device.  
Possible values: `enabled`, `disabled`.

**MAC notification interval**

This field displays the MAC notification interval for the device.  
Possible values: `1..2147483647`.

**Interface**

This field displays the number of the interface in `slot/port` format.

**MAC notify**

This field displays the status of MAC notification traps for this port.  
Possible values: `enabled`, `disabled`

**Mode**

This field displays the mode for which action the device sends a MAC notification trap.

Possible values: `add`, `remove`, `all`

**Last MAC address**

This field displays the last MAC address added or removed from the address table for this interface.

Possible values: Valid MAC address in `aa:bb:cc:dd:ee:ff` notation.

**Last MAC status**

This field displays the status of the last MAC address on this interface.

Possible values: `added`, `removed`, `other`.

## 4.9.77 show monitor session

This command displays the port monitoring information for the system.

### Format

```
show monitor session <Session Number>
```

### Mode

Global Config, Privileged EXEC, User EXEC

### Session

Display port monitor session settings.

### Session Number

Session number. Enter 1 for the session number.

### Session ID

Displays the session number of the port monitor session.

Possible values: 1.

### Admin Mode

Displays the status of the port monitoring feature.

Possible values: Enable, Disable.

### Probe Port

Displays the interface configured as the probe port (in slot/port notation). If this value has not been configured, 'Not Configured' will be displayed.

### Mirrored Port

Displays the interface configured as the mirrored port (in slot/port notation). If this value has not been configured, 'Not Configured' will be displayed.

### Direction

Displays the direction which has been configured for the port.

Possible values: rx (receive), tx (transmit), rx/tx (receive and transmit)

If this value has not been configured, 'Not Configured' will be displayed.

## 4.9.78 show port

This command displays port information.

### Format

```
show port {<slot/port> | all} [name]
```

### Mode

Privileged EXEC and User EXEC

### Slot/Port

Valid slot and port number separated by forward slashes.

### Name

When the optional command parameter `name` was specified, the output is different. It specifically includes the Interface Name as the second column, followed by other basic settings that are also shown by the normal command without the command parameter `name`.

### Type

If not blank, this field indicates that this port is a special type of port. The possible values are:

`Mon` - this port is a monitoring port. Look at the Port Monitoring screens to find out more information.

`LA Mbr` - this port is a member of a Link Aggregation (LAG).

`Probe` - this port is a probe port.

### Admin Mode

Indicates the Port control administration state. The port must be enabled in order for it to be allowed into the network. - May be enabled or disabled. The factory default is enabled.

### Physical Mode

Indicates the desired port speed and duplex mode. If auto-negotiation support is selected, then the duplex mode and speed will be set from the auto-negotiation process. Note that the port's maximum capability (full duplex -100M) will be advertised. Otherwise, this object will determine the port's duplex mode and transmission rate. The factory default is Auto.

### Physical Status

Indicates the port speed and duplex mode.

### Link Status

Indicates whether the Link is up or down.

**Link Trap**

This object determines whether or not to send a trap when link status changes. The factory default is enabled.

**Flow**

Indicates if enable flow control is enabled on this port.

**Device Status**

Indicates whether or not the given port's link status is monitored by the device status.

**VLAN Prio**

This object displays the port VLAN priority.

## 4.9.79 show link-aggregation

This command displays an overview of all link-aggregations (LAGs) on the switch.

**Format**

```
show link-aggregation {<logical slot/port> | all}
```

**Mode**

Privileged EXEC and User EXEC

**Logical slot/port**

Valid slot and port number separated by forward slashes.

**Name**

The name of this link-aggregation (LAG). You may enter any string of up to 15 alphanumeric characters.

**Link State**

Indicates whether the Link is up or down.

**Admin Mode**

May be enabled or disabled. The factory default is enabled.

**Link Trap Mode**

This object determines whether or not to send a trap when link status changes. The factory default is enabled.

**STP Mode**

The Spanning Tree Protocol Administrative Mode associated with the port or link-aggregation (LAG). The possible values are:

`Disable` - Spanning tree is disabled for this port.

`Enable` - Spanning tree is enabled for this port.

**Mbr Ports**

A listing of the ports that are members of this link-aggregation (LAG), in slot/port notation. There can be a maximum of eight ports assigned to a given link-aggregation (LAG).

**Port Speed**

Speed of the link-aggregation port.

**Type**

This field displays the status designating whether a particular link-aggregation (LAG) is statically or dynamically maintained. The possible values of this field are `Static`, indicating that the link-aggregation is statically maintained; and `Dynamic`, indicating that the link-aggregation is dynamically maintained.

**Active Ports**

This field lists the ports that are actively participating in the link-aggregation (LAG).

## 4.9.80 show rmon-alarm

This command displays switch configuration information.

**Format**

```
show rmon-alarm
```

**Mode**

```
Privileged EXEC and User EXEC
```

### 4.9.81 show selftest

This command displays switch configuration information.

#### Format

```
show selftest
```

#### Mode

Privileged EXEC and User EXEC

#### Ramtest state

May be enabled or disabled. The factory default is enabled.

#### Reboot on error

May be enabled, disabled or seriousOnly. The factory default is enabled.

## 4.9.82 show storm-control

This command displays switch configuration information.

### Format

```
show storm-control
```

### Mode

Privileged EXEC and User EXEC

### Ingress Limiting

May be enabled or disabled. The factory default is disabled.

### Ingress Limiter Mode

**Note:** This command is available for the MACH4000 and PowerMICE devices.

Sets the global mode for the ingress limiter. The factory default is: Broadcasts only.

### Egress Broadcast Limiting

May be enabled or disabled. The factory default is disabled.

### Egress Limiting (all traffic)

May be enabled or disabled. The factory default is disabled.

### 802.3x Flow Control Mode

May be enabled or disabled. The factory default is disabled.

### 4.9.83 show storm-control limiters port

This command displays the limiter settings per port. "0" means that the respective limiter is disabled.

#### Format

```
show storm-control limiters port {<slot/port>|all}
```

#### Mode

Privileged EXEC and User EXEC

#### Ingress Mode

**Note:** This command is available for the devices RS20/RS30/RS40, MS20/MS30 and OCTOPUS.

Shows the mode for the ingress limiter. The factory default is: Broadcasts only.

#### Ingress Limit

Shows the ingress rate limit. The factory default is: 0.

#### Egress Broadcast Limit

Shows the egress broadcast rate limit. The factory default is: 0.

#### Egress Limit (all traffic)

**Note:** This command is available for the devices RS20/RS30/RS40, MS20/MS30 and OCTOPUS.

Shows the egress rate limit for all frame types.

The factory default is: 0.

### 4.9.84 show vlan

This command displays detailed information, including interface information, for a specific VLAN. The ID is a valid VLAN identification number

#### Format

```
show vlan <vlanid>
```

#### Mode

Privileged EXEC and User EXEC



**VLAN ID**

There is a VLAN Identifier (VID) associated with each VLAN. The range of the VLAN ID is 1 to 4042.

**VLAN Name**

A string associated with this VLAN as a convenience. It can be up to 32 alphanumeric characters long, including blanks. The default is blank. VLAN ID 1 always has a name of `Default`. This field is optional.

**VLAN Type**

Type of VLAN, which can be Default, (VLAN ID = 1), a static (one that is configured and permanently defined), or Dynamic (one that is created by GVRP registration).

**VLAN Creation Time**

Time since VLAN has been created:  
d days, hh:mm:ss (System Uptime).

**Interface**

Valid slot and port number separated by forward slashes. It is possible to set the parameters for all ports by using the selectors on the top line.

**Current**

Determines the degree of participation of this port in this VLAN. The permissible values are:

`Include` - This port is always a member of this VLAN. This is equivalent to registration fixed in the IEEE 802.1Q standard.

`Exclude` - This port is never a member of this VLAN. This is equivalent to registration forbidden in the IEEE 802.1Q standard.

`Autodetect` - Specifies to allow the port to be dynamically registered in this VLAN via GVRP. The port will not participate in this VLAN unless a join request is received on this port. This is equivalent to registration normal in the IEEE 802.1Q standard.

**Configured**

Determines the configured degree of participation of this port in this VLAN. The permissible values are:

`Include` - This port is always a member of this VLAN. This is equivalent to registration fixed in the IEEE 802.1Q standard.

`Exclude` - This port is never a member of this VLAN. This is equivalent to registration forbidden in the IEEE 802.1Q standard.

`Autodetect` - Specifies to allow the port to be dynamically registered in this VLAN via GVRP. The port will not participate in this VLAN unless a join request is received on this port. This is equivalent to registration normal in the IEEE 802.1Q standard.

### Tagging

Select the tagging behavior for this port in this VLAN.

`Tagged` - specifies to transmit traffic for this VLAN as tagged frames.

`Untagged` - specifies to transmit traffic for this VLAN as untagged frames.

### 4.9.85 show vlan brief

This command displays a list of all configured VLANs.

#### Format

```
show vlan brief
```

#### Mode

Privileged EXEC and User EXEC

#### VLAN ID

There is a VLAN Identifier (vlanid) associated with each VLAN. The range of the VLAN ID is 1 to 4042.

#### VLAN Name

A string associated with this VLAN as a convenience. It can be up to 32 alphanumeric characters long, including blanks. The default is blank. VLAN ID 1 always has a name of `Default`. This field is optional.

#### VLAN Type

Type of VLAN, which can be Default, (VLAN ID = 1), a static (one that is configured and permanently defined), or a Dynamic (one that is created by GVRP registration).

#### VLAN Creation Time

Displays the time (as the system time up time) when the VLAN was created.

### 4.9.86 show vlan port

This command displays VLAN port information.

#### Format

```
show vlan port {<slot/port> | all}
```

#### Mode

Privileged EXEC and User EXEC

**Slot/Port**

Valid slot and port number separated by forward slashes. It is possible to set the parameters for all ports by using the selectors on the top line.

**Port VLAN ID**

The VLAN ID that this port will assign to untagged frames or priority tagged frames received on this port. The value must be for an existing VLAN. The factory default is 1.

**Acceptable Frame Types**

Specifies the types of frames that may be received on this port. The options are 'VLAN only' and 'Admit All'. When set to 'VLAN only', untagged frames or priority tagged frames received on this port are discarded. When set to 'Admit All', untagged frames or priority tagged frames received on this port are accepted and assigned the value of the Port VLAN ID for this port. With either option, VLAN tagged frames are forwarded in accordance to the 802.1Q VLAN specification.

**Ingress Filtering**

May be enabled or disabled. When enabled, the frame is discarded if this port is not a member of the VLAN with which this frame is associated. In a tagged frame, the VLAN is identified by the VLAN ID in the tag. In an untagged frame, the VLAN is the Port VLAN ID specified for the port that received this frame. When disabled, all frames are forwarded in accordance with the 802.1Q VLAN bridge specification. The factory default is disabled.

**GVRP**

The protocol for VLAN administration, GVRP (GARP VLAN Registration Protocol) is particularly used for the adjustment of terminal devices and VLAN switches. In realtime, it traces users log-in and log-off and provides updated configuration data to the network management system. In order to be able to use this protocol, GVRP has to be supported by every switch.

GVRP may be enabled or disabled. The factory default is disabled.

**Default Priority**

The 802.1p priority assigned to tagged packets arriving on the port.

### 4.9.87 show voice vlan

Use this command to display the current global Voice VLAN Administrative Mode.

Voice VLAN is a feature used to automatically separate voice and data traffic on a port, by VLAN and/or priority. A primary benefit of using Voice VLAN is to ensure that the sound quality of an IP phone is safeguarded from deteriorating when the data traffic on the port is high.

#### Format

```
show voice vlan
```

#### Mode

```
Privileged EXEC
```

#### Administrative Mode

Possible values: Disable, Enable

## 4.9.88 show voice vlan interface

Use this command to display Use this command to display a summary of the current Voice VLAN configuration for a specific interface.

<slot/port> indicates a specific physical interface.

all indicates all valid interfaces.

### Format

```
show voice vlan interface {<slot/port> | all}
```

### Mode

Privileged EXEC

### <slot/port>

Indicates a specific physical interface.

### all

Indicates all valid interfaces.

### Interface

Displays the physical interface.

### Voice VLAN Interface Mode

Displays the Voice VLAN Interface Mode.

Value range: Disabled, Enabled.

### Voice VLAN Authentication

Displays the Voice VLAN Authentication.

Value range: Disabled, Enabled.

### Voice VLAN Port Status

Displays the Voice VLAN Port Status.

Value range: Disabled, Enabled.

## 4.9.89 shutdown

This command disables a port.

### Default

enabled

### Format

shutdown

### Mode

Interface Config

### ■ no shutdown

This command enables a port.

### Format

no shutdown

### Mode

Interface Config

## 4.9.90 shutdown all

This command disables all ports.

### Default

enabled

### Format

shutdown all

### Mode

Global Config

### ■ no shutdown all

This command enables all ports.

### Format

no shutdown *all*

### Mode

Global Config



## 4.9.91 snmp trap link-status

This command enables link status traps by interface.

**Note:** This command is valid only when the Link Up/Down Flag is enabled. See 'snmp-server enable traps linkmode' command.

### Format

```
snmp trap link-status
```

### Mode

```
Interface Config
```

### ■ no snmp trap link-status

This command disables link status traps by interface.

**Note:** This command is valid only when the Link Up/Down Flag is enabled. See 'snmp-server enable traps linkmode' command).

### Format

```
no snmp trap link-status
```

### Mode

```
Interface Config
```

## 4.9.92 snmp trap link-status all

This command enables link status traps for all interfaces.

**Note:** This command is valid only when the Link Up/Down Flag is enabled (see “snmp-server enable traps linkmode” ).

### Format

```
snmp trap link-status all
```

### Mode

```
Global Config
```

## ■ no snmp trap link-status all

This command disables link status traps for all interfaces.

**Note:** This command is valid only when the Link Up/Down Flag is enabled (see “snmp-server enable traps linkmode”).

### Format

```
no snmp trap link-status all
```

### Mode

```
Global Config
```

### 4.9.93 spanning-tree bpdumigrationcheck

This command enables BPDU migration check on a given interface. This will force the specified port to transmit RST or MST BPDUs. The **all** option enables BPDU migration check on all interfaces.

#### Format

```
spanning-tree bpdumigrationcheck {<slot/port>|all}
```

#### Mode

```
Global Config
```

#### ■ no spanning-tree bpdumigrationcheck

This command disables BPDU migration check on a given interface. The **all** option disables BPDU migration check on all interfaces.

#### Format

```
no spanning-tree bpdumigrationcheck {<slot/  
port>|all}
```

#### Mode

```
Global Config
```

## 4.9.94 speed

This command sets the speed and duplex setting for the interface.

### Format

```
speed {<100 | 10> <half-duplex | full-duplex> | 1000  
full-duplex}
```

### Mode

```
Interface Config
```

Acceptable values are:

#### 1000f

```
1000BASE-T full duplex
```

#### 100h

```
100BASE-T half duplex
```

#### 100f

```
100BASE-T full duplex
```

#### 10h

```
10BASE-T half duplex
```

#### 10f

```
100BASE-T full duplex
```

### 4.9.95 storm-control broadcast

This command enables the egress broadcast limiter globally.

#### Format

```
storm-control broadcast
```

#### Mode

```
Global Config
```

### ■ no storm-control broadcast

This command disables the egress broadcast limiter globally.

#### Format

```
no storm-control broadcast
```

#### Mode

```
Global Config
```

### 4.9.96 storm-control egress-limiting

This command enables or disables the egress limiter globally for all frame types.

#### Format

```
storm-control egress-limiting {disable | enable}
```

#### Mode

```
Global Config
```

### 4.9.97 storm-control ingress-limiting

This command enables or disables the ingress limiter globally.

#### Format

```
storm-control ingress-limiting {disable | enable}
```

#### Mode

```
Global Config
```

### 4.9.98 storm-control ingress-mode

**Note:** This command is available for the MACH4000 and PowerMICE devices.

This command sets the frame type for the ingress limiter globally to: BC or BC+MC.

#### Format

```
storm-control ingress-mode {bc | mc+bc}
```

#### Mode

```
Global Config
```

### 4.9.99 storm-control broadcast (port-related)

This command enables the broadcast limiter per port.  
Enter the maximum number of broadcasts that the given port is allowed to send (unit: frames per second, min.: 0 (no limit), default: 0 (no limit)).

#### Format

```
storm-control broadcast <max. broadcast rate>
```

#### Mode

```
Interface Config
```

### 4.9.100 storm-control egress-limit

**Note:** This command is available for the RS20/RS30/RS40, MS20/MS30 and OCTOPUS devices.

Sets the egress rate limit in kbit/s. "0" means: no limit.

#### Format

```
storm-control egress-limit <max. egress rate>
```

#### Mode

```
Interface Config
```

### 4.9.101 storm-control ingress-limit

Sets the ingress rate limit in kbit/s. "0" means: no limit.

#### Format

```
storm-control ingress-limit <max. ingress rate>
```

#### Mode

```
Interface Config
```

### 4.9.102 storm-control ingress-mode

**Note:** This command is available for the RS20/RS30/RS40, MS20/MS30, OCTOPUS devices.

This command sets the frame type for the ingress limiter to:  
All, BC, BC+MC, BC+MC+uUC.

#### Format

```
storm-control ingress-mode {all | bc | mc+bc |  
uuc+mc+bc}
```

#### Mode

```
Interface Config
```



### 4.9.103 storm-control flowcontrol

This command enables 802.3x flow control for the switch.

**Note:** This command only applies to full-duplex mode ports.

#### Default

disabled

#### Format

```
storm-control flowcontrol
```

#### Mode

Interface Config  
Global Config

#### ■ no storm-control flowcontrol

This command disables 802.3x flow control for the switch.

**Note:** This command only applies to full-duplex mode ports.

#### Format

```
no storm-control flowcontrol
```

#### Mode

Interface Config  
Global Config

### 4.9.104 storm-control flowcontrol per port

This command enables 802.3x flow control for the port.

**Note:** This command only applies to full-duplex mode ports.

#### Default

enabled

#### Format

```
storm-control flowcontrol
```

#### Mode

Interface Config

### ■ no storm-control flowcontrol per port

This command disables 802.3x flow control for the port.

**Note:** This command only applies to full-duplex mode ports.

#### Format

```
no storm-control flowcontrol
```

#### Mode

Interface Config

## 4.9.105vlan

This command creates a new VLAN and assigns it an ID. The ID is a valid VLAN identification number (ID 1 is reserved for the default VLAN). VLAN range is 1-4042.

### Format

```
vlan <1-4042>
```

### Mode

```
VLAN database
```

### ■ no vlan

This command deletes an existing VLAN. The ID is a valid VLAN identification number (ID 1 is reserved for the default VLAN). VLAN range is 1-4042.

### Format

```
no vlan <1-4042>
```

### Mode

```
VLAN database
```

## 4.9.106vlan0-transparent-mode

Activate the “Transparent Mode“ to be able to switch priority tagged frames without a VLAN affiliation thus with VLAN-ID “0”.

In this mode the VLAN-ID “0” persists in the frame, irrespective of the Port VLAN ID setting in the “VLAN Port“ dialog.

**Note:** For PowerMICE, MACH100, MACH1000 and MACH4000:

In transparency mode devices ignore received vlan tags. Set the vlan membership of the ports to untagged for all vlans.

**Note:** For RS20/RS30/RS40, MS20/MS30 and OCTOPUS:

In transparency mode devices ignore the configured port vlan id. Set the vlan membership of the ports from vlan 1 to untagged or member.

### Format

```
vlan0-transparent-mode {disable|enable}
```

### Mode

```
VLAN database
```

## 4.9.107vlan acceptframe

This command sets the frame acceptance mode per interface. For VLAN Only mode, untagged frames or priority frames received on this interface are discarded. For Admit All mode, untagged frames or priority frames received on this interface are accepted and assigned the value of the interface VLAN ID for this port. With either option, VLAN tagged frames are forwarded in accordance with the IEEE 802.1Q VLAN Specification.

### Default

```
Admit All
```

### Format

```
vlan acceptframe <vlanonly | all | untaggedonly>
```

### Mode

```
Interface Config
```

### all

Untagged frames or priority frames received on this interface are accepted and assigned the value of the interface VLAN ID for this port.

### vlanonly

Only frames received with a VLAN tag will be forwarded. Other frames will be dropped.

### untaggedonly

Only frames received without a VLAN tag will be forwarded. Other frames will be dropped.

**Note:** This command is available for devices of the RS20/RS30/RS40, MS20/MS30, MACH102, RSR20/RSR30, MACH1020/MACH1030 and OCTOPUS family.

**■ no vlan acceptframe**

This command sets the frame acceptance mode per interface to `Admit All`. For `Admit All` mode, untagged frames or priority frames received on this interface are accepted and assigned the value of the interface VLAN ID for this port. With either option, VLAN tagged frames are forwarded in accordance with the IEEE 802.1Q VLAN Specification.

**Format**

```
no vlan acceptframe
```

**Mode**

```
Interface Config
```

**4.9.108vlan database**

This command switches into the global VLAN mode.

**Default**

```
Admit All
```

**Format**

```
vlan database
```

**Mode**

```
Privileged EXEC
```

## 4.9.109vlan ingressfilter

This command enables ingress filtering. If ingress filtering is disabled, frames received with VLAN IDs that do not match the VLAN membership of the receiving interface are admitted and forwarded to ports that are members of that VLAN.

### Default

disabled

### Format

vlan ingressfilter

### Mode

Interface Config

### ■ no vlan ingressfilter

This command disables ingress filtering. If ingress filtering is disabled, frames received with VLAN IDs that do not match the VLAN membership of the receiving interface are admitted and forwarded to ports that are members of that VLAN.

### Format

no vlan ingressfilter

### Mode

Interface Config

## 4.9.110vlan name

This command changes the name of a VLAN. The name is an alphanumeric string of up to 32 characters, and the ID is a valid VLAN identification number. ID range is 1-4042.

### Default

The name for VLAN ID 1 is always Default. The name for other VLANs is defaulted to a blank string.

### Format

```
vlan name <1-4042> <newname>
```

### Mode

```
VLAN database
```

### ■ no vlan name

This command sets the name of a VLAN to a blank string. The VLAN ID is a valid VLAN identification number. ID range is 1-4042.

### Format

```
no vlan name <1-4042>
```

### Mode

```
VLAN database
```



## 4.9.11 vlan participation

This command configures the degree of participation for a specific interface in a VLAN. The ID is a valid VLAN identification number, and the interface is a valid interface number .

### Format

```
vlan participation  
    <exclude | include | auto> <1-4042>
```

### Mode

```
Interface Config
```

Participation options are:

#### include

The interface is always a member of this VLAN. This is equivalent to registration fixed.

#### exclude

The interface is never a member of this VLAN. This is equivalent to registration forbidden.

#### auto

The interface is dynamically registered in this VLAN by GVRP. The interface will not participate in this VLAN unless a join request is received on this interface. This is equivalent to registration normal.

## 4.9.112vlan participation all

This command configures the degree of participation for all interfaces in a VLAN. The ID is a valid VLAN identification number.

### Format

```
vlan participation all <exclude | include | auto>  
<1-4042>
```

### Mode

Global Config

Participation options are:

#### **include**

The interface is always a member of this VLAN. This is equivalent to registration fixed.

#### **exclude**

The interface is never a member of this VLAN. This is equivalent to registration forbidden.

#### **auto**

The interface is dynamically registered in this VLAN by GVRP. The interface will not participate in this VLAN unless a join request is received on this interface. This is equivalent to registration normal.

## 4.9.113vlan port acceptframe all

This command sets the frame acceptance mode for all interfaces. For VLAN Only mode, untagged frames or priority frames received on this interface are discarded. For Admit All mode, untagged frames or priority frames received on this interface are accepted and assigned the value of the interface VLAN ID for this port. With either option, VLAN tagged frames are forwarded in accordance with the IEEE 802.1Q VLAN Specification.

### Default

```
Admit All
```

### Format

```
vlan port acceptframe all <vlanonly | all>
```

### Mode

```
Global Config
```

### ■ no vlan port acceptframe all

This command sets the frame acceptance mode for all interfaces to Admit All. For Admit All mode, untagged frames or priority frames received on this interface are accepted and assigned the value of the interface VLAN ID for this port. With either option, VLAN tagged frames are forwarded in accordance with the IEEE 802.1Q VLAN Specification.

### Format

```
no vlan port acceptframe all
```

### Mode

```
Global Config
```

### 4.9.114 **vlan port ingressfilter all**

This command enables ingress filtering for all ports. If ingress filtering is disabled, frames received with VLAN IDs that do not match the VLAN membership of the receiving interface are admitted and forwarded to ports that are members of that VLAN.

#### **Default**

disabled

#### **Format**

```
vlan port ingressfilter all
```

#### **Mode**

Global Config

### ■ **no vlan port ingressfilter all**

This command disables ingress filtering for all ports. If ingress filtering is disabled, frames received with VLAN IDs that do not match the VLAN membership of the receiving interface are admitted and forwarded to ports that are members of that VLAN.

#### **Format**

```
no vlan port ingressfilter all
```

#### **Mode**

Global Config

### 4.9.115vlan port pvid all

This command changes the VLAN ID for all interface.

#### Default

1

#### Format

```
vlan port pvid all <1-4042>
```

#### Mode

Global Config

#### ■ no vlan port pvid all

This command sets the VLAN ID for all interfaces to 1.

#### Format

```
no vlan port pvid all <1-4042>
```

#### Mode

Global Config

### 4.9.116vlan port tagging all

This command configures the tagging behavior for all interfaces in a VLAN to enabled. If tagging is enabled, traffic is transmitted as tagged frames. If tagging is disabled, traffic is transmitted as untagged frames. The ID is a valid VLAN identification number.

#### Format

```
vlan port tagging all <1-4042>
```

#### Mode

```
Global Config
```

#### ■ no vlan port tagging all

This command configures the tagging behavior for all interfaces in a VLAN to disabled. If tagging is disabled, traffic is transmitted as untagged frames. The ID is a valid VLAN identification number.

#### Format

```
no vlan port tagging all <1-4042>
```

#### Mode

```
Global Config
```

## 4.9.117vlan pvid

This command changes the VLAN ID per interface.

### Default

1

### Format

```
vlan pvid <1-4042>
```

### Mode

Interface Config

### ■ no vlan pvid

This command sets the VLAN ID per interface to 1.

### Format

```
no vlan pvid <1-4042>
```

### Mode

Interface Config

## 4.9.118vlan tagging

This command configures the tagging behavior for a specific interface in a VLAN to enabled. If tagging is enabled, traffic is transmitted as tagged frames. If tagging is disabled, traffic is transmitted as untagged frames. The ID is a valid VLAN identification number.

### Format

```
vlan tagging <1-4042>
```

### Mode

```
Interface Config
```

### ■ no vlan tagging

This command configures the tagging behavior for a specific interface in a VLAN to disabled. If tagging is disabled, traffic is transmitted as untagged frames. The ID is a valid VLAN identification number.

### Format

```
no vlan tagging <1-4042>
```

### Mode

```
Interface Config
```



## 4.9.119 voice vlan (Global Config Mode)

This command enables the Voice VLAN feature.

Voice VLAN is a feature used to automatically separate voice and data traffic on a port, by VLAN and/or priority. A primary benefit of using Voice VLAN is to ensure that the sound quality of an IP phone is safeguarded from deteriorating when the data traffic on the port is high.

### Default

Disabled

### Format

```
voice vlan
```

### Mode

Global Config

### ■ no voice vlan

This command disables the Voice VLAN feature.

### Default

Disabled

### Format

```
no voice vlan
```

### Mode

Global Config

### 4.9.120 voice vlan <id>

Use this command to configure VLAN tagging and 802.1p priority.

#### Format

```
voice vlan <id> [dot1p <priority>] }
```

#### Mode

Interface Config

#### <id>

Enter the Voice VLAN ID.

#### dot1p

Configure Voice VLAN 802.1p priority tagging for voice traffic.

#### <priority>

The priority tag range is 0–7.

#### ■ no voice vlan

This command disables the Voice VLAN feature on the interface.

#### Default

Disabled

#### Format

```
no voice vlan
```

#### Mode

Interface Config

### 4.9.121 voice vlan dot1p

Use this command to configure Voice VLAN 802.1p priority tagging for voice traffic.

#### Format

```
voice vlan dot1p <priority>
```

#### Mode

```
Interface Config
```

#### <priority>

Configure Voice VLAN 802.1p priority tagging for voice traffic.  
The priority tag range is 0–7.

### 4.9.122 voice vlan none

Use this command to allow the IP phone to use its own configuration to send untagged voice traffic.

#### Format

```
voice vlan none
```

#### Mode

```
Interface Config
```

### 4.9.123 voice vlan untagged

Use this command to configure the phone to send untagged voice traffic.

#### Format

```
voice vlan untagged
```

#### Mode

```
Interface Config
```

### 4.9.124 voice vlan auth

Use this command to set Voice VLAN Authentication Mode. If disabled, VOIP devices which are detected via LLDP-med will have access to the Voice VLAN without authentication.

#### Default

```
Enabled
```

#### Format

```
voice vlan auth [enabled | disabled]
```

#### Mode

```
Interface Config
```

#### disable

VOIP devices which are detected via LLDP-MED will have access to the Voice VLAN without authentication.

#### enable

VOIP devices which are detected via LLDP-MED will not have access to the Voice VLAN without authentication.

## 4.10 User Account Management Commands

These commands manage user accounts.

### 4.10.1 disconnect

This command closes a telnet session.

#### Format

```
disconnect {<sessionID> | all}
```

#### Mode

```
Privileged EXEC
```

#### Session ID

Enter the session ID (1-11).

## 4.10.2 show loginsession

This command displays current telnet and serial port connections to the switch.

### Format

```
show loginsession
```

### Mode

Privileged EXEC and User EXEC

### ID

Login Session ID

### User Name

The name the user will use to login using the serial port or Telnet. A new user may be added to the switch by entering a name in a blank entry. The user name may be up to 8 characters, and is not case sensitive. Two users are included as the factory default, 'admin' and 'user'.

### Connection From

IP address of the telnet client machine or EIA-232 for the serial port connection.

### Idle Time

Time this session has been idle.

### Session Time

Total time this session has been connected.

### 4.10.3 show users

This command displays the configured user names and their settings. This command is only available for users with readwrite privileges. The SNMPv3 fields will only be displayed if SNMP is available on the system.

#### Format

```
show users
```

#### Mode

```
Privileged EXEC
```

#### User Name

The name the user will use to login using the serial port, Telnet or Web. A new user may be added to the switch by entering a name in a blank entry. The user name may be up to eight characters, and is not case sensitive. Two users are included as the factory default, 'admin' and 'user'

#### Access Mode

Shows whether the operator is able to change parameters on the switch (Read/Write) or is only able to view them (Read Only). As a factory default, the 'admin' user has Read/Write access and the 'user' has Read Only access. There can only be one Read/Write user and up to five Read Only users.

#### SNMPv3 AccessMode

This field displays the SNMPv3 Access Mode. If the value is set to ReadWrite, the SNMPv3 user will be able to set and retrieve parameters on the system. If the value is set to ReadOnly, the SNMPv3 user will only be able to retrieve parameter information. The SNMPv3 access mode may be different than the CLI and Web access mode.

#### SNMPv3 Authentication

This field displays the authentication protocol to be used for the specified login user.

#### SNMPv3 Encryption

This field displays the encryption protocol to be used for the specified login user.

### 4.10.4 users defaultlogin

This command assigns the authentication login list to use for non-configured users when attempting to log in to the system. This setting is overridden by the authentication login list assigned to a specific user if the user is configured locally. If this value is not configured, users will be authenticated using local authentication only.

#### Format

```
users defaultlogin <listname>
```

#### Mode

```
Global Config
```

#### listname

Enter an alphanumeric string of not more than 15 characters.



### 4.10.5 users login <user>

Enter user name.

#### Format

```
users login <user> <listname>
```

#### Mode

```
Global Config
```

#### Note:

When assigning a list to the 'admin' account, include an authentication method that allows administrative access even when remote authentication is unavailable (use 'authentication login <listname> [method1 [method2 [method3]]]').

### ■ no users login <user>

This command removes an operator.

#### Format

```
no users login <user> <listname>
```

#### Mode

```
Global Config
```

#### Note:

The 'admin' user account cannot be deleted.

### 4.10.6 users access

This command sets access for a user: readonly/readwrite.

#### Format

```
users access <username> {readonly | readwrite}
```

#### Mode

Global Config

#### <username>

Enter a name up to 32 alphanumeric characters in length.

#### readonly

Enter the access mode as readonly.

#### readwrite

Enter the access mode as readwrite.

#### ■ no users access

This command deletes access for a user.

#### Format

```
no users access <username>
```

#### Mode

Global Config

## 4.10.7 users name

This command adds a new user (account) if space permits. The account <username> can be up to eight characters in length. The name may be comprised of alphanumeric characters as well as the dash ('-') and underscore ('\_'). The <username> is not case-sensitive.

Six user names can be defined.

### Format

```
users name <username>
```

### Mode

```
Global Config
```

### ■ no users name

This command removes an operator.

### Format

```
no users name <username>
```

### Mode

```
Global Config
```

### Note:

The 'admin' user account cannot be deleted.

## 4.10.8 users passwd

This command is used to change a password. The password should not be more than eight alphanumeric characters in length. If a user is authorized for authentication or encryption is enabled, the password must be at least eight alphanumeric characters in length. The username and password are case-sensitive. When a password is changed, a prompt will ask for the former password. If none, press enter.

**Note:** Make sure, that the passwords of the users differ from each other. If two or more users try to choose the same password, the CLI will display an error message.

### Default

No Password

### Format

```
users passwd <username> {<password>}
```

### Mode

Global Config

### ■ no users passwd

This command sets the password of an existing operator to blank. When a password is changed, a prompt will ask for the operator's former password. If none, press enter.

### Format

```
no users passwd <username> {<password>}
```

### Mode

Global Config

### 4.10.9 users snmpv3 accessmode

This command specifies the snmpv3 access privileges for the specified login user. The valid accessmode values are `readonly` or `readwrite`. The `<username>` is the login user name for which the specified access mode applies. The default is `readwrite` for 'admin' user; `readonly` for all other users

#### Default

```
admin -- readwrite; other -- readonly
```

#### Format

```
users snmpv3 accessmode <username> <readonly |  
readwrite>
```

#### Mode

```
Global Config
```

#### ■ no users snmpv3 accessmode

This command sets the snmpv3 access privileges for the specified login user as `readwrite` for the 'admin' user; `readonly` for all other users. The `<username>` is the login user name for which the specified access mode will apply.

#### Format

```
no users snmpv3 accessmode <username>
```

#### Mode

```
Global Config
```

## 4.10.10 users snmpv3 authentication

This command specifies the authentication protocol to be used for the specified login user. The valid authentication protocols are `none`, `md5` or `sha`. If `md5` or `sha` are specified, the user login password is also used as the snmpv3 authentication password and therefore must be at least eight characters in length. The `<username>` is the login user name associated with the authentication protocol.

### Default

```
no authentication
```

### Format

```
users snmpv3 authentication <username> <none | md5  
| sha>
```

### Mode

```
Global Config
```

### ■ no users snmpv3 authentication

This command sets the authentication protocol to be used for the specified login user to `none`. The `<username>` is the login user name for which the specified authentication protocol will be used.

### Format

```
users snmpv3 authentication <username>
```

### Mode

```
Global Config
```

## 4.10.11 users snmpv3 encryption

This command specifies the encryption protocol to be used for the specified login user. The valid encryption protocols are `des` or `none`.

If `des` is specified, the required key may be specified on the command line. The `key` may be up to 16 characters long. If the `des` protocol is specified but a key is not provided, the user will be prompted for the key. When using the `des` protocol, the user login password is also used as the `snmpv3` encryption password and therefore must be at least eight characters in length.

If `none` is specified, a key must not be provided. The `<username>` is the login user name associated with the specified encryption.

### Default

```
no encryption
```

### Format

```
users snmpv3 encryption <username> <none |  
des[key]>
```

### Mode

```
Global Config
```

### ■ no users snmpv3 encryption

This command sets the encryption protocol to `none`. The `<username>` is the login user name for which the specified encryption protocol will be used.

### Format

```
no users snmpv3 encryption <username>
```

### Mode

```
Global Config
```

## 4.11 System Utilities

This section describes system utilities.

### 4.11.1 address-conflict

This command configures the setting for detection possible address conflicts of the agent's IP address with other devices' IP addresses in the network.

#### Format

```
address-conflict
  {detection-mode { active-only | disable |
  enable | passive-only}|
  ongoing-detection { disable | enable } }
```

#### Mode

Global Config

#### detection mode

Configure the device's address conflict detection mode (active-only, disable, enable or passive-only). Default: enable.

#### ongoing detection

Disable or enable the ongoing address conflict detection.  
Default: enable.



## 4.11.2 boot skip-aca-on-boot

Use this command to skip external memory (AutoConfiguration Adapter ACA21) during boot phase to shorten startup duration. The ACA21 functionality will be available after the boot phase.

### Format

```
boot skip-aca-on-boot {disable | enable}
```

### Mode

```
Global Config
```

### Default

```
disabled
```

### enable

Enable ACA21 skip during boot phase.

### disable

Disable ACA21 skip during boot phase.

## 4.11.3 show boot skip-aca-on-boot

Use this command display the status of the option of skipping external memory (AutoConfiguration Adapter ACA21) during boot phase.

### Format

```
show boot skip-aca-on-boot
```

### Mode

```
Global Config
```

### Default

```
disabled
```

### Enabled

ACA21 skip during boot phase is enabled.

### Disabled

ACA21 skip during boot phase is disabled.

### 4.11.4 cablestatus

This command tests the cable attached to an interface for short or open circuit. During the test the traffic is interrupted on this port.

**Format**

```
cablestatus <slot/port>
```

**Mode**

Privileged EXEC

### 4.11.5 clear eventlog

Clear the event log. The CLI will ask for confirmation.

Answer `y` (yes) or `n` (no).

The CLI displays the end of this operation.

**Format**

```
clear eventlog
```

**Mode**

Privileged EXEC

## 4.11.6 traceroute

This command is used to discover the routes that packets actually take when traveling to their destination through the network on a hop-by-hop basis.

<ipaddr> should be a valid IP address.

The optional port parameter is the UDP port used as the destination of packets sent as part of the traceroute. This port should be an unused port on the destination system. [port] should be a valid decimal integer in the range of 0 (zero) to 65,535. The default value is 33,434.

### Format

```
traceroute <ipaddr> [port]
```

### Mode

Privileged EXEC

## 4.11.7 clear arp-table-switch

This command clears the agent's ARP table (cache).

### Format

```
clear arp-table-switch
```

### Mode

Privileged EXEC

### 4.11.8 clear config

This command resets the configuration in RAM to the factory defaults without powering off the switch.

**Format**

```
clear config
```

**Mode**

```
Privileged EXEC
```

### 4.11.9 clear config factory

This command resets the whole configuration to the factory defaults. Configuration data and scripts stored in nonvolatile memory will also be deleted.

**Format**

```
clear config factory
```

**Mode**

```
Privileged EXEC
```

### 4.11.10 clear counters

This command clears the stats for a specified <slot/port> or for all the ports or for the entire switch based upon the argument.

**Format**

```
clear counters {<slot/port> | all}
```

**Mode**

```
Privileged EXEC
```

### **4.11.11 clear hiper-ring**

This command clears the HIPER Ring configuration (deletes it).

#### **Format**

```
clear hiper-ring
```

#### **Mode**

```
Privileged EXEC
```

### **4.11.12 clear igmpsnooping**

This command clears the tables managed by the IGMP Snooping function and will attempt to delete these entries from the Multicast Forwarding Database.

#### **Format**

```
clear igmpsnooping
```

#### **Mode**

```
Privileged EXEC
```

### 4.11.13 clear mac-addr-table

This command clears the switch's MAC address table (the forwarding database that contains the learned MAC addresses).

**Note:** this command does not affect the MAC filtering table.

#### Format

```
clear mac-addr-table
```

#### Mode

Privileged EXEC

### 4.11.14 clear pass

This command resets all user passwords to the factory defaults without powering off the switch. You are prompted to confirm that the password reset should proceed.

#### Format

```
clear pass
```

#### Mode

Privileged EXEC

### **4.11.15clear link-aggregation**

This command clears all link-aggregations (LAGs).

#### **Format**

```
clear link-aggregation
```

#### **Mode**

```
Privileged EXEC
```

### **4.11.16clear signal-contact**

This command clears the signal-contact output configuration.

Switches the signal contact 1's mode to `auto` and its manual setting to `open`.

Switches the signal contact 2's mode to `manual` and its manual setting to `closed`.

Enables the monitoring of the power supplies for signal contact 1 only.

Disables the sending of signal contact traps.

#### **Format**

```
clear signal-contact
```

#### **Mode**

```
Privileged EXEC
```

### **4.11.17clear traplog**

This command clears the trap log.

#### **Format**

```
clear traplog
```

#### **Mode**

Privileged EXEC

### **4.11.18clear ring-coupling**

This command clears the ring-coupling configuration.

#### **Format**

```
clear ring-coupling
```

#### **Mode**

Privileged EXEC

### **4.11.19clear vlan**

This command resets VLAN configuration parameters to the factory defaults.

#### **Format**

```
clear vlan
```

#### **Mode**

Privileged EXEC



## 4.11.20 config-watchdog

If the function is enabled and the connection to the switch is interrupted for longer than the time specified in “timeout [s]”, the switch then loads the last configuration saved.

### Format

```
config-watchdog {admin-state {disable|enable}}
timeout <10..600>
```

### Mode

Global Config

### admin-state

Enable or disable the Auto Configuration Undo feature (default: disabled).

### timeout

Configure the Auto Configuration Undo timeout (unit: seconds).

## 4.11.21 copy

This command uploads and downloads to/from the switch. Remote URLs can be specified using ftp.

`copy` (without parameters) displays a brief explanation of the most important copy commands. A list of valid commands is provided below.

The command can be used to save the running configuration to nvram by specifying the source as `system:running-config` and the destination as `nvram:startup-config`.

### Default

none

### Format

```
copy
copy aca:script <sourcefilename> nvram:script
    [targetfilename]
copy aca:capturefilter <sourcefilename>
    nvram:capturefilter [targetfilename]
```

```
copy aca:sfp-white-list <sourcefilename>
  nvram:sfp-white-list
copy nvram:backup-image system:image
copy nvram:clibanner <url>
copy nvram:capture aca:capture
copy nvram:capture <url>
copy nvram:capturefilter <sourcefilename>
  aca:capturefilter <targetfilename>
copy nvram:capturefilter <sourcefilename>
copy nvram:errorlog <url>
copy nvram:script <sourcefilename> aca:script
  [targetfilename]
copy nvram:script <sourcefilename> <url>
copy nvram:startup-config <url>
copy nvram:startup-config system:running-config
copy nvram:traplog <url>
copy system:running-config nvram:startup-config
<url>
copy system:running-config <url>
copy <tftp://ip/filepath/fileName>
  nvram:sfp-white-list
copy tftp://<server_ip>/<path_to_pem>
  nvram:https-cert
copy <url> nvram:clibanner
copy <url> nvram:capturefilter <destfilename>
copy aca:capturefilter <sourcefilename>
  nvram:capturefilter <destfilename>
copy <url> nvram:script <destfilename>
copy <url> nvram:startup-config
copy <url> system:image
copy <url> system:running-config
copy <url> system:bootcode
```

**Mode**

Privileged EXEC

■ **copy aca:script <sourcefilename>  
nvram:script [targetfilename]**

Copies the script from the Auto Configuration Adapter.

- `sourcefilename`: Filename of source configuration Script. File-name length may be max. 20 characters, including extension '.cli' or '.CLI'.
- `targetfilename`: Filename on the switch's NVRAM. Filename length may be max. 20 characters, including extension '.cli'.

■ **copy aca:capturefilter <sourcefilename>  
nvram:capturefilter [targetfilename]**

Copies a capture filter file from the Auto Configuration Adapter.

- `sourcefilename`: Filename of source capture filter expressions file.
- `targetfilename`: Filename on the switch's NVRAM.

■ **copy aca:sfp-white-list <sourcefilename>  
nvram:sfp-white-list**

Use this command to load the SFP white list file from a ACA21.

**Note:** In order to delete the SFP white list file from the flash memory: use the command `clear sfp-white-list`.

The `clear config factory` command deletes the SFP white list, too.

■ **copy nvram:backup-image system:image**

Use this command to swap current and backup images. The backup image (backup.bin) and current image (main.bin) will exchange the file name, after reboot the both OS and configuration files will be swapped.

**■ copy <tftp://ip/filepath/fileName> nvram:sfp-white-list**

Use this command to load the SFP white list file from a TFTP server.

**Note:** In order to delete the SFP white list file from the flash memory: use the command `clear sfp-white-list`.

The `clear config factory` command deletes the SFP white list, too.

**■ copy tftp://<server\_ip>/<path\_to\_pem> nvram:https-cert**

Use this command for uploading a PEM certificate for HTTPS over TFTP

**Note:** Reboot the device or re-enable the HTTPS server after uploading a PEM certificate.

**■ copy nvram:clibanner <url>**

Downloads the CLI banner file via TFTP using <tftp://ip/filepath/fileName>.

**■ copy nvram:capture aca:capture**

Save the internal packet capture file to the Auto Configuration Adapter ACA21 (file name: "capture.cap").

**■ copy nvram:capture <url>**

Save the internal packet capture file to a tftp URL using <tftp://ip/filepath/fileName>.

■ **copy nvram:capturefilter <sourcefilename>  
aca:capturefilter <targetfilename>**

Save a capture filter file from the flash memory to the Auto Configuration Adapter.

- sourcefilename: Filename of source capture filter expressions file.
- targetfilename: Filename of target capture filter expressions file.

■ **copy nvram:capturefilter <sourcefilename> <url>**

Save the internal packet capture filter file from the flash memory to a tftp URL using <tftp://ip/filepath/fileName>.

- sourcefilename: Filename of source capture filter expressions file.

■ **copy nvram:errorlog <url>**

Uploads Errorlog file.

- <url>: Uploads Error log file using <tftp://ip/filepath/fileName>.

■ **copy nvram:script <sourcefilename>  
aca:script [targetfilename]**

Uploads configuration script file. Save the script to the AutoConfiguration Adapter.

- sourcefilename: Filename length may be max. 20 characters, including extension '.cli' or '.CLI'.
- targetfilename: Filename length may be max. 20 characters, including extension '.cli' or '.CLI'.

■ **copy nvram:script <sourcefilename> <url>**

Uploads Configuration Script file using <tftp://ip/filepath/fileName>. Filename length may be max. 20 characters, including extension '.cli'.

- sourcefilename: Filename length may be max. 20 characters, including extension '.cli' or '.CLI'.

**■ copy nvram:startup-config <url>**

Uploads config file using <tftp://ip/filepath/fileName>.

**■ copy nvram:startup-config system:running-config**

Uploads/Copies config file. The target is the currently running configuration.

**■ copy nvram:traplog <url>**

Uploads Trap log file. Uploads Trap log file using <tftp://ip/filepath/fileName>.

**■ copy system:running-config nvram:startup-config**

Copies system config file. Save the running configuration to NVRAM.

**■ copy system:running-config <url>**

Copies system config file. Uploads system running-config via tftp using <tftp://ip/filepath/fileName>.

### ■ **copy <url> nvram:clibanner**

This feature provides a privileged user the capability to change the CLI default banner:

```
-----
Copyright (c) 2004-2010 <Company Name>
```

```

    All rights reserved
```

```

    <Product Name> Release L3P-06.0.00
```

```

    (Build date 2010-05-01 00:30)
```

```

    System Name:   <Product Name>-518280
```

```

    Mgmt-IP       :   a.b.c.d
```

```

    1.Router-IP   :   0.0.0.0
```

```

    Base-MAC      :   aa:bb:cc:dd:ee:ff
```

```

    System Time:  2010-01-02 05:51:11
-----
```

The command uploads the CLI Banner file by tftp using <tftp://ip/filepath/fileName>.

After the upload you logout from CLI and the new CLI banner file will be displayed at the next login.

- `url`: Upload CLI banner file using <tftp://ip/filepath/fileName>.

If no cli banner file is defined, the default cli banner is displayed (see above).

**Note:** See that the the CLI banner file you created has the following properties:

- Use ASCII format (character codes 0x20 .. 0x7F, \n and \t as C-like sequences)
- Do not use regular expressions
- Do not exceed the limit of 2048 byte
- Do not exceed the limit of 20 lines
- Do not exceed the limit of 80 characters per line
- A device can only have one banner file at the moment
- Save the CLI banner file as \*.bnr.

**■ no clibanner**

This command deletes an existing CLI banner file.

**■ copy <url> nvram:capturefilter <destfilename>**

Load a Capture Filter file from a tftp URL into the flash memory using <tftp://ip/filepath/fileName>.

– *destfilename*: Destination filename of capture filter expressions file.

**■ copy aca:capturefilter <sourcefilename>  
nvram:capturefilter <targetfilename>**

Load a capture filter file from AutoConfiguration Adapter ACA21 into the flash memory.

– *sourcefilename*: Filename of source capture filter expressions file.

– *targetfilename*: Specify the file name on the switch's NVRAM.

**■ copy <url> nvram:script <destfilename>**

Downloads Configuration Script file using <tftp://ip/filepath/fileName>.

– *destfilename*: Filename length may be max. 20 characters, including extension '.cli' or '.CLI'.

**■ copy <url> nvram:sshkey-dsa**

Downloads IP secure shell (SSH) DSA key file by tftp using <tftp://ip/filepath/fileName>.

**■ copy <url> nvram:sshkey-rsa1**

Downloads IP secure shell (SSH) RSA1 key file by tftp using <tftp://ip/filepath/fileName>.



**■ copy <url> nvram:sshkey-rsa2**

Downloads IP secure shell (SSH) RSA2 key file by tftp using <tftp://ip/filepath/fileName>.

**■ copy <url> nvram:startup-config**

Downloads Config file by tftp using <tftp://ip/filepath/fileName>.

**■ copy <url> system:image**

Downloads code file by tftp using <tftp://ip/filepath/fileName>.

**■ copy <url> system:running-config**

Downloads Code/Config file using <tftp://ip/filepath/fileName>. The target is the currently running configuration.

**■ copy <url> system:bootcode**

Use the "copy <url> system:bootcode" command to load the bootcode file via tftp into the device. For <url> enter the path of the tftp server using the following notation: "<tftp://ip/filepath/fileName>", e.g. "tftp://10.1.112.214/switch/switch01.cfg".

**■ clear sfp-white-list**

Use this command to delete the SFP white list file from the flash memory.

**Note:** The `clear config factory` command deletes the SFP white list, too.

## 4.11.22 device-status connection-error

This command configures the device status link error monitoring for this port.

### Default

ignore

### Format

```
device-status connection-error {ignore|propagate}
```

### Mode

Interface Config

## 4.11.23 device-status monitor

This command configures the device-status.

### Format

```
device-status monitor
  {aca-removal | all | connection-error |
  hiper-ring |
  module-removal | power-supply-1 |
  power-supply-2 | power-supply-3-1 |
  power-supply-3-2 | power-supply-4-1 |
  power-supply-4-2 | ring-coupling | temperature }
  {error|ignore}
device-status trap {disable|enable}
```

### Mode

Global Config

### monitor

Determines the monitoring of the selected event or all events.

- `error` If the given event signals an error, the device state will also signal `error`,
- `ignore` Ignore the given event - even if it signals an error, the device state will not signal 'error' because of that.

### trap

Configure if a trap is sent when the device status changes its state.

- `enable` enables sending traps,
- `disable` disables sending traps.

## 4.11.24logout

This command closes the current telnet connection or resets the current serial connection.

**Note:** Save configuration changes before logging out.

### Format

```
logout
```

### Mode

```
Privileged EXEC
```

## 4.11.25ping

This command checks if another computer is on the network and listens for connections. To use this command, configure the switch for network (in-band) connection. The source and target devices must have the ping utility enabled and running on top of TCP/IP. The switch can be pinged from any IP workstation with which the switch is connected through the default VLAN (VLAN 1), as long as there is a physical path between the switch and the workstation. The terminal interface sends, three pings to the target station.

### Format

```
ping <ipaddr>
```

### Mode

```
Privileged EXEC and User EXEC
```

## 4.11.26 signal-contact connection-error

This command configures the signal contact link error monitoring for this port.

### Format

```
signal-contact connection-error {disable|enable}
```

### Mode

```
Interface Config
```

### disable

A link down event on this port will be not monitored by a signal contact (default).

### enable

A link down event on this port will be monitored by a signal contact.

## 4.11.27 signal-contact

This command configures the signal contacts.

### Format

```
signal-contact {1|2|all}
  {mode {auto|device-status|manual}
  |monitor {aca-removal|
  all|
  connection-error|hiper-ring|module-removal
  |power-supply-1| power-supply-2
  |power-supply-3-1|power-supply-3-2
  |power-supply-4-1|power-supply-4-2
  |ring-coupling|temperature} {disable|enable}
  |state {closed|open}
  |trap {disable|enable} }
```

### Mode

```
Global Config
```

**Contact No.**

Selection of the signal contact:

- 1 signal contact 1,
- 2 signal contact 2,
- all signal contact 1 and signal contact 2.

**mode**

Selection of the operational mode:

- auto function monitoring,
- device-status the device-status determines the signal contact's status.
- manual manually setting the signal contact.

**monitor**

Enables or disables the monitoring of the selected event or all events.

- enable monitoring,
- disable no monitoring.

**state**

Set the manual setting of the signal contact:

- closed ,
- open.

Only takes immediate effect in manual mode.

**trap**

Configures the sending of traps concerning the signal contact.

- enable enables sending traps,
- disable disables sending traps.

## 4.11.28temperature

**Note:** The command is available for RS20/RS30/RS40, MS20/MS30, RSR20/RSR30, MACH100, MACH1000, PowerMICE, MACH4000 and OCTOPUS devices.

This command configures the lower and upper temperature limit for the device. If these limits are exceeded, a trap is sent. The unit for the temperature limit is °C (Celsius), the minimum value is -99, the maximum value is 99. The default for the lower limit is 0, for the upper limit, it is 70.

**Note:** To give the temperature in Fahrenheit, use the suffix f.

### Format

```
temperature {lower-limit|upper-limit} <temperature  
value> [c|f]
```

### Mode

```
Global Config
```

### lower-limit

Configure the lower temperature limit.

### upper-limit

Configure the upper temperature limit.

## 4.11.29reboot

This command resets the switch (cold start) after a given time delay, for warm start See “[reload](#)” on page 322. Reset means that all network connections are terminated and the boot code executes. The switch uses the stored configuration to initialize the switch. You are prompted to confirm that the reset should proceed. A successful reset is indicated by the LEDs on the switch.

### Format

```
reboot {delay <seconds>}
```

### Mode

Privileged EXEC

### <seconds>

The number of seconds after which the switch will reboot.

Value range: None (no reboot scheduled), 0 - 2,147,483 sec (= 596 h + 31 min + 23 sec).

### ■ clear reboot

This command cancels a scheduled reboot.



## 4.11.30 show reboot

This command displays if a reboot is scheduled for the device. If scheduled, the command displays the number of seconds after which the switch will reboot.

### Format

```
show reboot
```

### Modes

```
Privileged EXEC
```

```
User Exec
```

### <seconds>

The number of seconds after which the switch will reboot.

Value range: None (no reboot scheduled), 0 - 2,147,483 sec (= 596 h + 31 min + 23 sec) .

## 4.11.31 reload

This command enables you to reset the switch (warm start) after a given time delay, for cold start [See “reboot” on page 320](#).

**Note:** First, the device is checking the software in the flash memory and then it resets. If a warm start is not possible, the device automatically executes a cold start.

Reset means that all network connections are terminated and the boot code executes. The switch uses the stored configuration to initialize the switch. You are prompted to confirm that the reset should proceed. A successful reset is indicated by the LEDs on the switch.

### Format

```
reload {delay <seconds>}
```

### Mode

```
Privileged EXEC
```

### <seconds>

The number of seconds after which the switch will reload.

Value range: 0 - 2,147,483 sec.

### ■ clear reload

This command cancels a scheduled reload.

## 4.11.32 show reload

This command displays if a reload is scheduled for the device. If scheduled, the command displays the number of seconds after which the switch will reload.

### Format

```
show reload
```

### Modes

```
Privileged EXEC
```

```
User Exec
```

### <seconds>

The number of seconds after which the switch will reload.

Possible values: None (no reload scheduled), 0 - 2,147,483 sec.

## 4.12 LLDP - Link Layer Discovery Protocol

These commands show and configure the LLDP parameters in compliance with IEEE 802.1 AB.

### 4.12.1 show lldp

This command shows all LLDP settings.

#### Format

```
show lldp
```

#### Mode

Privileged EXEC and User EXEC

### 4.12.2 show lldp config

This command shows all LLDP configuration settings.

#### Format

```
show lldp config
```

#### Mode

Privileged EXEC and User EXEC

### 4.12.3 show lldp config chassis

This command shows all LLDP configuration settings concerning the entire device.

**Format**

```
show lldp config chassis
```

**Mode**

Privileged EXEC and User EXEC

### 4.12.4 show lldp config chassis admin-state

Display the LLDP/IEEE802.1AB functionality on this device. If disabled, the LLDP protocol is inactive but the LLDP MIBs can still be accessed.

**Format**

```
show lldp config chassis admin-state
```

**Mode**

Privileged EXEC and User EXEC

### 4.12.5 show lldp config chassis notification-interval

Display the LLDP minimum notification trap interval (unit: seconds).

**Format**

```
show lldp config chassis notification-interval
```

**Mode**

Privileged EXEC and User EXEC

### 4.12.6 show lldp config chassis re-init-delay

Display the LLDP configuration's chassis re-initialization delay (unit: seconds).

#### Format

```
show lldp config chassis re-init-delay
```

#### Mode

Privileged EXEC and User EXEC

### 4.12.7 show lldp config chassis tx-delay

Display the LLDP transmit delay (unit: seconds). It indicates the delay between successive LLDP frame transmissions.

#### Format

```
show lldp config chassis tx-delay
```

#### Mode

Privileged EXEC and User EXEC

### 4.12.8 show lldp config chassis tx-hold-mult

Display the LLDP transmit hold multiplier, a time-to-live value expressed as a multiple of the LLDP Message Tx Interval (tx-interval).

#### Format

```
show lldp config chassis tx-hold-mult
```

#### Mode

Privileged EXEC and User EXEC

## 4.12.9 show lldp config chassis tx-interval

Display the interval (unit: seconds) at which LLDP frames are transmitted on behalf of this LLDP agent.

### Format

```
show lldp config chassis tx-interval
```

### Mode

Privileged EXEC and User EXEC

## 4.12.10 show lldp config port

This command shows all LLDP configuration settings and states concerning one or all ports.

### Format

```
show lldp config port <{slot/port|all}>  
  admin-state | fdb-mode | hm-mode |  
  max-neighbors | notification | tlv
```

### Mode

Privileged EXEC and User EXEC

### admin-state

Display the port's LLDP admin state (if LLDP/IEEE802.1AB frames will be transmitted and/or received).

### fdb-mode

Display the port's LLDP FDB mode.

### hm-mode

Display the port's LLDP Hirschmann mode.

### .max-neighbors

Display the port's max. no. of LLDP neighbors.

### notification

Display the port's LLDP notification (trap) setting.

### tlv

Display the port's LLDP TLV settings (they determine which information is included in the LLDP frames that are sent). The command is a group command and will output several lines of data.



## 4.12.11 show lldp config port tlv

This command shows all LLDP TLV configuration settings (if the given information is included in the sent LLDP frames or not) concerning one or all ports.

### Format

```
show lldp config port <{slot/port|all}> tlv
```

### Mode

Privileged EXEC and User EXEC

### inlinepower

Enable or disable the sending of the port's Power over Ethernet capabilities (PoE, IEEE 802.3af).

**Note:** This command is available for devices supporting PoE.

### link-aggregation

Display the port's LLDP TLV inclusion of Link Aggregation.

### mac-phy-config-state

Display the port's LLDP TLV inclusion of MAC Phy. Cfg. State.

### max-frame-size

Display the port's LLDP TLV inclusion of Max. Frame Size.

### PROFINET IO Status

Display the port's LLDP TLV inclusion of PROFINET IO Status.

### PROFINET IO Alias

Display the port's LLDP TLV inclusion of PROFINET IO Alias.

### PROFINET IO MRP

Display the port's LLDP TLV inclusion of PROFINET IO MRP.

### mgmt-addr

Display the port's LLDP TLV inclusion of Management Address.

### port-desc

Display the port's LLDP TLV inclusion of Port Description.

### port-vlan

Display the port's LLDP TLV inclusion of Port VLAN.

### protocol

Display the port's LLDP TLV inclusion of Protocol.

**sys-cap**

Display the port's LLDP TLV inclusion of System Capabilities.

**sys-desc**

Display the port's LLDP TLV inclusion of System Description.

**sys-name**

Display the port's LLDP TLV inclusion of System Name.

**vlan-name**

Display the port's LLDP TLV inclusion of VLAN Name.

### 4.12.12 show lldp med

Use this command to display a summary of the current LLDP MED global configuration.

**Format**

```
show lldp med
```

**Mode**

Privileged EXEC

**Fast Start Repeat Count**

Display the Fast Start Repeat Count, e.g. the number of LLDP PDUs that will be transmitted when the product is enabled.

The range is 1 to 10.

**Device class**

Display the Device class.

## 4.12.13 show lldp med interface

Use this command to display a summary of the current LLDP MED configuration for a specific interface.

### Format

```
show lldp med interface {<unit/slot/port> | all}
```

### Mode

Privileged EXEC

### <unit/slot/port>

Indicates a specific physical interface.

### all

Indicates all valid LLDP interfaces.

### Interface

Displays the physical interface.

### Link

Displays the link status. Value range: Up, Down.

### configMED

Displays if confignotification for the Media Endpoint Devices is Enabled/Disabled.

### operMED

Displays if operation for the Media Endpoint Devices is Enabled/Disabled.

### ConfigNotify

Displays the ConfigNotify. Value range: Enabled, Disabled.

### TLVsTx

Displays the TLVsTx.

## 4.12.14 show lldp med local-device detail

Use this command to display detailed information about the LLDP MED data that a specific interface transmits. <unit/slot/port> indicates a specific physical interface.

### Format

```
show lldp med local-device detail {<slot/port>}
```

### Mode

Privileged EXEC

### <slot/port>

Indicates a specific physical interface.

### Interface

Displays the physical interface.

### Network Policies

Displays the Network Policies.

### 4.12.15 show lldp med remote-device

Use this command to display the summary information about remote devices that transmit current LLDP MED data to the system. You can show information about LLDP MED remote data received on all valid LLDP interfaces or on a specific physical interface.

#### Format

```
show lldp med remote-device{<slot/port> | all}
```

#### Mode

Privileged EXEC

#### <slot/port>

Indicates a specific physical interface.

#### all

Indicates all valid LLDP interfaces.

#### Local Interface

Displays the local interface.

#### RemotID

Displays the RemotID.

#### Device Class

Displays the Device Class.

## 4.12.16 show lldp med remote-device detail

Use this command to display detailed information about remote devices that transmit current LLDP MED data to an interface on the system.

### Format

```
show lldp med remote-device detail <slot/port>
```

### Mode

Privileged EXEC

### Local Interface

Displays the local interface.

## 4.12.17 show lldp remote-data

This command shows all LLDP remote-data settings and states concerning one or all ports.

### Format

```
show lldp remote-data <{slot/port|all}>  
  chassis-id | detailed | ether-port-info |  
  inlinepower | link-aggregation-info |  
  mgmt-addr | profinetio-port-info |  
  port-desc | port-id | summary | sys-desc |  
  sys-name | vlan-info
```

### Mode

Privileged EXEC and User EXEC

### chassis-id

Display the remote data's chassis ID only.

### detailed

Display remote data in detailed format (i. e., all available data).

**Note:** most important data is output first (not in alphabetic order of command names). This is the default command if no specific command is given.

**ether-port-info**

Display the remote data's port Ethernet properties only (group command, outputs: Port Autoneg. Supported, Port Autoneg. Enabled, Port Autoneg. Advertized Capabilities and Port Operational MAU Type).

**inlinepower**

Displays the remote port's Power over Ethernet capabilities (PoE, IEEE 802.3af). Included are if the remote device is a PSE (Power Source Device) or a PD (Powered Device), if PoE is supported and if the power pairs are selectable.

**link-aggregation-info**

Display the remote data's link aggregation information only (group command, outputs: Link Agg. Status and Link Agg. Port ID).

**mgmt-addr**

Display the remote data's management address only.

**profinetio-port-info**

Display the remote data's Port ProfinetIO properties only.

**port-desc**

Display the port's LLDP TLV inclusion of Port Description.

**port-id**

Display the remote data's port ID only.

**summary**

Display remote data in summary format (table with most important data only, strings will be truncated if necessary, indicated by an appended '>' character).

**sys-desc**

Display the remote data's system description only.

**sys-name**

Display the remote data's system name only.

**vlan-info**

Display the remote data's VLAN information only (group command, outputs: Port VLAN ID, Membership VLAN IDs and their respective names).

## 4.12.18 lldp

Enable/disable the LLDP/IEEE802.1AB functionality on this device. If disabled, the LLDP protocol will become inactive, but the LLDP MIBs can still be accessed. This command is a shorthand notation for `lldp config chassis admin-state {off|on}` (see “[lldp config chassis admin-state](#)” on [page 337](#)).

The default setting is `on`.

### Format

```
lldp
```

### Mode

```
Global Config
```

### ■ no lldp

Disable the LLDP/IEEE802.1AB functionality on this device.

### Format

```
no lldp
```

### Mode

```
Global Config
```



## 4.12.19 lldp config chassis admin-state

Configure the LLDP/IEEE802.1AB functionality on this device. If disabled, the LLDP protocol will become inactive, but the LLDP MIBs can still be accessed.

- ▶ `off`: Disable the LLDP/IEEE802.1AB functionality.
- ▶ `on`: Enable the LLDP/IEEE802.1AB functionality.

The default setting is `on`.

### Format

```
lldp config chassis admin-state {off|on}
```

### Mode

```
Global Config
```

## 4.12.20 lldp config chassis notification-interval

Configure the LLDP minimum notification interval (the minimum time after a notification trap has been sent until a new trap can be sent, unit: seconds, min.: 5 sec., max.: 3600 sec., default: 5 sec.).

### Format

```
lldp config chassis notification-interval  
<notification interval>
```

### Mode

```
Global Config
```

### Notification interval

Configure the LLDP minimum notification interval (the minimum time after a notification trap has been sent until a new trap can be sent, unit: seconds, min.: 5 sec., max.: 3600 sec., default: 5 sec.).

### 4.12.21 lldp config chassis re-init-delay

Configure the LLDP re-initialization delay (unit: seconds, min.: 1 sec., max.: 10 sec., default: 2 sec.).

#### Format

```
lldp config chassis re-init-delay <re-init delay>
```

#### Mode

Global Config

#### Re-init-delay

Configure the LLDP re-initialization delay (unit:seconds, min.: 1 sec., max.: 10 sec., default: 2 sec.).

### 4.12.22 lldp config chassis tx-delay

Configure the LLDP transmit delay, the delay between successive LLDP frame transmissions (unit: seconds, min.: 1 sec., max.: 8192 sec., default: 2 sec.).

#### Format

```
lldp config chassis tx-delay <tx delay>
```

#### Mode

Global Config

#### Tx-delay

Configure the LLDP transmit delay, the delay between successive LLDP frame transmissions (unit: seconds, min.: 1 sec., max.: 8192 sec., default: 2 sec.).

### 4.12.23 lldp config chassis tx-hold-mult

Configure the LLDP transmit hold multiplier, a time-to-live value expressed as a multiple of the LLDP Message Tx Interval (tx-interval), min.: 2, max.: 10, default: 4.

#### Format

```
lldp config chassis tx-hold-mult
                                <tx hold multiplier>
```

#### Mode

Global Config

#### Tx-hold-mult

Configure the LLDP transmit hold multiplier, a time-to-live value expressed as a multiple of the LLDP Message Tx Interval (tx-interval), min.: 2, max.: 10, default: 4.

### 4.12.24 lldp chassis tx-interval

Configure the interval at which LLDP frames are transmitted on behalf of this LLDP agent (unit: seconds, min.: 5 sec., max.: 32768 sec., default: 30 sec.)

#### Format

```
lldp chassis tx-interval <tx interval>
```

#### Mode

Global Config

#### Tx-interval

Configure the interval at which LLDP frames are transmitted on behalf of this LLDP agent (unit: seconds, min.: 5 sec., max.: 32768 sec., default: 30 sec.).

## 4.12.25 clear lldp config all

Clear the LLDP configuration, i. e., set all configurable parameters to default values (all chassis- as well as port-specific parameters at once).

**Note:** LLDP Remote data remains unaffected.

### Format

```
clear lldp config all
```

### Mode

Privileged EXEC

## 4.12.26 lldp admin-state

Configure the port's LLDP admin state (if LLDP/IEEE802.1AB frames will be transmitted to and/or received from the standard IEEE multicast address 01:80:c2:00:00:0e).

The default setting is tx-and-rx.

### Format

```
lldp admin-state <{tx-only|rx-only|tx-and-rx|off}>
```

### Mode

Interface Config

### 4.12.27 lldp fdb-mode

Configure the port's LLDP FDB mode.

The default setting is `autodetect`.

#### Format

```
lldp fdb-mode <{lldp-only|mac-only|lldp-and-  
mac|autodetect}>
```

#### Mode

Interface Config

### 4.12.28 lldp hm-mode

Configure the port's LLDP Hirschmann mode (if LLDP/IEEE802.1AB frames will be transmitted to and/or received from the Hirschmann-specific multicast address 01:80:63:2f:ff:0b).

The default setting is `tx-and-rx`.

#### Format

```
lldp hm-mode <{tx-only|rx-only|tx-and-rx|off}>
```

#### Mode

Interface Config

### 4.12.29lldp max-neighbors

Configure the port's LLDP max. no. of neighbors (min.: 1, max.: 50, default: 10).

#### Format

```
lldp max-neighbors <1..50>
```

#### Mode

```
Interface Config
```

### 4.12.30lldp med

LLDP for Media Endpoint Devices (LLDP-MED) is an extension to LLDP that operates between endpoint devices such as IP phones, Voice / Media Gateways, Media Servers, IP Communications Controllers or other VoIP devices or servers, and network devices such as switches. It specifically provides support for voice over IP (VoIP) applications. In this purpose, it provides an additional set of common advertisement messages (TLVs), for capabilities discovery, network policy, Power over Ethernet, inventory management and location information.

Use this command to enable MED. By enabling MED, you will be effectively enabling the transmit and receive function of LLDP.

#### Default

Enabled

#### Format

```
lldp med
```

#### Mode

Interface Config

#### ■ no lldp med

Use this command to disable MED.

#### Format

```
no lldp med
```

#### Mode

Interface Config

### 4.12.31 lldp med all

Use this command to configure LLDP-MED on all the ports.

#### Default

Enabled

#### Format

```
lldp med all
```

#### Mode

Global Config

### 4.12.32 lldp med confignotification

Use this command to configure all the ports to send the topology change notification.

#### Default

Disabled

#### Format

```
lldp med confignotification
```

#### Mode

Interface Config

### ■ no lldp med confignotification

Use this command to disable notifications.

#### Format

```
no lldp med confignotification
```

#### Mode

Interface Config



### **4.12.33lldp med confignotification all**

Use this command to configure all the ports to send the topology change notification.

**Default**

Disabled

**Format**

```
lldp med confignotification all
```

**Mode**

Global Config

## 4.12.34 lldp med faststartrepeatcount

Use this command to set the value of the fast start repeat count.

### Default

3

### Format

```
lldp med faststartrepeatcount [count]
```

### Mode

Global Config

### [count]

The number of LLDP PDUs that will be transmitted when the product is enabled. The range is 1 to 10.

## ■ no lldp med faststartrepeatcount

Use this command to return to the factory default value.

### Format

```
no lldp med faststartrepeatcount
```

### Mode

Global Config

### 4.12.35 lldp med transmit-tlv

Use this command to specify which optional Type Length Values (TLVs) in the LLDP-MED set will be transmitted in the Link Layer Discovery Protocol Data Units (LLDPDUs).

#### Default

By default, the capabilities and network policy TLVs are included.

#### Format

```
lldp med transmit-tlv [capabilities]
                               [network-policy]
```

#### Mode

Interface Config

#### capabilities

Include/Exclude LLDP capabilities TLV.

#### network-policy

Include/Exclude LLDP network policy TLV.

### ■ no lldp med transmit-tlv

Use this command to remove a TLV.

#### Format

```
no lldp med transmit-tlv [capabilities]
                               [network-policy]
```

#### Mode

Interface Config

## 4.12.36 lldp med transmit-tlv all

Use this command to specify which optional Type Length Values (TLVs) in the LLDP MED set will be transmitted in the Link Layer Discovery Protocol Data Units (LLDPDUs).

### Default

By default, the capabilities and network policy TLVs are included.

### Format

```
lldp med transmit-tlv all [capabilities]
                               [network-policy]
```

### Mode

Global Config

### capabilities

Include/Exclude LLDP capabilities TLV.

### network-policy

Include/Exclude LLDP network policy TLV.

## ■ no lldp med med transmit-tlv all

Use this command to remove a TLV.

### Format

```
no lldp med transmit-tlv all [capabilities]
                               [network-policy]
```

### Mode

Global Config

### 4.12.37 lldp notification

Configure the port's LLDP notification setting (on or off, default: off).

#### Format

```
lldp notification <{off|on}>
```

#### Mode

```
Interface Config
```

### 4.12.38 lldp tlv link-aggregation

Configure the port's LLDP TLV inclusion of Link Aggregation (on or off, default: on).

#### Format

```
lldp tlv link-aggregation <{off|on}>
```

#### Mode

```
Interface Config
```

### 4.12.39 lldp tlv mac-phy-config-state

Configure the port's LLDP TLV inclusion of MAC Phy. Cfg. State (on or off, default: on).

#### Format

```
lldp tlv mac-phy-config-state <{off|on}>
```

#### Mode

```
Interface Config
```

### 4.12.40lldp tlv max-frame-size

Configure the port's LLDP TLV inclusion of Max. Frame Size (on or off, default: on).

#### Format

```
lldp tlv max-frame-size <{off|on}>
```

#### Mode

```
Interface Config
```

### 4.12.41lldp tlv mgmt-addr

Configure the port's LLDP TLV inclusion of Management Address (on or off, default: on).

#### Format

```
lldp tlv mgmt-addr <{off|on}>
```

#### Mode

```
Interface Config
```

### 4.12.42lldp tlv pnio

Configure the port's LLDP TLV inclusion of PROFINET IO Status (on or off, default: on).

#### Format

```
lldp tlv pnio <{off|on}>
```

#### Mode

```
Interface Config
```

### 4.12.43 lldp tlv pnio-alias

Configure the port's LLDP TLV inclusion of PROFINET IO Alias (on or off, default: on).

#### Format

```
lldp tlv pnio-alias <{off|on}>
```

#### Mode

```
Interface Config
```

### 4.12.44 lldp tlv pnio-mrp

Configure the port's LLDP TLV inclusion of PROFINET IO MRP (on or off, default: on).

#### Format

```
lldp tlv pnio-mrp <{off|on}>
```

#### Mode

```
Interface Config
```

### 4.12.45 lldp tlv port-desc

Configure the port's LLDP TLV inclusion of Port Description (on or off, default: on).

#### Format

```
lldp tlv port-desc <{off|on}>
```

#### Mode

```
Interface Config
```

### 4.12.46 lldp tlv port-vlan

Configure the port's LLDP TLV inclusion of Port VLAN (on or off, default: on).

#### Format

```
lldp tlv port-vlan <{off|on}>
```

#### Mode

```
Interface Config
```

### 4.12.47 lldp tlv gmrp

Configure the port's LLDP TLV inclusion of GMRP (on or off, default: on).

#### Format

```
lldp tlv gmrp <{off|on (on)}>
```

#### Mode

```
Interface Config
```

### 4.12.48 lldp tlv igmp

Configure the port's LLDP TLV inclusion of IGMP (on or off, default: on).

#### Format

```
lldp tlv igmp <{off|on (on)}>
```

#### Mode

```
Interface Config
```



### 4.12.49 lldp tlv portsec

Configure the port's LLDP TLV inclusion of PortSec (on or off, default: on).

#### Format

```
lldp tlv portsec <{off|on (on)}>
```

#### Mode

```
Interface Config
```

### 4.12.50 lldp tlv ptp

Configure the port's LLDP TLV inclusion of PTP (on or off, default: on).

#### Format

```
lldp tlv ptp <{off|on (on)}>
```

#### Mode

```
Interface Config
```

### 4.12.51 lldp tlv protocol

Configure the port's LLDP TLV inclusion of Protocol (on or off, default: on).

#### Format

```
lldp tlv protocol <{off|on (on)}>
```

#### Mode

```
Interface Config
```

### 4.12.52 lldp tlv sys-cap

Configure the port's LLDP TLV inclusion of System Capabilities (on or off, default: on).

#### Format

```
lldp tlv sys-cap <{off|on}>
```

#### Mode

```
Interface Config
```

### 4.12.53 lldp tlv sys-desc

Configure the port's LLDP TLV inclusion of System Description (on or off, default: on).

#### Format

```
lldp tlv sys-desc <{off|on}>
```

#### Mode

```
Interface Config
```

### 4.12.54 lldp tlv sys-name

Configure the port's LLDP TLV inclusion of System Name (on or off, default: on).

#### Format

```
lldp tlv sys-name <{off|on}>
```

#### Mode

```
Interface Config
```

## 4.12.55 lldp tlv vlan-name

Configure the port's LLDP TLV inclusion of VLAN Name.

### Format

```
lldp tlv vlan-name <{off|on}>
```

### Mode

```
Interface Config
```

## 4.12.56 name

Set or remove a descriptive name for the current interface (physical ports only).

### Format

```
name <descriptive name>
```

### Mode

```
Interface Config
```

### <descriptive name>

Enter a descriptive name for the current interface (physical ports only). Max. length is 20 characters.

**Note:** If it contains blanks or exclamation marks (!), enclose it in quotation marks ("). The description itself must not contain any quotation marks (' or "), question marks (?) or backslashes (\).

### ■ no name

Delete the descriptive name for the current interface (physical ports only).

### Format

```
no name
```

### Mode

```
Interface Config
```

## 4.13 SNTP - Simple Network Time Protocol

These commands show and configure the SNTP parameters.

### 4.13.1 show sntp

This command shows all SNTP settings.

#### Format

```
show sntp
```

#### Mode

Privileged EXEC and User EXEC

#### SNTP Server Anycast Address

Show SNTP Server Anycast Address (a.b.c.d).

#### SNTP Server Anycast Transmit Interval

Show SNTP Anycast Transmit Interval (in seconds).

#### SNTP Server Anycast VLAN

Show SNTP Server Anycast VLAN.

#### SNTP Server Disable if Timesource is local

Show SNTP Server Disable if Timesource is local (Yes/No).

#### SNTP Client Accepts Broadcasts

Show SNTP Client Accepts Broadcasts (Yes/No).

#### SNTP Client Disable after Synchronization

Show SNTP Client Disable after Synchronization (Yes/No).

#### SNTP Client Request Interval

Show SNTP Client Request Interval (in seconds).

**SNTP Client Local Time Offset**

Show SNTP Client Local Time Offset (in minutes).

**SNTP Client Primary Server IP Address**

Show SNTP Client Primary Server IP Address (a.b.c.d).

**SNTP Client Secondary Server IP Address**

Show SNTP Client Secondary Server IP Address (a.b.c.d).

**SNTP Client Threshold to Server Time**

Show SNTP Client Threshold to Server Time (in milliseconds).

**SNTP Operation Global**

Show SNTP Operation Global (Disabled or Enabled).

**SNTP Operation Server**

Show SNTP Operation Server (Disabled or Enabled).

**SNTP Operation Client**

Show SNTP Operation Client (Disabled or Enabled).

**SNTP Status**

Show SNTP Status

**SNTP Time**

Show SNTP Time (yyyy-mm-dd hh:mm:ss).

**SNTP System Time**

Show SNTP system Time (yyyy-mm-dd hh:mm:ss).

## 4.13.2 show sntp anycast

This command shows all SNTP anycast configuration settings.

### Format

```
show sntp anycast [address|transmit-interval|vlan]
```

### Mode

Privileged EXEC and User EXEC

### address

Show the SNTP server's anycast destination IP Address.

### transmit-interval

Show the SNTP Server's interval for sending Anycast messages (unit: seconds).

### vlan

Show the SNTP server's Anycast VLAN ID (used for sending Anycast messages).

## 4.13.3 show sntp client

This command shows all SNTP anycast configuration settings.

### Format

```
show sntp client [accept-broadcast|
                 disable-after-sync|
                 offset|
                 request-interval|
                 server<primary|secondary>|
                 threshold]
```

### Mode

Privileged EXEC and User EXEC

### accept-broadcast

Show if the SNTP Client accepts SNTP broadcasts.

**disable-after-sync**

Show if the SNTP client will be disabled once it is synchronized to the time server.

**offset**

Show the local time's offset (in minutes) with respect to UTC (positive values for locations east of Greenwich).

**request-interval**

Show the SNTP Client's request interval (unit: seconds).

**server**

Show the SNTP Client's server IP addresses.

**server primary**

Show the SNTP Client's primary server IP addresses.

**server secondary**

Show the SNTP Client's redundant server IP addresses.

**server threshold**

Show the SNTP Client's threshold in milliseconds.

## 4.13.4 show sntp operation

This command shows if the SNTP function is enabled or disabled.

**Format**

```
show sntp operation
```

**Mode**

Privileged EXEC and User EXEC

### 4.13.5 show sntp server

This command shows the SNTP Server's configuration parameters.

#### Format

```
show sntp server [disable-if-local]
```

#### Mode

Privileged EXEC and User EXEC

#### disable-if-local

Show if the server will be disabled if the time is running from the local clock and not synchronized to an external time source.

### 4.13.6 show sntp status

This command shows the SNTP state, synchronization and error messages.

#### Format

```
show sntp status
```

#### Mode

Privileged EXEC and User EXEC



### 4.13.7 show sntp time

This command shows time and date.

**Format**

```
show sntp time [sntp|system]
```

**Mode**

Privileged EXEC and User EXEC

**sntp**

Show the current SNTP date and UTC time.

**system**

Show the local system's current date and time.

### 4.13.8 no sntp

This command disables sntp.

**Format**

```
no sntp
```

**Mode**

Global Config

### 4.13.9 sntp anycast address

Set the SNTP server's anycast destination IP Address, default: 0.0.0.0 (none).

#### Format

```
sntp anycast address <IPAddress>
```

#### Mode

```
Global Config
```

#### ■ no sntp anycast address

Set the SNTP server's anycast destination IP Address to 0.0.0.0.

#### Format

```
no sntp anycast address
```

#### Mode

```
Global Config
```

### 4.13.10 sntp anycast transmit-interval

The transmit interval in seconds, default: 120.

#### Format

```
sntp anycast transmit-interval <1-3600>
```

#### Mode

```
Global Config
```

### 4.13.11 sntp anycast vlan

Set the SNTP server's Anycast VLAN ID used for sending Anycast messages, default: 1.

#### Format

```
sntp anycast vlan <1-4042>
```

#### Mode

```
Global Config
```

### 4.13.12 sntp client accept-broadcast

Enable/Disable that the SNTP Client accepts SNTP broadcasts.

#### Format

```
sntp client accept-broadcast <on | off>
```

#### Mode

```
Global Config
```

#### ■ no sntp accept-broadcast

Disable the SNTP Client accepts SNTP broadcasts.

#### Format

```
no sntp client accept-broadcast
```

#### Mode

```
Global Config
```

### 4.13.13 sntp client disable-after-sync

If this option is activated, the SNTP client disables itself once it is synchronised to a server.

#### Format

```
sntp client disable-after-sync <on | off>
```

#### Mode

Global Config

#### off

Do not disable SNTP client when it is synchronised to a time server.

#### on

Disable SNTP client as soon as it is synchronised to a time server.

### 4.13.14 sntp client offset

The offset between UTC and local time in minutes, default: 60.

#### Format

```
sntp client offset <-1000 to 1000>
```

#### Mode

Global Config

### **4.13.15 sntp client request-interval**

The synchronization interval in seconds, default: 30.

#### **Format**

```
sntp client request-interval <1-3600>
```

#### **Mode**

```
Global Config
```

### **4.13.16 no sntp client server**

Disable the SNTP client servers.

#### **Format**

```
no sntp client server
```

#### **Mode**

```
Global Config
```

### 4.13.17 sntp client server primary

Set the SNTP Client's primary server IP Address, default: 0.0.0.0 (none).

#### Format

```
sntp client server primary <IP-Address>
```

#### Mode

Global Config

#### ■ no sntp client server primary

Disable the primary SNTP client server.

#### Format

```
no sntp client server primary
```

#### Mode

Global Config

### **4.13.18 sntp client server secondary**

Set the SNTP Client's secondary server IP Address, default: 0.0.0.0 (none).

#### **Format**

```
sntp client server secondary <IP-Address>
```

#### **Mode**

```
Global Config
```

#### **■ no sntp client server secondary**

Disable the secondary SNTP client server.

#### **Format**

```
no sntp client server secondary
```

#### **Mode**

```
Global Config
```

## 4.13.19 sntp client threshold

With this option you can reduce the frequency of time alterations. Enter this threshold as a positive integer value in milliseconds. The switch obtains the server timer as soon as the deviation to the server time is above this threshold.

### Format

```
sntp client threshold <milliseconds>
```

### Mode

```
Global Config
```

### Milliseconds

```
Enter the allowed deviation to the server time as a  
positive integer value in milliseconds.
```

### ■ no sntp client threshold

Disable the sntp client threshold.

### Format

```
no sntp client threshold
```

### Mode

```
Global Config
```



## 4.13.20 sntp operation

Enable/Disable the SNTP function.

### Format

```
sntp operation <on | off> |  
                    client { on | off } |  
                    server { on | off }
```

### Mode

Global Config

### client

Enable or disable SNTP Client.

### server

Enable or disable SNTP Server.

### ■ no sntp operation

Disable the SNTP Client and Server.

### Format

```
no sntp operation
```

### Mode

Global Config

### 4.13.21 sntp server disable-if-local

With this option enabled, the switch disables the SNTP Server Function if it is not synchronized to a time server itself.

#### Format

```
sntp server disable-if-local <on | off>
```

#### Mode

Global Config

#### off

Enable the SNTP Server even if it is not synchronized to a time server itself.

#### on

Disable the SNTP Server if it is not synchronized to a time server itself.

### 4.13.22 sntp time system

Set the current sntp time.

#### Format

```
sntp time system <YYYY-MM-DD HH:MM:SS>
```

#### Mode

Global Config

## 4.14 PTP - Precision Time Protocol

These commands show and configure the PTP (IEEE 1588) parameters.

**Note:** The operation parameter is available for all devices. All other parameters are additionally available for MS20/MS30, MACH1040, MACH104 and PowerMICE.

### 4.14.1 show ptp

This command shows all PTP settings.

#### Format

```
show ptp
```

#### Mode

Privileged EXEC and User EXEC

#### PTP (Global) Operation

Show the global PTP (IEEE 1588) operation setting. This field shows if PTP is enabled/disabled on this device.

Possible values: Enabled, Disabled

#### PTP (Global) Clock Mode

Show which PTP clock mode is currently configured.

Possible values: v1-simple-mode, v2-simple-mode, v1-boundary-clock, v2-boundary-clock-onestep, v2-boundary-clock-twostep, v2-transparent-clock}

**PTP (Global) Sync. Upper Bound**

Show the upper bound for the PTP clock synchronization status (unit: nanoseconds).

Possible values: 31..1000000000 nsec

**PTP (Global) Sync. Lower Bound**

Show the lower bound for the PTP clock synchronization status (unit: nanoseconds).

Possible values: 0..999999999 nsec

**PTP Preferred Master**

Show if the local switch shall be regarded as a preferred master clock or not.

Possible values: False, True

**PTP Subdomain Name**

Show the PTP subdomain name.

Possible values: Up to 16 characters from ASCII hex value 0x21 (!) up to and including hex value 0x7e (~).

**PTP Sync. Interval**

Show the configured Precision Time Protocol sync interval.

The sync interval is the interval (in seconds) between successive sync messages issued by a master clock.

Possible values: sec-1, sec-2, sec-8, sec-16, sec-64

**PTP Status, Is Synchronized**

Show if the device is synchronized (true or false).

Possible values: False, True

**PTP Status, Offset From Master**

Show the device's offset from the master (unit: nanoseconds), i.e. the deviation of the local clock from the reference clock.

**PTP Status, Max. Offset Absolute**

Show the device's maximum offset absolute (unit: nanoseconds).

**PTP Status, Delay To Master**

Show the device's delay to the master (unit: nanoseconds), i.e. the single signal runtime between the local device and reference clock.

**PTP Status, Grandmaster UUID**

Show grandmaster Universally Unique Identifier, i.e. the MAC address of the grandmaster clock (Unique Universal Identifier).

Possible values: 32 hexadecimal numbers  
(hh hh hh hh hh hh hh hh).

**PTP Status, Parent UUID**

Show parent Universally Unique Identifier, i.e. the MAC address of the master clock with which the local time is directly synchronized.

Possible values: 32 hexadecimal numbers  
(hh hh hh hh hh hh hh hh).

**PTP Status, Clock Stratum**

Show the qualification of the local clock.

**PTP Status, Clock Identifier**

Show the device's clock properties (e.g. accuracy, epoch, etc.).

**PTPv1 Boundary Clock Ports**

Show port number, operation status, burst status of the PTPv1 Boundary Clock Ports.

**Port**

Show the number of the interface (in `slot/port` notation).

**Operation**

Show if sending and receiving / processing PTP synchronization messages is enabled or disabled on the device.

Possible values: `Enabled`, `Disabled`

**Burst**

Show the status of the burst feature for synchronization running during a synchronization interval.

Possible values: `Enabled`, `Disabled`

**Status**

Show the ports PTP status.

Possible values: `Initializing`, `faulty`, `disabled`, `listening`, `pre-master`, `master`, `passive`, `uncalibrated`, `slave`.

## 4.14.2 show ptp configuration

This command shows the configured PTP (IEEE 1588) values depending on the currently configured clock mode.

### Format

```
show ptp configuration
```

### Mode

Privileged EXEC and User EXEC

### PTP (Global) Clock Mode

Show which PTP clock mode is currently configured.

### PTP (Global) Sync. Upper Bound

Show the upper bound for the PTP clock synchronization status (unit: nanoseconds).

### PTP (Global) Sync. Lower Bound

Show the lower bound for the PTP clock synchronization status (unit: nanoseconds).

## 4.14.3 show ptp operation

Show the global PTP (IEEE 1588) operation setting (the administrative setting). This command shows if PTP is enabled/disabled on this device.

### Format

```
show ptp operation
```

### Mode

Privileged EXEC and User EXEC

## 4.14.4 show ptp port

This command shows the PTP (IEEE 1588) port configuration settings depending on the currently configured clock mode.

### Format

```
show port [<slot/port>|all]
```

### Mode

Privileged EXEC and User EXEC

### <slot/port>

Show the port-related PTP (IEEE 1588) settings for the given port.

### all

Show the port-related PTP (IEEE 1588) settings for all ports.

## 4.14.5 show ptp status

This command shows the device's global PTP (IEEE 1588) status (the operating states).

### Format

```
show ptp status
```

### Mode

Privileged EXEC and User EXEC

### PTP Status, Is Synchronized

Show if the device is synchronized (true or false).

### PTP Status, Offset From Master

Show the device's offset from the master (unit: nanoseconds).

### PTP Status, Max. Offset Absolute

Show the device's maximum offset absolute (unit: nanoseconds).

### PTP Status, Delay To Master

Show the device's delay to the master (unit: nanoseconds).

### PTP Status, Grandmaster UUID

Show grandmaster Universally Unique Identifier  
(32 hexadecimal numbers).

### PTP Status, Parent UUID

Show parent Universally Unique Identifier  
(32 hexadecimal numbers).

### PTP Status, Clock Stratum

Show the device's clock stratum.

### PTP Status, Clock Identifier

Show the device's clock identifier.



## 4.14.6 ptp clock-mode

Configure the Precision Time Protocol (PTP, IEEE 1588) clock mode. If the clock mode is changed, PTP will be initialized. The default is "disable"

### Format

```
ptp clock-mode {v1-simple-mode
                |v2-simple-mode
                |v1-boundary-clock
                |v2-boundary-clock-onestep
                |v2-boundary-clock-twostep
                |v2-transparent-clock}
```

### Mode

Global Config

#### v1-simple-mode

Set the clock mode to 'v1 Simple Mode'. This is a client only mode without hardware support. The device only accepts PTPv1 sync messages and sets the time directly. No BMC algorithm will run.

#### v2-simple-mode

Set the clock mode to 'v2 Simple Mode'. This is a client only mode without hardware support. The device only accepts PTPv2 sync (or follow\_up) messages and sets the time directly. No BMC algorithm will run.

#### v1-boundary-clock

Set the clock mode to 'v1 Boundary Clock'. This specifies the mode as described in the IEEE1588 standard.

#### v2-boundary-clock-onestep

Set the clock mode to 'v2 Boundary Clock one-step'. This specifies the boundary-clock mode as described in the IEEE1588-2008 (PTPv2) standard. The precise timestamp is inserted directly into the sync-packet (one-step Mode).

#### v2-boundary-clock-twostep

Set the clock mode to 'v2 Boundary Clock two-step'. This specifies the boundary-clock mode as described in the IEEE1588-2008 (PTPv2) standard. The precise timestamp is transmitted via a follow-up packet (two-step Mode).

### **v2-transparent-clock**

Set the clock mode to 'v2 Transparent Clock'. This specifies the transparent-clock mode (one-step) as described in the IEEE1588-2008 (PTPv2) standard.

## **4.14.7 ptp operation**

Enable or disable the Precision Time Protocol (IEEE 1588).  
The default is "disable"

### **Format**

```
ptp operation {disable|enable}
```

### **Mode**

Global Config

### **disable**

Disable the Precision Time Protocol (IEEE 1588).

### **enable**

Enable the Precision Time Protocol (IEEE 1588).

## **4.14.8 ptp sync-lower-bound**

Configure the lower bound for the PTP clock synchronization  
(unit: nanoseconds, min.: 0, max.: 999999999 ( $10^9-1$ ), default: 30).

**Note:** The lower bound always has to be smaller than the upper bound.

### **Format**

```
ptp sync-lower-bound <0-999999999>
```

### **Mode**

Global Config

## 4.14.9 ptp sync-upper-bound

Configure the upper bound for the PTP clock synchronization (unit: nanoseconds, min.: 31, max.: 1000000000 (10<sup>9</sup>), default: 5000).

**Note:** The upper bound always has to be larger than the lower bound.

### Format

```
ptp sync-upper-bound <31-1000000000>
```

### Mode

```
Global Config
```

## 4.14.10 ptp v1 preferred-master

Configure the PTPv1 (IEEE1588-2002) specific settings.

Specify if the local switch shall be regarded as a preferred master clock (i. e., if it will remain master in the presence of disconnection or connection of other clocks).

### Format

```
ptp v1 preferred-master {true|false}
```

### Mode

```
Global Config
```

### true

The local switch shall be regarded as a preferred master clock.

### false

The local switch shall not be regarded as a preferred master clock.

### 4.14.11ptp v1 re-initialize

Configure the PTPv1 (IEEE1588-2002) specific settings. Re-initialize the clocks in the local subdomain with the currently configured settings. Changes in the subdomain name or the sync interval will only take effect after this command.

#### Format

```
ptp v1 re-initialize
```

#### Mode

```
Global Config
```

### 4.14.12ptp v1 subdomain-name

Configure the PTPv1 (IEEE1588-2002) specific settings. Enter a Precision Time Protocol subdomain name. The default is "\_DFLT". **Note:** Changes are only applied after the 're-initialize' command or after a re-boot if the configuration was saved.

#### Format

```
ptp v1 subdomain-name <subdomain name>
```

#### Mode

```
Global Config
```

#### <subdomain name>

Enter a PTP subdomain name (up to 16 characters). Valid characters range from hex value 0x21 (!) up to and including hex value 0x7e (~). Enter special characters (\, !, ', ", ?) by preceding them with the escape character (\), e. g., as \\, \!, \', \", \?. The subdomain name must not be empty. The default is "\_DFLT".

### 4.14.13ptp v1 sync-interval

Configure the PTPv1 (IEEE1588-2002) specific settings.

Configure the Precision Time Protocol sync interval. The sync interval is the interval (in seconds) between successive sync messages issued by a master clock.

Valid values are: sec-1, sec-2, sec-8, sec-16, and sec-64. Default is sec-2.

**Note:** Changes are only applied after the 're-initialize' command or after a reboot if the configuration was saved.

#### Format

```
ptp v1 sync-interval {sec-1|sec-2|sec-8|sec-16|  
                    sec-64}
```

#### Mode

Global Config

#### sec-1

Set the PTP sync interval to sec-1 (1 sec).

#### sec-2

Set the PTP sync interval to sec-2 (2 sec).

#### sec-8

Set the PTP sync interval to sec-8 (8 sec).

#### sec-16

Set the PTP sync interval to sec-16 (16 sec).

#### sec-64

Set the PTP sync interval to sec-64 (64 sec).

### **4.14.14ptp v2bc priority1**

Configure the PTPv2 Boundary Clock (IEEE1588-2008) specific settings. Configure the priority1 value (0..255) for the BMC as described in IEEE1588-2008.

#### **Format**

```
ptp v2bc priority1 <0-255>
```

#### **Mode**

```
Global Config
```

### **4.14.15ptp v2bc priority2**

Configure the PTPv2 Boundary Clock (IEEE1588-2008) specific settings. Configure the priority2 value (0..255) for the BMC as described in IEEE1588-2008.

#### **Format**

```
ptp v2bc priority2 <0-255>
```

#### **Mode**

```
Global Config
```

### 4.14.16 ptp v2bc domain

Configure the PTPv2 Boundary Clock (IEEE1588-2008) specific settings. Configure the domain number (0..255) as described in IEEE1588-2008.

#### Format

```
ptp v2bc domain <0-255>
```

#### Mode

```
Global Config
```

### 4.14.17 ptp v2bc utc-offset

Configure the PTPv2 Boundary Clock (IEEE1588-2008) specific settings. Configure the current UTC offset in seconds.

#### Format

```
ptp v2bc utc-offset <seconds>
```

#### Mode

```
Global Config
```

### 4.14.18 ptp v2bc utc-offset-valid

Configure the PTPv2 Boundary Clock (IEEE1588-2008) specific settings. Configure the UTC offset valid flag.

#### Format

```
ptp v2bc utc-offset-valid {true|false}
```

#### Mode

```
Global Config
```

### 4.14.19 ptp v2bc vlan

Configure the PTPv2 Boundary Clock (IEEE1588-2008) specific settings. Use this command to configure the VLAN in which PTP packets are send. With a value of none all packets are send untagged.

#### Format

```
ptp v2bc vlan {none | <0-4042>}
```

#### Mode

```
Interface Config
```

### 4.14.20 ptp v2bc vlan-priority

Configure the PTPv2 Boundary Clock (IEEE1588-2008) specific settings. Use this command to configure the VLAN priority.

#### Format

```
ptp v2bc vlan-priority <0-7>
```

#### Mode

```
Interface Config
```



### 4.14.21 ptp v1 burst

Enable or disable the burst feature for synchronization runs during a synchronization interval. Default is disable.

#### Format

```
ptp v1 burst {enable|disable}
```

#### Mode

```
Interface Config
```

#### enable

During a synchronization interval, there are 2 to 8 synchronization runs. This permits faster synchronization when the network load is high.

#### disable

During a synchronization interval, there is only one synchronization run.

### 4.14.22 ptp v1 operation

Enable or disable the sending and receiving / processing of PTP synchronization messages. Default is enable.

#### Format

```
ptp v1 operation {enable|disable}
```

#### Mode

```
Interface Config
```

#### enable

Port sends and receives/ processes PTP synchronization messages.

#### disable

Port blocks PTP synchronization messages.

### 4.14.23 ptp v2bc operation

Enable or disable the sending and receiving / processing of PTP synchronization messages.

**Format**

```
ptp v2bc operation {disable|enable}
```

**Mode**

```
Interface Config
```

**enable**

Port sends and receives/ processes PTP synchronization messages.

**disable**

Port blocks PTP synchronization messages.

### 4.14.24 ptp v2bc announce-interval

Configure the Announce Interval in seconds {1|2|4|8|16}.

**Format**

```
ptp v2bc announce-interval {1|2|4|8|16}
```

**Mode**

```
Interface Config
```

### 4.14.25 ptp v2bc announce-timeout

Configure the Announce Receipt Timeout (2..10).

#### Format

```
ptp v2bc announce-timeout <2-10>
```

#### Mode

```
Interface Config
```

### 4.14.26 ptp v2bc sync-interval

Configure the Sync Interval in seconds {0.5|1|2}.

#### Format

```
ptp v2bc sync-interval {0.25|0.5|1|2}
```

#### Mode

```
Interface Config
```

### 4.14.27 ptp v2bc delay-mechanism

Configure the delay mechanism {e2e|p2p|disabled} of the transparent-clock.

#### Format

```
ptp v2bc delay-mechanism {e2e|p2p|disabled}
```

#### Mode

```
Interface Config
```

### 4.14.28 ptp v2bc pdelay-interval

Configure the Peer Delay Interval in seconds {1|2|4|8|16|32}. This interval is used if delay-mechanism is set to p2p.

#### Format

```
ptp v2bc pdelay-interval {1|2|4|8|16|32}
```

#### Mode

```
Interface Config
```

### 4.14.29 ptp v2bc network-protocol

Configure the network-protocol {ieee802\_3|udp\_ipv4} of the transparent-clock.

#### Format

```
ptp v2bc network-protocol {ieee802_3 | udp_ipv4}
```

#### Mode

```
Interface Config
```

### 4.14.30 ptp v2bc v1-compatibility-mode

Set the PTPv1 Hardware compatibility mode {auto|on|off}.

#### Format

```
ptp v2bc v1-compatibility-mode {auto|on|off}
```

#### Mode

```
Interface Config
```

### 4.14.31 ptp v2bc asymmetry

Specifies the asymmetrie in nanoseconds of the link connected to this port {+-1000000000}.

#### Format

```
ptp v2bc asymmetry <value in ns>
```

#### Mode

```
Interface Config
```

### 4.14.32 ptp v2tc asymmetry

Specifies the asymmetrie in nanoseconds of the link connected to this port {+-1000000000}.

#### Format

```
ptp v2tc asymmetry <value in ns>
```

#### Mode

```
Interface Config
```

### 4.14.33 ptp v2tc delay-mechanism

Configure the PTPv2 Transparent Clock (IEEE1588-2008) specific settings. Configure the delay mechanism {e2e | p2p | disabled} of the transparent-clock.

#### Format

```
ptp v2tc delay-mechanism {e2e|p2p}
```

#### Mode

```
Global Config
```

### 4.14.34ptp v2tc management

Configure the PTPv2 Transparent Clock (IEEE1588-2008) specific settings. Enable or disable the management of the transparent-clock (disable for fast packet rates).

#### Format

```
ptp v2tc management {enable|disable}
```

#### Mode

```
Global Config
```

### 4.14.35ptp v2tc multi-domain-mode

Configure the PTPv2 Transparent Clock (IEEE1588-2008) specific settings. Enable or disable the transparent-clock for one (primary-domain) or all domain numbers.

#### Format

```
ptp v2tc multi-domain-mode {enable|disable}
```

#### Mode

```
Global Config
```

### 4.14.36ptp v2tc network-protocol

Configure the PTPv2 Transparent Clock (IEEE1588-2008) specific settings. Configure the network-protocol {ieee802\_3|udp\_ipv4} of the transparent-clock.

#### Format

```
ptp v2tc network-protocol {ieee802_3|udp_ipv4}
```

#### Mode

```
Global Config
```

### 4.14.37ptp v2tc operation

Enable or disable the sending and receiving/ processing of PTP synchronization messages.

#### Format

```
ptp v2tc operation {disable|enable}
```

#### Mode

```
Interface Config
```

#### enable

Port sends and receives/ processes PTP synchronization messages.

#### disable

Port blocks PTP synchronization messages.

### 4.14.38 ptp v2tc pdelay-interval

Configure the Peer Delay Interval in seconds {1|2|4|8|16|32}. This interval is used if delay-mechanism is set to p2p.

#### Format

```
ptp v2tc pdelay-interval {1|2|4|8|16|32}
```

#### Mode

```
Interface Config
```

### 4.14.39 ptp v2tc primary-domain

Configure the PTPv2 Transparent Clock (IEEE1588-2008) specific settings. Configure the primary-domain {for syntonization} of the transparent-clock.

#### Format

```
ptp v2tc primary-domain <0-255>
```

#### Mode

```
Global Config
```



## 4.14.40 ptp v2tc profile

**Note:** This command is available for the devices of the MACH104, MACH1040, PowerMICE and MS20/MS30 family.

Configure the PTPv2 Transparent Clock (IEEE1588-2008) specific settings. Use this command to configure the PTP v2TC parameters to match the default of a profile.

### Format

```
ptp v2tc profile
        { power | default-e2e | default-p2p }
```

### Mode

```
Global Config
```

### default-e2e

Configure the PTP v2TC parameters to match the default of a profile (end-to-end transparent clock).

### default-p2p

Configure the PTP v2TC parameters to match the default of a profile (peer-to-peer transparent clock).

### power

Configure the PTP v2TC parameters to match the default of a profile (power profile C37.238).

## 4.14.41 ptp v2tc syntonization

Configure the PTPv2 Transparent Clock (IEEE1588-2008) specific settings. Enable or disable the syntonization of the transparent-clock.

### Format

```
ptp v2tc syntonization {enable|disable}
```

### Mode

```
Global Config
```

### 4.14.42ptp v2tc vlan

Configure the PTPv2 Transparent Clock (IEEE1588-2008) specific settings. Use the command to configure the VLAN in which PTP packets are send. With a value of none all packets are send untagged.

#### Format

```
ptp v2tc vlan {none | <0-4042>}
```

#### Mode

```
Global Config
```

### 4.14.43ptp v2tc power-tlv-check

**Note:** This command is available for the devices of the MACH104, MACH1040, PowerMICE and MS20/MS30 family.

Configure the PTPv2 Transparent Clock (IEEE1588-2008) specific settings. Use the command to configure the Power TLV Check.

#### Default

```
Disable
```

#### Format

```
ptp v2tc power-tlv-check {enable | disable}
```

#### Mode

```
Global Config
```

#### enable

Only announce messages including the TLVs specified in the power profile (C37.238) are accepted for syntonization.

#### disable

Disable v2tc power-tlv-check.

### 4.14.44 **ptp v2tc vlan-priority**

Configure the PTPv2 Transparent Clock (IEEE1588-2008) specific settings. Use the command to configure the VLAN priority of tagged ptp packets.

#### **Format**

```
ptp v2tc vlan-priority <0-7>
```

#### **Mode**

```
Global Config
```

### 4.14.45 **ptp v2tc sync-local-clock**

Configure the PTPv2 Transparent Clock (IEEE1588-2008) specific settings. Use the command to enable or disable synchronisation of the local clock (only valid if syntonization is enabled).

#### **Format**

```
ptp v2tc sync-local-clock {enable | disable}
```

#### **Mode**

```
Global Config
```

## 4.15 PoE - Power over Ethernet

These commands show and configure the Power over Ethernet (IEEE 802.3af) parameters.

### 4.15.1 show inlinepower

This command shows global Inline Power settings PoE.

**Format**

```
show inlinepower
```

**Mode**

Privileged EXEC and User EXEC

### 4.15.2 show inlinepower port

This command shows the configuration settings and states per port.

**Format**

```
show inlinepower port [<slot/port> | all]
```

**Mode**

Privileged EXEC and User EXEC

### 4.15.3 inlinepower (Global Config)

Configure the global Inline Power parameters.

#### Format

```
inlinepower {admin-mode {disable|enable} |  
trap {disable|enable} | threshold <1-99> |  
fast-startup {enable|disable} }
```

#### Mode

Global Config

#### admin-mode

Configure the global Inline Power administrative setting (enable or disable, default: enable).

#### trap

Configure the Inline Power notification (trap) setting (enable or disable, default: disable).

#### threshold

Configure the Inline Power notification (trap) threshold (unit: percent of maximum rated power, valid range: 1-99, default: 90).

#### fast-startup

Configure the Inline Power to be enabled at the beginning of the start phase (enable or disable, default: disable).

## 4.15.4 inlinepower (Interface Config)

Configure the port-related Inline Power parameters.

**Note:** The interface name you enter in the `name`-command.

### Format

```
inlinepower {admin-mode {disable|enable} |  
priority {critical|high|low} }
```

### Mode

Interface Config

### admin-mode

Configure the port-related Inline Power administrative setting (enable or disable, default: enable).

### priority

Configure the Inline Power priority for this port. In case of power scarcity, inline power on ports configured with the lowest priority is dropped first. Possible values are: critical, high or low, default: low. The highest priority is critical.

**Note:** This parameter is available for MACH1000, MACH4000 and devices which support Power over Ethernet Plus (MACH104-16TX-PoEP devices and MACH102 devices with media module M1-8TP-RJ45 PoE).

## 4.15.5 clear inlinepower

Reset the Inline Power parameters to default settings.

### Format

```
clear inlinepower
```

### Mode

Privileged EXEC

## 4.16 PoE+ - Power over Ethernet Plus

Additionally to the PoE (Power over Ethernet) commands, these commands show and configure the Power over Ethernet Plus (IEEE 802.3at) parameters.

**Note:** PoE+ is available for:

- MACH104-16TX-PoEP devices
- MACH 102 devices with media module M1-8TP-RJ45 PoEP

### 4.16.1 show inlinepower slot

This command shows the PoE+ configuration settings and states per slot.

#### Format

```
show inlinepower slot [<slot> | all]
```

#### Mode

Privileged EXEC and User EXEC

#### Slot

For MACH102 devices with M1-8TP-RJ45 PoEP media modules:

Slot = Slot number of the PoE+ module (valid range: 1 - 2)

For MACH104-16TX-PoEP devices: Slot = 1

#### Nominal Power

Shows the configured nominal power budget which the device provides for the PoE+ ports of the PoE+ module.

#### Maximum Power

Shows the nominal power which the device provides for the PoE+ ports of the PoE+ module (valid range: 0 - 248 W).

**Reserved Power**

Shows the maximum power which the device provides for all PoE+ devices together which are connected to the PoE+ module, based on their classification.

**Delivered Power**

Shows the current demand for power on all PoE+ ports of the module (valid range: 0 - 248 W).

**Send Traps**

Shows, if the function is enabled/disabled. If send traps is enabled, the device will send a trap if the power threshold exceeds or falls below the power limit or if the PoE+ power supply is switched on/off on one or more ports.

**Power Threshold**

Power threshold in per cent of the nominal power. If the power is exceeding/falling below this threshold, the device will send a trap.

## 4.16.2 inlinepower budget slot

Configure the available power budget per slot in Watts.

**Format**

```
inlinepower budget slot <slot> <0..1000>
```

**Mode**

```
Global Config
```

**Slot**

For MACH102 devices with M1-8TP-RJ45 PoEP media modules:

Slot = Slot number of the PoE+ module (valid range: 1 - 2)

For MACH104-16TX-PoEP devices: Slot = 1



### 4.16.3 inlinepower threshold slot

Configure the usage power threshold expressed in per cents for comparing the measured power for this slot and initiating an alarm if the threshold is exceeded.

#### Format

```
inlinepower threshold slot <slot> <0..99>
```

#### Mode

```
Global Config
```

#### Slot

For MACH102 devices with M1-8TP-RJ45 PoEP media modules:

Slot = Slot number of the PoE+ module (valid range: 1 - 2)

For MACH104-16TX-PoEP devices: Slot = 1

### 4.16.4 inlinepower trap slot

Configure the alarm that is send if the configured threshold for this slot is exceeded.

#### Format

```
inlinepower trap slot <slot> {enable | disable}
```

#### Mode

```
Global Config
```

#### Slot

For MACH102 devices with M1-8TP-RJ45 PoEP media modules:

Slot = Slot number of the PoE+ module (valid range: 1 - 2)

For MACH104-16TX-PoEP devices: Slot = 1

## 4.17 Port monitor

These commands show and configure the port monitor parameters.

The port monitor feature monitors certain port (or global) states or changes and performs a certain action, when the specified condition occurs.

Using this commands, you can disable a port and send a trap (see "port admin shutdown").

Disabling a port by condition will not modify the configuration and therefore not keep the port in disabled state after reload/reboot.

To enable the action if a port state occurs

- ▶ enable the port monitor globally,
- ▶ enable the port monitor on the port,
- ▶ configure condition(s) that is (are) performed in port state on a port and
- ▶ an action that is performed on that port, when the condition complies.

The condition can be link flapping or CRC/Fragments error, an action can be sending a trap or disabling that port (and send a trap).

If a port was disabled by the Port-Monitor the port can be enabled again with a port monitor reset command (see "port-monitor reset").

## 4.17.1 show port-monitor

Use this command to display the global Port Monitor settings.

### Format

```
show port-monitor
```

### Mode

```
Global Config
```

### Port Monitor

Display if Port Monitor function is enabled or disabled.

### Condition crc-fragment interval (seconds)

Display the condition of the CRC fragment interval in seconds.

### Condition crc-fragment count

Display the condition of the CRC fragment count.

### Condition link flap interval (seconds)

Display the condition of the link flap interval in seconds.

### Condition link flap count

Display the condition of the link flap count.

### Condition overload-detect interval (seconds)

**Note:** This command is available for the MACH1040 and MACH104 devices.

Display the condition of the overload-detect interval in seconds.

## 4.17.2 show port-monitor <slot/port>

Use this command to display the Port Monitor details for the port.

### Format

```
show port-monitor <slot/port>
```

### Mode

Global Config

### Port Monitor

Display if Port Monitor is enabled or disabled.

### Link Flap

Display if Link Flap is enabled or disabled.

### Crc-Fragment

Display if CRC Fragment is enabled or disabled.

### Overload detection

**Note:** This command is available for the MACH1040 and MACH104 devices.

Display the condition of the overload-detection state.

Possible values: Enabled, Disabled.

### Active Condition

Display the active condition for the port.

Possible values: Link-Flap, None.

### Action

Display the action (disable port or send trap) to be triggered on the port. Possible values: Disable-Port, Trap-Only.

### Port Oper State

Display the link state of the port. Possible values: Up, Down.

### 4.17.3 show port-monitor brief

Use this command to display the Port Monitor brief summary.

#### Format

```
show port-monitor brief
```

#### Mode

```
Global Config
```

#### Intf

Display the number of the interface (slot/port).

#### Admin Mode

Display if Port Monitor is enabled or disabled.

#### Link Flap

Display if Link Flap is enabled or disabled.

#### Crc Fragment

Display if CRC Fragment is enabled or disabled.

#### Overload detection

**Note:** This command is available for the MACH1040 and MACH104 devices.

Display the condition of the overload-detection state.

Possible values: Enabled, Disabled.

#### Active Condition

Display the active condition for the port.

Possible values: Link-Flap, None.

#### Action

Display the action (disable port or send trap) to be triggered on the port. Possible values: Disable-Port, Trap-Only.

#### Port Oper State

Display the link state of the port. Possible values: Up, Down.

## 4.17.4 show port-monitor crc-fragment

Use this command to display the CRC fragment counter.

### Format

```
show port-monitor crc-fragment <slot/port>
```

### Mode

Global Config

### <slot/port>

Display the Port Monitor interface details.

### Crc\_fragments in last interval

Display the CRC fragments in last interval.

### Crc\_fragments total

Display the CRC fragments total.

## 4.17.5 show port-monitor link-flap

Use this command to display the Link Flap counter for the port.

### Format

```
show port-monitor link-flap <slot/port>
```

### Mode

Global Config

### <slot/port>

Display the Port Monitor interface details.

### Link flaps in last interval

Display the Link flaps in last interval.

### Link flaps total

Display the Link flaps total.

## 4.17.6 port-monitor (Global Config)

Use this command to enable or disable the Port Monitor globally.

**Note:** This command does not reset the port disable states.

### Default

Disable

### Format

```
port-monitor {enable | disable}
```

### Mode

Global Config

## 4.17.7 port-monitor (Interface Config)

Use this command to enable or disable the Port Monitor on the port.

**Note:** This command does not reset the port disable states.

### Default

Disable

### Format

```
port-monitor {enable | disable}
```

### Mode

Interface Config

## 4.17.8 port-monitor action

Use this command to configure the Port Monitor action (disable a port or send a trap).

**Note:** Disable the Port Monitor action will reset the port from port-state.

### Default

Enable

### Format

```
port-monitor action {port-disable | trap-only}
```

### Mode

Interface Config

### port-disable

Disable the port when the configured Port Monitor condition triggers.

### trap-only

Send a trap when the configured Port Monitor condition triggers.



### 4.17.9 port-monitor condition overload-detection polling-interval (Global Config)

**Note:** This command is available for the MACH104 and MACH1040 devices. Use this command to configure the polling-interval in seconds for overload-detection condition.

#### Default

1

#### Format

```
port-monitor condition overload-detection
                    polling-interval <interval value>
```

#### Mode

Global Config

#### <interval value>

Enter a polling-interval value for overload-detection.  
Possible values: 1..20. Default: 1.

### 4.17.10 port-monitor condition overload-detection (Interface Config)

**Note:** This command is available for the MACH104 and MACH1040 devices. Use this command to configure the Port Monitor overload-detection settings.

#### Format

```
port-monitor condition overload-detection
    { [traffic-type bc | bc+mc | all] |
      [threshold-type pps | kbps | link-capacity ] |
      [lower-threshold <threshold value>] |
```

```
[upper-threshold <threshold value>] |  
{enable | disable}
```

## Mode

Interface Config

### traffic-type bc

Define traffic class for overload-detection: Broadcast traffic (bc).

### traffic-type bc+mc

Define traffic class for overload-detection:  
Broadcast and multicast traffic (bc+mc).

### traffic-type all

Define traffic class for overload-detection: All traffic types (all).

### threshold-type pps

Define threshold type for overload-detection condition:  
Packets per second (pps).

### threshold-type kbps

Define threshold type for overload-detection condition:  
Kilobits per second (kbps).

### threshold-type link-capacity

Define threshold type for overload-detection condition:  
Link capacity percentage (% of the link capacity).

### lower-threshold

Define the lower threshold value for overload-condition (packets per second, kbits or % of the link capacity) for different types of traffic.  
<threshold value> Enter a lower-threshold value.  
Possible values: 0..10000000.

### upper-threshold

Define the upper threshold value for overload-condition (packets per second, kbits or % of the link capacity) for different types of traffic.  
<threshold value> Enter a upper-threshold value.  
Possible values: 0..10000000.

### enable

Enable the overload-detection.

### disable

Disable the overload-detection.

## 4.17.11 show port-monitor overload-detection

**Note:** This command is available for the MACH104 and MACH1040 devices. Use this command to display information about port-monitor overload-detection for a specific interface.

### Default

1

### Format

```
show port-monitor overload-detection <slot/port>
```

### Mode

User EXEC and Privileged EXEC

### <slot/port>

Valid slot and port number separated by forward slashes.

### Overload-detection traffic type

Display the traffic type for the port monitor overload detection.

Possible values:

`bc` (broadcast traffic),

`bc+mc` (broadcast and multicast),

`all` (all traffic types).

### Overload-detection threshold type

Display the threshold type for the port monitor overload detection.

Possible values:

`pps` (packets per second),

`kbps` (kilobits per second),

`link-capacity` (% of the link capacity).

### Overload-detection lower threshold

Display the lower threshold for the port monitor overload detection.

Possible values: 0..10000000

### Overload-detection upper threshold

Display the upper threshold for the port monitor overload detection.

Possible values: 0..10000000

### 4.17.12 port-monitor condition link-flap (Global Config)

Use this command to configure the Link Flap settings (Link Flap counter and interval for Link Flap detection).

#### Default

Disable

#### Format

```
port-monitor condition link-flap
                               {count <1-100>| interval <1-180>}
```

#### Mode

Global Config

#### count

Configure the Link Flap counter.

Default: 5. Value range: 1 - 100.

#### interval

Configure the measure interval in seconds for Link Flap detection.

Default: 10 seconds. Value range: 1 - 180 seconds.

### 4.17.13 port-monitor condition link-flap (Interface Config)

Use this command to enable or disable Link Flap condition on a port to trigger an action.

#### Default

Disable

#### Format

```
port-monitor condition link-flap {enable | disable}
```

#### Mode

Interface Config

### 4.17.14 port-monitor condition crc-fragment (Global Config)

Use this command to configure the crc-fragment settings (crc-fragment counter and interval for crc-fragment detection).

#### Default

Disable

#### Format

```
port-monitor condition crc-fragment
                    {count <1-1000000> | interval <5-180>}
```

#### Mode

Global Config

#### count

Configure the crc-fragment counter.

Default: 1,000. Value range: 1 - 1,000,000.

#### interval

Configure the measure interval in seconds for crc-fragment detection.

Default: 10 seconds. Value range: 5 - 180 seconds.

### 4.17.15 port-monitor condition crc-fragment (Interface Config)

Use this command to enable or disable crc-fragment settings on a port to trigger an action.

#### Default

Disable

#### Format

```
port-monitor condition crc-fragment
                    {enable | disable}
```

#### Mode

Interface Config



## 5 CLI Commands: Switching

This section provides detailed explanation of the Switching commands. The commands are divided into two functional groups:

- ▶ Show commands display spanning tree settings, statistics, and other information.
- ▶ Configuration Commands configure features and options of the switch. For every configuration command there is a show command that displays the configuration setting.





# 5.1 Spanning Tree Commands

## 5.1.1 show spanning-tree

This command displays spanning tree settings for the common and internal spanning tree, when the optional parameter “brief” is not included in the command. The following details are displayed.

### Format

```
show spanning-tree [brief]
```

### Mode

Privileged EXEC and User EXEC

### Spanning Tree Adminmode

Enabled or Disabled

### Bridge Priority

Configured value.

### Bridge Identifier

The bridge identifier for the CST (CST = Classical Spanning Tree IEEE 802.1d). It is made up using the bridge priority and the base MAC address of the bridge.

### Time Since Topology Change

in seconds

### Topology Change Count

Number of times changed.

### Topology Change

Boolean value of the Topology Change parameter for the switch indicating if a topology change is in progress on any port assigned to the common and internal spanning tree.

### Designated Root

The bridge identifier of the root bridge. It is made up from the bridge priority and the base MAC address of the bridge.

### Root Path Cost

Value of the Root Path Cost parameter for the common and internal spanning tree.

**Root Port Identifier**

Identifier of the port to access the Designated Root for the CST.

**Root Port Max Age**

Derived value

**Root Port Bridge Forward Delay**

Derived value

**Hello Time**

Configured value

**Bridge Hold Time**

Minimum time between transmission of Configuration Bridge Protocol Data Units (BPDUs)

**CST Regional Root**

Bridge Identifier of the CST Regional Root. It is made up using the bridge priority and the base MAC address of the bridge.

**Regional Root Path Cost**

Path Cost to the CST Regional Root.

**Associated FIDs**

List of forwarding database identifiers currently associated with this instance.

**Associated VLANs**

List of VLAN IDs currently associated with this instance.

**■ show spanning-tree brief**

When the “brief” optional parameter is included, this command displays a brief overview of the spanning tree settings for the bridge. In this case, the following details are displayed.

**Bridge Priority**

Configured value.

**Bridge Identifier**

The bridge identifier for the selected MST instance. It is made up using the bridge priority and the base MAC address of the bridge.

**Bridge Max Age**

Configured value.

**Bridge Hello Time**

Configured value.

**Bridge Forward Delay**

Configured value.

**Bridge Hold Time**

Minimum time between transmission of Configuration Bridge Protocol Data Units (BPDUs)

**Rstp Mrp Mode**

Rapid spanning tree mrp (Media Redundancy Protocol) mode (Enabled/Disabled)

**Rstp Mrp configuration error**

Configuration error in Rapid spanning tree mrp (Media Redundancy Protocol) (No/Yes)

## 5.1.2 show spanning-tree interface

This command displays the settings and parameters for a specific switch port within the common and internal spanning tree. The <slot/port> is the desired switch port. The following details are displayed on execution of the command.

### Format

```
show spanning-tree interface <slot/port>
```

### Mode

Privileged EXEC and User EXEC

### Port mode

Enabled or disabled.

### Port Up Time Since Counters Last Cleared

Time since port was reset, displayed in days, hours, minutes, and seconds.

### STP BPDUs Transmitted

Spanning Tree Protocol Bridge Protocol Data Units sent

### STP BPDUs Received

Spanning Tree Protocol Bridge Protocol Data Units received.

### RST BPDUs Transmitted

Rapid Spanning Tree Protocol Bridge Protocol Data Units sent

### RST BPDUs Received

Rapid Spanning Tree Protocol Bridge Protocol Data Units received.

### MSTP BPDUs Transmitted

Multiple Spanning Tree Protocol Bridge Protocol Data Units sent

### MSTP BPDUs Received

Multiple Spanning Tree Protocol Bridge Protocol Data Units received.

### 5.1.3 show spanning-tree mst detailed

This command displays settings and parameters for the specified multiple spanning tree instance. The instance <mstid> is a number that corresponds to the desired existing multiple spanning tree instance ID. The following details are displayed.

#### Format

```
show spanning-tree mst detailed <mstid>
```

#### Mode

Privileged EXEC and User EXEC

#### mstid

Enter a multiple spanning tree instance identifier.  
Valid values: 0 - 4094.

#### MST Instance ID

Valid value: 0

#### MST Bridge Priority

Valid values: 0-61440 in increments of 4096.

#### Time Since Topology Change

in seconds

#### Topology Change Count

Number of times the topology has changed for this multiple spanning tree instance.

#### Topology Change in Progress

Value of the Topology Change parameter for the multiple spanning tree instance.

#### Designated Root

Identifier of the Regional Root for this multiple spanning tree instance.

#### Root Path Cost

Path Cost to the Designated Root for this multiple spanning tree instance

#### Root Port Identifier

Port to access the Designated Root for this multiple spanning tree instance

**Associated FIDs**

List of forwarding database identifiers associated with this instance.

**Associated VLANs**

List of VLAN IDs associated with this instance.

## 5.1.4 show spanning-tree mst port detailed

This command displays the detailed settings and parameters for a specific switch port within a particular multiple spanning tree instance. The instance <mstid> is a number that corresponds to the desired existing multiple spanning tree instance. The <slot/port> is the desired switch port.

**Format**

```
show spanning-tree mst port detailed <mstid> <slot/  
port>
```

**Mode**

Privileged EXEC and User EXEC

**MST Instance ID**

Valid value: 0

**Port Identifier**

Port priority as a two digit hex number followed by the port number as a two digit hex number.

**Port Priority**

Decimal number.

**Port Forwarding State**

Current spanning tree state of this port

**Port Role**

The port's current RSTP port role.

**Port Path Cost**

Configured value of the Internal Port Path Cost parameter

**Designated Root**

The Identifier of the designated root for this port.

**Designated Port Cost**

Path Cost offered to the LAN by the Designated Port

**Designated Bridge**

Bridge Identifier of the bridge with the Designated Port.

**Designated Port Identifier**

Port on the Designated Bridge that offers the lowest cost to the LAN  
If 0 (defined as the default CIST ID) is passed as the <mstid>, then this command displays the settings and parameters for a specific switch port within the common and internal spanning tree. The <slot/port> is the desired switch port. In this case, the following are displayed.

**Port Identifier**

The port identifier for this port within the CST.

**Port Priority**

The priority of the port within the CST.

**Port Forwarding State**

The forwarding state of the port within the CST.

**Port Role**

The role of the specified interface within the CST.

**Port Path Cost**

The configured path cost for the specified interface.

**Designated Root**

Identifier of the designated root for this port within the CST.

**Designated Port Cost**

Path Cost offered to the LAN by the Designated Port.

**Designated Bridge**

The bridge containing the designated port

**Designated Port Identifier**

Port on the Designated Bridge that offers the lowest cost to the LAN

**Topology Change Acknowledgement**

Value of flag in next Configuration Bridge Protocol Data Unit (BPDU) transmission indicating if a topology change is in progress for this port.

**Hello Time**

The hello time in use for this port.

**Edge Port**

The configured value indicating if this port is an edge port.

**Edge Port Status**

The derived value of the edge port status. True if operating as an edge port; false otherwise.

**Point To Point MAC Status**

Derived value indicating if this port is part of a point to point link.

**CST Regional Root**

The regional root identifier in use for this port.

**CST Port Cost**

The configured path cost for this port.



### 5.1.5 show spanning-tree mst port summary

This command displays the settings of one or all ports within the specified multiple spanning tree instance. The parameter <mstid> indicates a particular MST instance. The parameter {<slot/port> | all} indicates the desired switch port or all ports.

If 0 (defined as the default CIST ID) is passed as the <mstid>, then the status summary is displayed for one or all ports within the common and internal spanning tree.

#### Format

```
show spanning-tree mst port summary <mstid> {<slot/  
port> | all}
```

#### Mode

Privileged EXEC and User EXEC

#### MST Instance ID

The MST instance associated with this port. Valid value: 0.

#### Interface

Valid slot and port number separated by forward slashes.

#### STP Mode

Current STP mode of this port in the specified spanning tree instance.

#### Type

Currently not used.

#### Port Forwarding State

The forwarding state of the port in the specified spanning tree instance

#### Port Role

The role of the specified port within the spanning tree.

## 5.1.6 show spanning-tree mst summary

This command displays settings and parameters for the specified multiple spanning tree instance. The following details are displayed.

### Format

```
show spanning-tree mst summary
```

### Mode

Privileged EXEC and User EXEC

### MST Instance ID

Valid value: 0

### Associated FIDs

List of forwarding database identifiers associated with this instance.

### Associated VLANs

List of VLAN IDs associated with this instance.

### 5.1.7 show spanning-tree summary

This command displays spanning tree settings and parameters for the switch. The following details are displayed on execution of the command.

**Format**

```
show spanning-tree summary
```

**Mode**

Privileged EXEC and User EXEC

**Spanning Tree Adminmode**

Enabled or disabled.

**Spanning Tree Version**

Version of 802.1 currently supported (IEEE 802.1Q-2005, IEEE 802.1D-2004) based upon the Force Protocol Version parameter

**Configuration Name**

Configured name.

**Configuration Revision Level**

Configured value.

**Configuration Digest Key**

Calculated value.

**Configuration Format Selector**

Configured value.

**MST Instances**

List of all multiple spanning tree instances configured on the switch

### 5.1.8 show spanning-tree vlan

This command displays the association between a VLAN and a multiple spanning tree instance. The <vlanid> corresponds to an existing VLAN ID (1-4042).

**Format**

```
show spanning-tree vlan <vlanid>
```

**Mode**

Privileged EXEC and User EXEC

**vlanid**

Enter a VLAN identifier (1 - 4042).

**VLAN Identifier**

The VLANs associated with the selected MST instance.

**Associated Instance**

Identifier for the associated multiple spanning tree instance or "CST" if associated with the common and internal spanning tree

### 5.1.9 **spanning-tree**

This command sets the spanning-tree operational mode to enabled.

**Default**

```
disabled
```

**Format**

```
spanning-tree
```

**Mode**

```
Global Config
```

**■ no spanning-tree**

This command sets the spanning-tree operational mode to disabled. While disabled, the spanning-tree configuration is retained and can be changed, but is not activated.

**Format**

```
no spanning-tree
```

**Mode**

```
Global Config
```

### 5.1.10 spanning-tree auto-edgeport

This command specifies that this port is an Edge Port within the common and internal spanning tree. This will allow this port to transition to Forwarding State without delay.

**Format**

```
spanning-tree auto-edgeport
```

**Mode**

```
Interface Config
```

**■ no spanning-tree auto-edgeport**

This command specifies that this port is not an Edge Port within the common and internal spanning tree.

**Format**

```
no spanning-tree auto-edgeport
```

**Mode**

```
Interface Config
```

### 5.1.11 spanning-tree bpduguard

This command sets the BPDU (Bridge Protocol Data Units) Guard on the switch to enabled.

**Default**

disabled

**Format**

spanning-tree bpduguard

**Mode**

Global Config

**■ no spanning-tree bpduguard**

This command sets the BPDU (Bridge Protocol Data Units) Guard to disabled.

**Format**

no spanning-tree bpduguard

**Mode**

Global Config

### 5.1.12 spanning-tree configuration name

This command sets the Configuration Identifier Name for use in identifying the configuration that this switch is currently using. The <name> is a string of at most 32 characters.

#### Default

The base MAC address displayed using hexadecimal notation as specified in IEEE 802 standard.

#### Format

```
spanning-tree configuration name <name>
```

#### Mode

```
Global Config
```

#### ■ no spanning-tree configuration name

This command resets the Configuration Identifier Name to its default.

#### Format

```
no spanning-tree configuration name
```

#### Mode

```
Global Config
```



### 5.1.13 spanning-tree configuration revision

This command sets the Configuration Identifier Revision Level for use in identifying the configuration that this switch is currently using. The Configuration Identifier Revision Level is a number in the range of 0 to 65535.

**Default**

0

**Format**

```
spanning-tree configuration revision <0-65535>
```

**Mode**

Global Config

**■ no spanning-tree configuration revision**

This command sets the Configuration Identifier Revision Level for use in identifying the configuration that this switch is currently using to the default value, i.e. 0.

**Format**

```
no spanning-tree configuration revision
```

**Mode**

Global Config

### 5.1.14 spanning-tree edgeport

This command specifies that this port is an Edge Port within the common and internal spanning tree. This will allow this port to transition to Forwarding State without delay.

**Format**

```
spanning-tree edgeport
```

**Mode**

```
Interface Config
```

**■ no spanning-tree edgeport**

This command specifies that this port is not an Edge Port within the common and internal spanning tree.

**Format**

```
no spanning-tree edgeport
```

**Mode**

```
Interface Config
```

## 5.1.15 spanning-tree forceversion

This command sets the Force Protocol Version parameter to a new value. The Force Protocol Version can be one of the following:

- ▶ 802.1d - ST BPDUs are transmitted (802.1Q-2005 functionality supported)
- ▶ 802.1s - ST BPDUs are transmitted (802.1Q-2005 functionality supported)
- ▶ 802.1w - RST BPDUs are transmitted (802.1Q-2005 functionality supported)

### Default

```
802.1w
```

### Format

```
spanning-tree forceversion  
                        <802.1d | 802.1s | 802.1w>
```

### Mode

```
Global Config
```

### ■ no spanning-tree forceversion

This command sets the Force Protocol Version parameter to the default value, i.e. 802.1w.

### Format

```
no spanning-tree forceversion
```

### Mode

```
Global Config
```

### 5.1.16 spanning-tree forward-time

This command sets the Bridge Forward Delay parameter to a new value for the common and internal spanning tree. The forward-time value is in seconds within a range of 4 to 30, with the value being greater than or equal to  $(\text{Bridge Max Age} / 2) + 1$ .

**Default**

15

**Format**

```
spanning-tree forward-time <4-30>
```

**Mode**

Global Config

**■ no spanning-tree forward-time**

This command sets the Bridge Forward Delay parameter for the common and internal spanning tree to the default value, i.e. 15.

**Format**

```
no spanning-tree forward-time
```

**Mode**

Global Config

### 5.1.17 spanning-tree guard loop

This command enables loop guard and disables root guard guard on an interface.

**Default**

disabled

**Format**

spanning-tree guard loop

**Mode**

Interface Config

**■ no spanning-tree guard**

This command disables the guard for this port.

**Format**

no spanning-tree guard

**Mode**

Interface Config

### 5.1.18 spanning-tree guard none

This command disables root guard and disables loop guard guard on an interface.

**Default**

disabled

**Format**

spanning-tree guard none

**Mode**

Interface Config

**■ no spanning-tree guard**

This command disables the guard for this port.

**Format**

no spanning-tree guard

**Mode**

Interface Config

### 5.1.19 spanning-tree guard root

This command enables root guard and disables loop guard on an interface.

**Default**

disabled

**Format**

spanning-tree guard root

**Mode**

Interface Config

**■ no spanning-tree guard**

This command disables the guard for this port.

**Format**

no spanning-tree guard

**Mode**

Interface Config

## 5.1.20 spanning-tree hello-time

This command sets the Hello Time parameter to a new value for the common and internal spanning tree. The hellotime <value> is in whole seconds within a range of 1 to 2 with the value being less than or equal to  $(\text{Bridge Max Age} / 2) - 1$ .

### Default

2

### Format

```
spanning-tree hello-time <1-2>
```

### Mode

Interface Config

Global Config

### ■ no spanning-tree hello-time

This command sets the Hello Time parameter for the common and internal spanning tree to the default value, i.e. 2.

### Format

```
no spanning-tree hello-time
```

### Mode

Interface Config

Global Config



### 5.1.21 spanning-tree hold-count

This command sets the bridge hold count parameter.

**Default**

disabled

**Format**

spanning-tree hold-count <1-40>

**Mode**

Global Config

**<1-40>**

Enter the bridge parameter for hold count as an integer in the range 1 - 40.

**■ no spanning-tree hold-count**

This command sets bridge hold count to disabled.

**Format**

no spanning-tree hold-count

**Mode**

Global Config

## 5.1.22 spanning-tree max-age

This command sets the Bridge Max Age parameter to a new value for the common and internal spanning tree. The max-age value is in seconds within a range of 6 to 40, with the value being less than or equal to "2 times (Bridge Forward Delay - 1)".

### Default

20

### Format

```
spanning-tree max-age <6-40>
```

### Mode

Global Config

### ■ no spanning-tree max-age

This command sets the Bridge Max Age parameter for the common and internal spanning tree to the default value, i.e. 20.

### Format

```
no spanning-tree max-age
```

### Mode

Global Config

### 5.1.23 spanning-tree max-hops

This command sets the Bridge Max Hops parameter to a new value for the common and internal spanning tree. The max-hops value is an integer within a range of 1 to 127.

#### Format

```
spanning-tree max-hops <1-127>
```

#### Mode

```
Global Config
```

#### ■ no spanning-tree max-hops

This command sets the Bridge Max Hops parameter for the common and internal spanning tree to the default value, i.e. 20.

#### Format

```
no spanning-tree max-age
```

#### Mode

```
Global Config
```

## 5.1.24 spanning-tree mst

This command sets the Path Cost or Port Priority for this port within the multiple spanning tree instance or in the common and internal spanning tree. If the <mstid> parameter corresponds to an existing multiple spanning tree instance, then the configurations are done for that multiple spanning tree instance. If however 0 (defined as the default CIST ID) is passed as the <mstid>, then the configurations are performed for the common and internal spanning tree instance.

This command accepts the value 0 for the mstid, meaning the common and internal spanning tree.

If the 'cost' token is specified, this command sets the path cost for this port within a multiple spanning tree instance or the common and internal spanning tree instance, depending on the <mstid> parameter. The pathcost can be specified as a number in the range of 1 to 200000000 or auto. If "auto" is specified, the pathcost value will be set based on Link Speed.

If the 'port-priority' token is specified, this command sets the priority for this port within a specific multiple spanning tree instance or the common and internal spanning tree instance, depending on the <mstid> parameter. The port-priority value is a number in the range of 0 to 240 in increments of 16.

### Default

```
cost : auto; external-cost : auto;
port-priority : 128
```

### Format

```
spanning-tree mst <mstid>
    {{cost <1-200000000> | auto } |
    {external-cost <1-200000000> | auto } |
    port-priority <0-240>}
```

### Mode

```
Interface Config
```

**■ no spanning-tree mst**

This command sets the Path Cost or Port Priority for this port within the multiple spanning tree instance or in the common and internal spanning tree to the respective default values. If the <mstid> parameter corresponds to an existing multiple spanning tree instance, then the configurations are done for that multiple spanning tree instance. If however 0 (defined as the default CIST ID) is passed as the <mstid>, then the configurations are performed for the common and internal spanning tree instance.

This command accepts the value 0 for the mstid, meaning the common and internal spanning tree.

If the 'cost' token is specified, this command sets the path cost for this port within a multiple spanning tree instance or the common and internal spanning tree instance, depending on the <mstid> parameter, to the default value, i.e. a pathcost value based on the Link Speed.

If the 'port-priority' token is specified, this command sets the priority for this port within a specific multiple spanning tree instance or the common and internal spanning tree instance, depending on the <mstid> parameter, to the default value, i.e. 128.

**Format**

```
no spanning-tree mst <mstid> <cost | port-priority>
```

**Mode**

```
Interface Config
```

## 5.1.25 spanning-tree mst priority

This command sets the bridge priority for a specific multiple spanning tree instance. The instance <mstid> is a number that corresponds to the desired existing multiple spanning tree instance. The priority value is a number within a range of 0 to 61440 in increments of 4096.

This command accepts the value 0 for the mstid.

If 0 (defined as the default CIST ID) is passed as the <mstid>, then this command sets the Bridge Priority parameter to a new value for the common and internal spanning tree. The bridge priority value again is a number within a range of 0 to 61440. The twelve least significant bits will be masked according to the 802.1s specification. This will cause the priority to be rounded down to the next lower valid priority.

### Default

32768

### Format

```
spanning-tree mst priority <mstid> <0-61440>
```

### Mode

Global Config

### ■ no spanning-tree mst priority

This command sets the bridge priority for a specific multiple spanning tree instance to the default value, i.e. 32768. The instance <mstid> is a number that corresponds to the desired existing multiple spanning tree instance.

This command accepts the value 0 for the mstid.

If 0 (defined as the default CIST ID) is passed as the <mstid>, then this command sets the Bridge Priority parameter for the common and internal spanning tree to the default value, i.e. 32768.

### Format

```
spanning-tree mst priority <mstid>
```

### Mode

Global Config

## 5.1.26 spanning-tree mst vlan

This command adds an association between a multiple spanning tree instance and a VLAN. The VLAN will no longer be associated with the common and internal spanning tree. The instance <mstid> is a number that corresponds to the desired existing multiple spanning tree instance. The <vlanid> corresponds to an existing VLAN ID (1-4042). This command accepts the value 0 for the mstid.

### Format

```
spanning-tree mst vlan <mstid> <vlanid>
```

### Mode

```
Global Config
```

### ■ no spanning-tree mst vlan

This command removes an association between a multiple spanning tree instance and a VLAN. The VLAN will again be associated with the common and internal spanning tree. The instance <mstid> is a number that corresponds to the desired existing multiple spanning tree instance. The <vlanid> corresponds to an existing VLAN ID. This command accepts the value 0 for the mstid.

### Format

```
no spanning-tree mst vlan <mstid> <vlanid>
```

### Mode

```
Global Config
```

## 5.1.27 spanning-tree mst instance

This command creates a MST instance.

### Format

```
spanning-tree mst instance <1-4094>
```

### Mode

Global Config

### <1-4094>

Enter a multiple spanning tree instance identifier.

## ■ no spanning-tree mst instance

This command removes a MST instance.

### Format

```
no spanning-tree mst instance <1-4094>
```

### Mode

Global Config

### <1-4094>

Enter a multiple spanning tree instance identifier.



### 5.1.28 spanning-tree port mode

This command sets the Administrative Switch Port State for this port to enabled.

**Default**

disabled

**Format**

spanning-tree port mode

**Mode**

Interface Config

**■ no spanning-tree port mode**

This command sets the Administrative Switch Port State for this port to disabled.

**Format**

no spanning-tree port mode

**Mode**

Interface Config

## 5.1.29 spanning-tree port mode all

This command sets the Administrative Switch Port State for all ports to enabled.

### Default

disabled

### Format

```
spanning-tree port mode all
```

### Mode

Global Config

### ■ no spanning-tree port mode all

This command sets the Administrative Switch Port State for all ports to disabled.

### Format

```
no spanning-tree port mode all
```

### Mode

Global Config

### 5.1.30 spanning-tree stp-mrp-mode

This command sets the spanning tree mrp (Media Redundancy Protocol) mode to enabled.

**Default**

disabled

**Format**

```
spanning-tree stp-mrp-mode
```

**Mode**

Global Config

**■ no spanning-tree stp-mrp-mode**

This command sets the spanning tree mrp (Medium Redundancy Protocol) mode to disabled.

**Format**

```
no spanning-tree stp-mrp-mode
```

**Mode**

Global Config

### 5.1.31 spanning-tree tcnguard

This command enables tcn guard on an interface.

**Default**

disabled

**Format**

spanning-tree guard tcnguard

**Mode**

Interface Config

**■ no spanning-tree tcnguard**

This command disables tcn guard for this port.

**Format**

no spanning-tree tcnguard

**Mode**

Interface Config

## 5.2 MRP

The concept of the MRP-Ring enables the construction of high-availability, ring-shaped network structures.

The two ends of a backbone in a line-type configuration can be closed to form a redundant ring - the MRP-Ring - by using the RM function (Redundancy Manager) of the Switch.

It is possible to mix the devices that support this function in any combination within the MRP ring.

If a line section becomes inoperable, the ring structure of up to 50 switches typically transforms back to a line-type configuration within 150 ms (maximum 500 ms).

### 5.2.1 show mrp

This command displays the settings and states of the MRP-Ring. The following details are displayed on execution of the command.

#### Format

```
show mrp [current-domain]
```

#### Mode

Privileged EXEC and User EXEC

#### current-domain

Specify the optional keyword "current-domain" to show the current MRP domain's settings. If you omit the keyword "current-domain", the show command will display the settings of all existing MRP domains.

**Note:** Currently, it is only possible to configure one MRP domain, so the keyword keyword "current-domain" can be omitted (it exists for future compatibility reasons).

## 5.2.2 show mrp current-domain

This command displays the settings and states of the MRP-Ring's current domain. The following details are displayed on execution of the command. If you omit the optional keywords (e. g., advanced-mode), all settings will be displayed.

### Format

```
show mrp current-domain [advanced-mode |  
  domain-id | info | manager-priority | mode |  
  name | recovery-delay | operation |  
  port [primary | secondary] | summary | vlan]
```

### Mode

Privileged EXEC and User EXEC

### advanced mode

Show the switch's advanced mode setting for the given MRP domain.

### domain-id

Show the given MRP domain's ID.

### info

Show status information for the given MRP domain.

**Note:** The information displayed depends on the switch's mode (Client or Manager) because only a subset of them are useful for each mode.

### manager-priority

Show the switch's manager priority for the given MRP domain.

### mode

Show the switch's mode for the given MRP domain.

### name

Show the given MRP domain's name.

### recovery-delay

Show the given MRP domain's recovery delay.

### operation

Show the switch's administrative setting for the given MRP domain (enabled or disabled).

**port**

Show the ports for the given MRP domain

**port primary**

Show the primary port for the given MRP domain.

**port secondary**

Show the secondary port for the given MRP domain.

**summary**

Show a summary for the given MRP domain.

**vlan**

Show the VLAN ID for the given MRP domain.

### 5.2.3 mrp current-domain

Specify that you want to configure the current MRP domain's settings.

**Default**

none

**Format**

```
mrp current-domain {advanced-mode {disable|enable}  
| manager-priority <0-65535>  
| mode {client|manager} | name <domain-name>  
| recovery-delay {500ms|200ms}  
| operation {disable|enable}  
| port {primary|secondary} <slot/port>  
| vlan <0-4042>}
```

**Mode**

Global Config

**advanced-mode**

Enable or disable the switch's advanced mode for the given MRP domain.

**manager-priority**

Configure the given MRP domain's manager priority (0-65535).

**mode**

Configure the switch's MRP mode for the given domain (client or manager).

`client`: Switch is client for the given MRP domain.

`manager`: Switch is manager for the given MRP domain.

**name**

Set a name for the given MRP domain.

**recovery-delay**

Configure the MRP recovery delay for the given domain.

`500ms`: Recovery delay is 500 ms for the given MRP domain.

`200ms`: Recovery delay is 200 ms for the given MRP domain.

**operation**

Enable or disable the switch for the given MRP domain.

**port**

Specify the switch's ports for the given MRP domain (in slot/port notation).

`primary`: Specify the switch's primary port for the given MRP domain.

`secondary`: Specify the switch's secondary port for the given MRP domain.

**vlan**

Enter the VLAN for the given MRP domain (0 - 4042, default: 0).



## 5.2.4 mrp delete-domain

Delete current MRP domain.

### Format

```
mrp delete-domain current-domain
```

### Mode

```
Global Config
```

## 5.2.5 mrp new-domain

Create a new MRP domain. The configuration will consist of default parameters and its operation will be disabled.

### Default

```
n/a not set
```

### Format

```
mrp new-domain (<domain-id> | default-domain)
```

### Mode

```
Global Config
```

### domain-id

Enter a new MRP domain id. Format: 16 bytes in decimal notation, example: 1.2.3.4.5.6.7.8.9.10.11.12.13.14.15.16

The MRP domain id 0.0.0.0.0.0.0.0.0.0.0.0.0.0.0.0 is invalid.

### default-domain

Create a default MRP domain (ID: 255.255.255.255.255.255.255.255.255.255.255.255.255.255.255.255).

## 5.2.6 arc

Use this command to configure ARC (Automatic Ring Configuration). ARC supports MRP.

The ARC protocol is a simple protocol that checks a ring configuration and, if suitable, configures all clients of this ring automatically.

The check cycle includes an analysis of the ARC devices for an already active ring configuration and wrong ring configuration values. The ARC devices can detect loop situations and other ARC Managers in the ring. Errors are reported to the ARC Manager. With this information the ARC Manager can decide whether a configuration of the ring clients is possible or not.

### Format

```
arc { manager {enable | disable} |
      client {enable | disable | checkOnly} |
      check |
      configure}
```

### Mode

Global Config

### client

Configure the ARC client.

- `enable`: Enable the ARC client for configuring and checking.
- `disable`: Disable the ARC client for configuring and checking.
- `checkOnly`: The device can only be checked but not configured by ARC.

### manager

Configure the ARC manager.

- `enable`: Enable the ARC manager for configuring and checking.
- `disable`: Disable the ARC manager for configuring and checking.

### check

Check the topology. All important values will be taken from the current ring configuration on the devices.

### configure

Configure the topology. All important values will be taken from the current ring configuration of the ARC manager.

## 5.2.7 show arc

This command displays the current ARC configuration and the result of the last action.

### Format

```
show arc
```

### Mode

```
Global Config
```

### Client Settings:

Display the Client Settings for the current ARC configuration.

### Admin Status

Display if the ARC client is enabled or disabled.

### MAC address of the ARC Manager

Display the MAC address of the ARC Client.

### IP address of the ARC Manager

Display the IP address of the ARC Client.

### Port 1

Display the number of Ring Port 1 for the client (slot/port).

### Port 2

Display the number of Ring Port 2 for the client (slot/port).

### Manager Settings:

Display the Manager Settings for the current ARC configuration.

### Admin Status

Display the ARC manager is enabled or disabled

### Protocol

Display the Protocol. Possible values: mrp, ....

### Port 1

Display the number of Ring Port 1 for the manager (slot/port).

### Port 2

Display the number of Ring Port 2 for the manager (slot/port).

### VLAN ID

Display the VLAN ID. Possible values: 0 - ....

## Last Action Result

Display the Result of the Last Action.

Possible values: Ring is open, Already Configured, Loop Source, Multiple RM, Configuration failed, Port not in full duplex mode, ARC not supported by the ring devices.

## Last Check result:

Display the Result of the last check.

- Nr: Display the number of the check result.
- Mac Address: Display the concerned MAC address.
- IP Address: Display the concerned IP address.
- Type: Display the type of the result. Possible values: Error, Warning.

Possible check results (examples):

Error - Ring is open

Warning - Already Configured - HIPER Ring - Port1: 1.1 - Port2: 1.2

Warning - Already Configured - MRP - Port1: 1.9 - Port2: 1.10 - VLAN ID: 0

Warning - Already Configured - Fast HIPER Ring - Port1: 1.3 - Port2: 1.4

Error - Loop Source - Hop count: 1 - Port1: 1.1 - Port2: 1.4 - Port3: 1.15

Error - Multiple RM - MRP

Error - Configuration failed - MRP

Warning - Port not in full duplex mode - Port1: 1.1 Half - Port2: 1.2 Full

Warning - ARC not supported by the ring devices

## 5.3 HIPER-Ring

The concept of the HIPER-Ring enables the construction of high-availability, ring-shaped network structures. Within such a ring topology, network components supporting the HIPER-Ring are connected with each other via their ring ports. Exactly one redundancy manager assumes control of the ring. These commands are for configuring the Hirschmann High Performance Redundancy Ring.

Further information concerning this function you will find in the User Manual "Redundancy Configuration".

### 5.3.1 show hiper-ring

This command displays the settings and states of the HIPER-Ring. The following details are displayed on execution of the command.

#### Format

```
show hiper-ring
  {info | mode | port [primary | secondary] |
  redundancy-state | rm-state | recovery-delay}
```

#### Mode

Privileged EXEC and User EXEC

#### info

Display the information about the HIPER-Ring configuration (cabling).

#### mode

Display the HIPER-Ring mode settings.

#### port

Display the HIPER-Ring's primary and secondary port properties.

#### port primary

Display the HIPER Ring's primary port properties.

#### port secondary

Display the HIPER Ring's secondary port properties.

#### redundancy-state

Display the actual state of the HIPER-Ring redundancy.

#### rm-state

Display the state of the HIPER Ring redundancy manager.

#### recovery-delay

Display the value of the recovery delay.

### 5.3.2 hiper-ring

Configure the HIPER-Ring.

Press Enter for a list of valid commands and their recommended order.

#### Format

```
hiper-ring
```

#### Mode

```
Global Config
```

#### ■ no hiper-ring

Clear the HIPER Ring configuration (delete it).

#### Format

```
no hiper-ring
```

#### Mode

```
Global Config
```

### 5.3.3 hiper-ring mode

This command sets the HIPER-Ring mode. Possible values are:

- ▶ `ring-manager` Set the switch's HIPER Ring mode to Ring Manager.
- ▶ `rm` Abbreviation of Ring Manager.
- ▶ `ring-switch` Set the switch's HIPER Ring mode to Ring Switch.
- ▶ `rs` Abbreviation of Ring Switch.

#### Default

```
none
```

#### Format

```
hiper-ring mode <{ring-manager|ring-switch|rm|rs}>
```

#### Mode

```
Global Config
```

### 5.3.4 hiper-ring port primary

Enter the switch's primary HIPER Ring port.

**Default**

n/a (not set)

**Format**

```
hiper-ring port primary <primary ring port>
```

**Mode**

Global Config

**primary ring port**

Enter the switch's primary HIPER Ring port (<slot/port>).

### 5.3.5 hiper-ring port secondary

Enter the switch's secondary HIPER Ring port.

**Default**

n/a not set

**Format**

```
hiper-ring port secondary <secondary ring port>
```

**Mode**

Global Config

**secondary ring port**

Enter the switch's secondary HIPER Ring port (<slot/port>).



### 5.3.6 hiper-ring recovery-delay

Defines the maximum recovery delay of ring recovery in the HIPER Ring (500 or 300 ms).

**Default**

n/a not set

**Format**

hiper-ring recovery-delay (<500/300>)

**Mode**

Global Config

## 5.4 Fast-HIPER-Ring

The concept of the Fast-HIPER-Ring enables the construction of high-availability, ring-shaped network structures. Within such a ring topology, network components supporting the Fast-HIPER-Ring are connected with each other via their ring ports. Exactly one redundancy manager assumes control of the ring.

These commands are for configuring the Hirschmann Fast High Performance Redundancy Ring.

Further information concerning this function you will find in the User Manual "Redundancy Configuration".

### 5.4.1 **show fast-hiper-ring (MACH1000, RSR20/RSR30)**

This command displays the settings and states of the HIPER-Ring. The following details are displayed on execution of the command.

#### **Format**

```
show fast-hiper-ring
```

#### **Mode**

Privileged EXEC and User EXEC

#### **Ring ID**

Display the Ring ID.

#### **Mode of Switch (administrative setting)**

Display the HIPER-Ring mode administrative settings.

#### **Mode of Switch (real operating state)**

Display the HIPER-Ring operation mode.

#### **Ring Name**

Display the Fast-HIPER-Ring's name.

#### **Number of nodes in the ring**

Display the number of nodes in the ring.

#### **Port Number, Primary**

Display the HIPER-Ring's primary port number and its properties.

#### **Port Number, Secondary**

Display the HIPER-Ring's secondary port number and its properties.

#### **Operation**

Display the admin state of the HIPER-Ring configuration.

#### **General Operating States**

Display general information concerning the fast-hiper-ring state.

## 5.4.2 show fast-hiper-ring current-id (MACH1000, RSR20/RSR30)

Specify that you want to show the current Fast HIPER-Ring ID's settings.

### Format

```
show fast-hiper-ring current-id
  {id | info | mode | operation | port |
  port [primary |secondary] | summary |
  ring-name | nodes | vlan}
```

### Mode

Privileged EXEC and User EXEC

### id

Display the given Fast HIPER-Ring's ID.

### info

Display status information for the given Fast HIPER-Ring ID.

### mode

Display the switch's mode for the given Fast HIPER-Ring ID.

### operation

Display the switch's operative setting for the given Fast HIPER-Ring ID.

**Note:** In case of configuration problems, this value may differ from the administrative setting (may become 'Disabled').

### port

Display the ports for the given Fast HIPER-Ring ID.

### port primary

Display the primary port for the given Fast HIPER-Ring ID.

### port secondary

Display the secondary port for the given Fast HIPER-Ring ID.

### summary

Display a summary for the given Fast HIPER-Ring ID.

### ring-name

Display the ring name for the given Fast HIPER-Ring ID.

**nodes**

Display the number of nodes in the ring for the given Fast HIPER-Ring ID.

**vlan**

Display the VLAN ID for the given Fast HIPER-Ring ID.

### 5.4.3 fast-hiper-ring

Configure the Fast-HIPER-Ring.

**Format**

```
fast-hiper-ring {current-id
  {mode {ring-manager|ring-switch|rm|rs} |
  operation {disable|enable} |
  port {primary|secondary} <slot/port> |
  ring-name <ring-name> |
  nodes <1-n> |
  vlan <0-4042>} |
delete-id current-id |
new-id {<id>|default-id}}
```

**Mode**

Global Config

**current-id**

Specify that you want to configure the current Fast-HIPER-Ring ID's settings.

**mode**

Configure the switch's Fast HIPER-Ring mode for the given ID (ring-manager or ring-switch).

rm: Abbreviation for 'ring-manager'.

rs: Abbreviation for 'ring-switch'.

**mode ring-manager**

Switch is ring-manager for the given Fast HIPER-Ring ID.

**mode ring-switch**

Switch is ring-switch for the given Fast HIPER-Ring ID.

**mode rm**

Abbreviation for 'ring-manager'.

**mode rs**

Abbreviation for 'ring-switch'.

**operation**

Enable or disable the switch for the given Fast-HIPER-Ring ID.

**port**

Specify the switch's ports for the given Fast-HIPER-Ring ID.

**ring-name**

Set a ring name for the given Fast HIPER-Ring ID.

**nodes**

Specify the number of nodes in the ring for the given Fast HIPER-Ring ID.

**vlan**

Specify the VLAN for the given Fast HIPER-Ring ID.

**delete-id**

Delete the given Fast HIPER-Ring ID.

**new-id**

Create a new Fast HIPER-Ring ID. The configuration will consist of default parameters and its operation will be disabled.

**<id>**

Enter a new Fast HIPER-Ring ID. Format: a number in the range 1-2147483647 ( $2^{31} - 1$ ). An ID of 0 is invalid.

**default-id**

Create a default Fast HIPER-Ring ID (1).

## 5.5 Redundant Coupling

The control intelligence built into the switch allows the redundant coupling of HiPER-Rings and network segments. Two network segments can be connected via two separate paths with one of the following switches:

- ▶ RS2-16M
- ▶ RS20/RS30/RS40
- ▶ RSR20/RSR30
- ▶ MICE (Rel. 3.0 or higher)
- ▶ MS20/MS30
- ▶ PowerMICE
- ▶ MACH1000
- ▶ MACH3000 (Rel. 3.3 or higher)
- ▶ MACH4000

The switch in the redundant line and the switch in the main line inform each other about their operating states by using control frames via the ethernet or via the control line.

**Note:** For redundancy security reasons, the Rapid Spanning Tree protocol and redundant network/ring coupling may not be enabled simultaneously.

**Note:** The network that connects the master and the slave must always be a HiPER-Ring. The coupling switch in single mode also must have a HiPER-Ring Configured.

Further information concerning this function you will find in the User Manual "Redundancy Configuration".

These commands allow you to configure the redundant coupling of network segments.

## 5.5.1 show ring-coupling

This command displays the settings and states of the network coupling / ring coupling.

To set up a new Ring Coupling configuration when no configuration is currently present (e. g., after a clear command), always set the local port first. Please refer to: ring-coupling port local <slot/port>.

The following details are displayed on execution of the command.

### Format

```
show ring-coupling <config | info |
net-coupling | operation | partner-ip |
port [ all | control | local | partner] |
redundancy-mode>
```

### Mode

Privileged EXEC and User EXEC

### config

Display the Ring Coupling's configuration

- single
- dual-master-inband
- dual-master-outband
- dual-slave-inband
- dual-slave-outband.

### info

Display information about the Ring Coupling's states:

- configuration failure,
- Extended diagnosis,
- redundancy guaranteed.

### net-coupling

Display the Ring Coupling's ring/network coupling setting (network/ring-only).

### operation

Display the Ring Coupling's operation setting

- on
- off



**partner IP**

Display the switch's Ring Coupling partner IP address (only valid for remote configurations).

**port**

Display the switch's Ring Coupling ports

- all
- local
- partner (only takes effect in dual configurations)
- control (only takes effect in outband configurations).

**redundancy-mode**

Display the Ring Coupling's redundancy mode

- normal
- extended.

**Ring/Network Coupling Mode**

Display the Ring/Network Coupling mode

- ring-only if you wish to couple a HIPER-Ring.
- network if you wish to couple a line-type configuration.

## 5.5.2 ring-coupling

Configure the redundant coupling of HIPER-Rings / network segments. This command, if called without arguments, lists the available subcommands, their recommended order and tips how to set up a new configuration.

### Format

```
ring-coupling
```

### Mode

```
Global Config
```

### ■ no ring-coupling

Clear the ring-coupling configuration (delete it).

### Format

```
no ring-coupling
```

### Mode

```
Global Config
```

### 5.5.3 ring-coupling config

This command sets the Ring Coupling configuration.

Possible values are:

- ▶ `single` Configure the Ring Coupling's basic setting to single (both coupling ports are local to the switch, switch performs master and slave functions).
- ▶ `dual-master-inband` Configure the Ring Coupling's basic setting to dual-master-inband (2nd coupling port is on a remote switch, local switch is master, communication over network).
- ▶ `dual-master-outband` Configure the Ring Coupling's basic setting to dual-master-outband (2nd coupling port is on a remote switch, local switch is master, communication over dedicated control port).
- ▶ `dual-slave-inband` Configure the Ring Coupling's basic setting to dual-slave-inband (2nd coupling port is on a remote switch, local switch is slave, communication over network).
- ▶ `dual-slave-outband` Configure the Ring Coupling's basic setting to dual-slave-outband (2nd coupling port is on a remote switch, local switch is slave, communication over dedicated control port).
- ▶ `dmi` Abbreviation for `dual-master-inband`.
- ▶ `dmo` Abbreviation for `dual-master-outband`.
- ▶ `dsi` Abbreviation for `dual-slave-inband`.
- ▶ `dso` Abbreviation for `dual-slave-outband`.

#### Default

`none`

#### Format

```
ring-coupling config <{ single |
dual-master-inband | dual-master-outband |
dual-slave-inband | dual-slave-outband |
dmi | dmo | dsi | dso }>
```

#### Mode

Global Config

## 5.5.4 ring-coupling net-coupling

Coupling mode refers to the type of coupled network.

Possible values are:

- ▶ `network`, if you wish to couple a line-type configuration.
- ▶ `ring-only`, if you wish to couple a HIPER-Ring.

### Default

`none`

### Format

```
ring-coupling net-coupling <{network|ring-only}>
```

### Mode

Global Config

## 5.5.5 ring-coupling operation

Configure the Ring Coupling's operation setting. Possible values are:

- ▶ `on` Enable the current Ring Coupling configuration.
- ▶ `off` Disable the current Ring Coupling configuration.

### Default

`off`

### Format

```
ring-coupling operation <{off|on}>
```

### Mode

Global Config

## 5.5.6 ring-coupling port

Configure the Ring Coupling's ports. Possible values are:

- ▶ `control` Enter the Ring Coupling's control coupling port in outband configurations.
- ▶ `local` Enter the Ring Coupling's local coupling port.
- ▶ `partner` Enter the Ring Coupling's partner coupling port in single mode configuration.

### Default

`none`

### Format

```
ring-coupling port <{control|local|partner}> <slot/  
port>
```

### Mode

Global Config

## 5.5.7 ring-coupling redundancy-mode

Configure the Ring Coupling's redundancy mode. Possible values are:

- ▶ `extended` Slave responds to a failure in the remote ring or network.
- ▶ `normal` Slave does not respond to a failure in the remote ring or network.

### Default

`extended`

### Format

```
ring-coupling redundancy-mode <{extended|normal}>
```

### Mode

Global Config

## 5.6 Port Security

With the Port Security function you can specify for each port from which terminal devices data can be received and sent to other ports. This function helps to protect the network from unauthorized access.

### 5.6.1 show port-sec mode

Display the MAC/IP Based Port Security global setting for all ports.

#### Format

```
show port-sec mode
```

#### Mode

Privileged EXEC and User EXEC

### 5.6.2 show port-sec port

Display the MAC/IP Based Port Security port-related settings (allowed MAC address, current MAC address, allowed IP address, current action and current port state).

#### Format

```
show port-sec port <{all|<slot/port>}>
```

#### Mode

Privileged EXEC and User EXEC

### 5.6.3 port-sec mode

Configure the global MAC/IP Based Port Security mode:

- ▶ `ip-based` Port security is based on a given, allowed source IP address.
- ▶ `mac-based` Port security is based on a given, allowed source MAC address.

#### Format

```
port-sec mode <{ip-based|mac-based}>
```

#### Mode

```
Global Config
```

## 5.6.4 port-sec action

Configure the action to be taken if port security is violated at this port.

- ▶ `none` No action is taken if port security is violated at this port.
- ▶ `port-disable` The port is disabled for traffic if port security is violated.
- ▶ `trap-only` A trap is sent if port security is violated at this port (this port remains open for traffic).

Configure the allowed IP source address for this port.

Configure the allowed MAC source address for this port.

### Format

```
port-sec {action {none|port-disable|trap-only}
         |allowed-ip <IP1> [IP2 [IP3 [IP4 [IP5
           [IP6 [IP7 [IP8 [IP9 [IP10]]]]]]]]
         |allowed-mac <MAC1> [MAC2 [MAC3 [MAC4
           [MAC5 [MAC6 [MAC7 [MAC8 [MAC9
           [MAC10]]]]]]]] } }
```

### Mode

Interface Config

### ■ no port-sec

No action is taken if port security is violated at this port.

### Format

```
no port-sec
```

### Mode

Interface Config



### 5.6.5 port-sec allowed-ip

Enter the allowed IP source address for this port, format: nnn.nnn.nnn.nnn (nnn: decimal number 0..255) (up to 10).

#### Format

```
port-sec allowed-ip <IP Address 1> <IP Address 2>
... <IP Address 10>
```

#### Mode

```
Interface Config
```

### 5.6.6 port-sec allowed-ip add

Enter the allowed IP source address for this port, format: nnn.nnn.nnn.nnn (nnn: decimal number 0..255) (up to 50).

#### Format

```
port-sec allowed-ip add <IP Address 1>
                        <IP Address 2> ... <IP Address 50>
```

#### Mode

```
Interface Config
```

### 5.6.7 port-sec allowed-ip remove

Enter the allowed IP source address for this port, format: nnn.nnn.nnn.nnn (nnn: decimal number 0..255) (up to 50).

#### Format

```
port-sec allowed-ip remove <IP Address 1>  
                               <IP Address 2> ... <IP Address 50>
```

#### Mode

```
Interface Config
```

### 5.6.8 port-sec allowed-mac

Enter the allowed MAC source address for this port, format: nn:nn:nn:nn:nn:nn (n: hexadecimal digit) or format: nn:nn:nn:nn:nn:nn/m (n: hexadecimal digit) (m: decimal digit (1..48)) (up to 10).

#### Format

```
port-sec allowed-mac <MAC Address 1>  
                    <MAC Address 2> ... <MAC Address 10>
```

#### Mode

```
Interface Config
```

### 5.6.9 port-sec allowed-mac add

Enter the allowed MAC source address for this port,  
format: nn:nn:nn:nn:nn:nn (n: hexadecimal digit) or  
format: nn:nn:nn:nn:nn:nn/m  
n: hexadecimal digit, m: decimal digit (1..48)  
(up to 50).

#### Format

```
port-sec allowed-mac add <MAC Address 1>  
                        <MAC Address 2> ... <MAC Address 50>
```

#### Mode

```
Interface Config
```

### 5.6.10 port-sec allowed-mac remove

Enter the allowed MAC source address for this port,  
format: nn:nn:nn:nn:nn:nn (n: hexadecimal digit) or  
format: nn:nn:nn:nn:nn:nn/m  
n: hexadecimal digit, m: decimal digit (1..48)  
(up to 50).

#### Format

```
port-sec allowed-mac remove <MAC Address 1>  
                            <MAC Address 2> ... <MAC Address 50>
```

#### Mode

```
Interface Config
```

### 5.6.11 clear port-sec

Clear the MAC/IP Based Port Security by setting each port's security action (applied when port security is violated) to None. Additionally, the global mode is set to MAC Based.

**Note:** This does not clear the 802.1X Port Security.

#### Format

```
clear port-sec
```

#### Mode

```
User EXEC and Global Config
```

## 5.7 DHCP Relay Commands

These commands configure the DHCP Relay parameters. The commands are divided by functionality into these different groups:

- ▶ Configuration Commands are used to configure features and options of the switch. For every configuration command there is a show command that will display the configuration setting.
- ▶ Show commands are used to display switch settings, statistics and other information.
- ▶ Commands that start with the keyword 'no' (so-called 'no commands') are used to clear some or all of the settings to factory defaults.

## 5.7.1 dhcp-relay

Set different options for BOOTP/DHCP relay and option 82 inclusion.

### Format

```
dhcp-relay
  {opt82
    {operation {disable|enable}}|
    man-id <Manual Remote ID>|
    remote-id-type {client-id|ip|mac|other}}|
    server-address <Server-ID (1..4)> <Server IP
                                     Address>}
```

### Mode

Global Config

#### **dhcp-relay opt82 operation {disable|enable}**

Enable/Disable option 82 globally. Default: enable.

#### **dhcp-relay opt82 man-id <Manual Remote ID>**

Configure the DHCP Relay's Option 82 Manual Value for the Remote ID Type (only effective, if Remote ID is set to "other"). Default: no ID.

#### **dhcp-relay opt82 remote-id-type {client-id|ip|mac|other}**

Configure the DHCP Relay's Option 82 Remote ID Type.  
Default: mac

#### **dhcp-relay server-address <Server ID (1..4)> <Server IP Address>**

Set the server IP address for one of the 4 possible server IDs.  
Default: 0.0.0.0

### ■ **no dhcp-relay**

Clear the DHCP Relay configuration (set all server addresses to 0.0.0.0).

### Format

```
no dhcp-relay
```

### Mode

Global Config

## 5.7.2 dhcp-relay

Set different port specific options for option 82 inclusion.

### Format

```
dhcp-relay {admin-state {disable|enable} |  
            operation {disable|enable} |  
            hirschmann-device {disable|enable} |  
            hirschmann-agent {disable|enable}}
```

### Mode

Interface Config

#### dhcp-relay admin-state {disable|enable}

Enable or disable the DHCP Relay's Admin State on this port.

Default: enable.

**Note:** Make sure that "Active Protocol" is "Relay" for both ports involved in DHCP Relaying (the one connected to DHCP client and the one connected to DHCP server).

#### dhcp-relay operation {disable|enable}

Enable or disable the DHCP Relay's Option 82 on this port. Default: enable.

#### dhcp-relay hirschmann-device {disable|enable}

Enable this parameter if a Hirschmann DHCP client is connected to this port.

- It disables the forwarding of DHCP multicast requests that are received on this port.
- It will send its own DHCP multicast requests to be relayed by the DHCP relay; this will reduce the load in your network.

Disable this parameter if a Non-Hirschmann DHCP client is connected to this port (these devices send normal broadcast DHCP requests; this enables the relaying of DHCP broadcast requests that are received on this port).

#### dhcp-relay hirschmann-agent {disable|enable}

Enable or disable the forwarding of DHCP requests that are received on this port. Enable this parameter if a Hirschmann DHCP client is connected to this port. Default: disable.

Disable this parameter if a Non-Hirschmann DHCP client is connected to this port (these devices send normal broadcast DHCP requests; this enables the relaying of DHCP broadcast requests that

are received on this port)

Enable this parameter if a Hirschmann DHCP client is connected to this port (it will send its own DHCP multicast requests to be relayed by the DHCP relay; this will reduce the load in your network).

### 5.7.3 show dhcp-relay

Display the settings of the BOOTP/DHCP relay.

#### Format

```
show dhcp-relay [opt82 | port {<slot/port>|all} |  
server-address]
```

#### Mode

Privileged EXEC and User EXEC

#### opt82

Show the DHCP Relay's Option 82 settings exclusively.

#### port

Display the DHCP Relay's port-related settings for the specified port exclusively.

#### <slot/port>

Show the DHCP Relay's port-related settings for the specified port exclusively.

#### all

Show the DHCP Relay's port-related settings for all ports.

#### server-address

Display the DHCP Relay's server address settings exclusively.

#### Port

Display the port number in <slot/port> notation.



**Admin State**

Display the DHCP Relay's admin state settings.

Possible values: Disabled, Enabled

**Active Protocol**

Display the DHCP Relay's active protocol settings.

Possible values: Relay, Disabled, Server, Inaccessible

**Option 82**

Display the DHCP Relay's option 82 settings.

Possible values: Disabled, Enabled

**Hirschmann Device**

Display the DHCP Relay's Hirschmann device settings.

Possible values: Disabled, Enabled

## 5.8 DHCP Server Commands

These commands configure the DHCP server parameters. The commands are divided by functionality into these different groups:

- ▶ Configuration Commands are used to configure features and options of the switch. For every configuration command there is a show command that will display the configuration setting.
- ▶ Show commands are used to display switch settings, statistics and other information.
- ▶ Commands that start with the keyword 'no' (so-called 'no commands') clear some or all of the settings to factory defaults.

### 5.8.1 DHCP server configuration example

The example shown below has the following task: The IP address is only to be served, if a request is coming via interface 1/1 with specified Mac address.

```
<Hirschmann PowerMICE> >enable
<Hirschmann PowerMICE> #configure
<Hirschmann PowerMICE> <Config>#dhcp-server operation
enable
<Hirschmann PowerMICE> <Config>#dhcp-server pool add 1
static 192.168.0.10
<Hirschmann PowerMICE> <Config>#dhcp-server pool modify
1 mode interface 1/1
<Hirschmann PowerMICE> <Config>#dhcp-server pool modify
1 mode mac 00:80:63:12:34:56
<Hirschmann PowerMICE> <Config>#dhcp-server pool modify
1 option gateway 192.168.0.1
<Hirschmann PowerMICE> <Config>#dhcp-server pool enable
1
<Hirschmann PowerMICE> <Config>#interface 1/1
<Hirschmann PowerMICE> <interface 1/1>#dhcp-server oper-
ation enable
```

```
<Hirschmann PowerMICE> <config>#dhcp-server pool modify
1 option vendor-specific <f1 08 0a 7e 7e 02 0a 7f 7f 02>
```

This configuration leads to the following result:

```
<Hirschmann PowerMICE> #show dhcp-server pool 1
ID..... 1
Status..... Enabled
Start Address..... 192.168.0.10
End Address..... 192.168.0.10
Leasetime..... 86400
Hirschmann Device..... Disabled
Mode..... Interface(1/1)
MAC..... 00:80:63:12:34:56
Options:
Configpath.....
Gateway..... 192.168.0.1
Subnet Mask..... 255.255.255.0
WINS..... 0.0.0.0
DNS..... 0.0.0.0
Hostname.....
Vendor Specific Information..... "f1 08 0a 7e 7e 02 0a
7f 7f 02"
```

## 5.8.2 show dhcp-server

Display DHCP Server global and interface information.

### Format

```
show dhcp-server
```

### Mode

Privileged EXEC and User EXEC

### DHCP Server

Display the DHCP server operation setting.

Possible values: `Enabled`, `Disabled`

### DHCP Address Probe

Display the DHCP server address probe setting.

Possible values: `Enabled`, `Disabled`

### DHCP, Port-Related Settings:

#### Port

Display the port number in `<slot/port>` notation.

#### Mode

Display the DHCP server interface information.

Possible values: `enable`, `disable`

### DHCP, Pools:

Display the DHCP server pool related information.

### 5.8.3 show dhcp-server operation

Display DHCP Server global information.

#### Format

```
show dhcp-server operation
```

#### Mode

Privileged EXEC and User EXEC

#### DHCP Server

Display the DCHP server operation setting.

Possible values: Enabled, Disabled

#### DHCP Address Probe

Display the DCHP server address probe setting.

Possible values: Enabled, Disabled

### 5.8.4 show dhcp-server port

Display the DCHP port-related settings for all ports or specific port only.

#### Format

```
show dhcp-server port {all | <slot/port>}
```

#### Mode

Privileged EXEC and User EXEC

#### show dhcp-server port all

Display the DCHP port-related settings for all ports.

#### show dhcp-server port <slot/port>

Display the DCHP port-related settings for the specified port only.

### 5.8.5 show dhcp-server pool

Display DHCP server pool information for all pool or detailed information for a specific pool.

#### Format

```
show dhcp-server pool {all | <id>}
```

#### Mode

Privileged EXEC and User EXEC

#### show dhcp-server pool all

Display the DHCP server pool information for all IDs.

#### show dhcp-server pool <id>

Display the DHCP server pool information for the specified ID only.

### 5.8.6 dhcp-server addr-probe

Use this command to enable or disable the probing of allocated addresses with an ICMP Echo request.

#### Format

```
dhcp-server addr-probe {disable|enable}
```

#### Mode

Global Config

#### dhcp-server addr-probe enable

Enable the DHCP server address probe. This is the default.  
The DHCP server will send ICMP echo request before offering an IP.

#### dhcp-server addr-probe disable

Disable the DHCP server address probe.  
The DHCP server will offer an IP without checking if already in use.

### 5.8.7 dhcp-server operation

Enable or disable the DHCP server globally. Default: disable.

#### Format

```
dhcp-server operation {disable|enable}
```

#### Mode

Interface Config

#### dhcp-server operation disable

Disable the DHCP server. This is the default.

#### dhcp-server operation enable

Enable the DHCP server.

### 5.8.8 dhcp-server pool add <id>

Add a pool with a single IP address (static) or with an IP range (dynamic)

#### Format

```
dhcp-server pool {add <id> {static <ipaddr>  
|dynamic <start ipaddr> <end ipaddr>}}
```

#### Mode

Global Config

#### dhcp-server pool add <id> {static <ipaddr>}

Add a pool with a single IP address (static).

#### dhcp-server pool add <id> {dynamic <start ipaddr> <end ipaddr>}

Add a pool with an IP range (dynamic).

### 5.8.9 dhcp-server pool modify <id> mode

Add or delete one or more pool modes.

#### Format

```
dhcp-server pool modify <id> mode
    {interface {all | <slot/port>} 1)
    |mac {none | <macaddr>} 1)
    |clientid {none | <clientid>} 1)
    |relay {none | <ipaddr>}
    |remoteid {none | <remoteid>} 1)
    |circuitid {none | < circuitid >} 1)
    |vlan {none | < vlan id >} }
```

#### Mode

Global Config

**dhcp-server pool modify <id> mode interface all 1)**

Set pool to all interfaces.

**dhcp-server pool modify <id> mode interface <slot/port> 1)**

Set pool to a specific interface.

**dhcp-server pool modify <id> mode mac none 1)**

Use none to remove the mode.

**dhcp-server pool modify <id> mode mac <macaddr> 1)**

Enter macaddr in xx:xx:xx:xx:xx:xx format.

**dhcp-server pool modify <id> mode clientid none 1)**

Use none to remove the mode.

**dhcp-server pool modify <id> mode clientid <clientid> 1)**

Enter clientid in xx:xx:....:xx format.

**dhcp-server pool modify <id> mode relay none**

Use none to remove the mode.

**dhcp-server pool modify <id> mode relay <ipaddr>**

Enter IP address of the relay.



**dhcp-server pool modify <id> mode remoteid none** <sup>1)</sup>

Use none to remove the mode.

**dhcp-server pool modify <id> mode remoteid <remoteid>** <sup>1)</sup>

Enter remoteid in xx:xx:....:xx format.

**dhcp-server pool modify <id> mode circuitid none** <sup>1)</sup>

Use none to remove the mode.

**dhcp-server pool modify <id> mode circuitid <circuitid>** <sup>1)</sup>

Enter circuitid in xx:xx:....:xx format.

**dhcp-server pool modify <id> mode vlan <vlan id>** <sup>1)</sup>

Enter valid VLAN ID.

<sup>1)</sup> Available for pools with single IP address only.

## 5.8.10 dhcp-server pool modify <id> option

Modify pool options.

### Format

```
dhcp-server pool modify <id> option
    {configpath <url> |
    gateway <ipaddr> |
    netmask <netmask> |
    wins <ipaddr> |
    dns <ipaddr> |
    hostname <name>}
    vendor-specific <string>}
```

### Mode

Global Config

#### **dhcp-server pool modify <id> option configpath <url>**

Option configpath. Enter the configpath URL in 'tftp://<servername-or-ip>/<file>' format.

#### **dhcp-server pool modify <id> option gateway <ipaddr>**

Option default gateway. Enter the gateway IP address.

#### **dhcp-server pool modify <id> option netmask <netmask>**

Option netmask. Enter the netmask.

#### **dhcp-server pool modify <id> option wins <ipaddr>**

Option wins. Enter WINS IP address.

#### **dhcp-server pool modify <id> option dns <ipaddr>**

Option DNS. Enter the DNS IP address.

#### **dhcp-server pool modify <id> option hostname <name>**

Option hostname. Enter the host name.

#### **dhcp-server pool modify <id> option vendor-specific <string>**

Option vendor-specific information. Enter vendor specific information as hex in xx:xx: . . . :xx format..

### 5.8.11 dhcp-server pool modify leasetime

Modify pool leasetime. Enter the leasetime in seconds.

#### Format

```
dhcp-server pool modify leasetime <seconds>
```

#### Mode

```
Global Config
```

### 5.8.12 dhcp-server pool modify <id> hirschmann-device

Set this pool to Hirschmann devices only or to all devices.

#### Format

```
dhcp-server pool modify <id> hirschmann-device  
{enable|disable}
```

#### Mode

```
Global Config
```

#### **dhcp-server pool modify <id> hirschmann-device disable**

Use pool for all devices.

#### **dhcp-server pool modify <id> hirschmann-device enable**

Use pool for Hirschmann devices only.

### 5.8.13 dhcp-server pool enable

Enable a specific pool.

#### Format

```
dhcp-server pool enable <id>
```

#### Mode

Global Config

### 5.8.14 dhcp-server pool disable

Disable a specific pool.

#### Format

```
dhcp-server pool disable <id>
```

#### Mode

Global Config

### 5.8.15 dhcp-server pool delete

Delete a specific pool.

#### Format

```
dhcp-server pool delete <id>
```

#### Mode

Global Config

## 5.9 Sub-Ring Commands

These commands configure the sub-ring parameters.

The commands are divided by functionality into these different groups:

- ▶ Configuration commands are used to configure features and options of the switch. For every configuration command there is a show command that will display the configuration setting.
- ▶ Show commands are used to display switch settings, statistics and other information.

### 5.9.1 show sub-ring

Display sub-ring information for all sub-rings or detailed information for a specific sub-ring.

#### Format

```
show sub-ring {all-ids | <id>}
               {id | info | mode | operation | protocol | port |
               summary | ring-name | vlan | mrp-domainID |
               partner-mac}
```

#### Mode

Privileged EXEC and User EXEC

#### show sub-ring

Display the sub-ring information.

#### show sub-ring all-ids

Display the sub-ring information for all existing Sub-Ring IDs.

#### show sub-ring <id>

Display the sub-ring information for the specified ID.

#### id

Display the given Sub-Ring's ID.

**info**

Display status information for the given Sub-Ring ID.

**mode**

Display the switch's mode for the given Sub-Ring ID.

**operation**

Display the switch's operative setting for the given Sub-Ring ID.

**Note:** In case of configuration problems, this value may differ from the administrative setting (may become 'Disabled').

**protocol**

Display the switch's protocol setting for the given Sub-Ring ID.

**Note:** In case of configuration problems, this value may differ from the administrative setting (may become 'Disabled').

**port**

Display the ports for the given Sub-Ring ID.

**summary**

Display a summary for the given Sub-Ring ID.

**ring-name**

Display ring name for the given Sub-Ring ID.

**vlan**

Display the VLAN ID for the given Sub-Ring ID.

**mrp-domainID**

Display the MRP domain ID for the given Sub-Ring ID.

**partner-mac**

Display the partner MAC for the given Sub-Ring ID.

## 5.9.2 sub-ring <id> mode

Configure the switch's Sub-Ring mode for the given ID (manager or redundant-manager).

### Format

```
sub-ring <id> mode {manager |  
                    redundant-manager |  
                    single-manager}
```

### Mode

Global Config

### <id>

Specify the Sub-Ring ID whose settings you want to configure.

### manager

Switch is manager for the given Sub-Ring ID.

### redundant-manager

Switch is redundant-manager for the given Sub-Ring ID.

### single-manager

Switch is single-manager for the given Sub-Ring ID.

### 5.9.3 sub-ring <id> operation

Enable or disable the switch for the given Sub-Ring ID.

#### Format

```
sub-ring <id> operation {enable|disable}
```

#### Mode

Global Config

#### <id>

Specify the Sub-Ring ID whose settings you want to configure.

#### enable

Enable the switch for the given Sub-Ring ID.

#### disable

Disable the switch for the given Sub-Ring ID.

### 5.9.4 sub-ring <id> protocol

Set MRP or FHR as sub-ring protocol for the given Sub-Ring ID.

#### Format

```
sub-ring <id> protocol standard_mrp
```

#### Mode

Global Config

#### <id>

Specify the Sub-Ring ID whose settings you want to configure.

#### standard\_mrp

Set MRP as sub-ring protocol for the given Sub-Ring ID.



### 5.9.5 sub-ring <id> port

Specify the switch's ports for the given Sub-Ring ID.

#### Format

```
sub-ring <id> port <slot/port>
```

#### Mode

```
Global Config
```

#### <id>

Specify the Sub-Ring ID whose settings you want to configure.

#### <slot/port>

Specify the port (in slot/port notation).

### 5.9.6 sub-ring <id> ring-name

Set a ring name for the given Sub-Ring ID.

#### Format

```
sub-ring <id> ring-name <ring-name>
```

#### Mode

```
Global Config
```

#### <id>

Specify the Sub-Ring ID whose settings you want to configure.

#### <ring-name>

Enter a name for the given Sub-Ring ID. The name may be up to 254 characters long and contain only printable characters. If you do not give a name, the current name will be set to an empty string ("").

### 5.9.7 sub-ring <id> vlan

Specify the VLAN for the given Sub-Ring ID.

#### Format

```
sub-ring <id> vlan <0-4042>
```

#### Mode

Global Config

#### <id>

Specify the Sub-Ring ID whose settings you want to configure.

#### <0-4042>

Enter the VLAN for the given Sub-Ring ID  
(min.: 0, max.: 4042, default: 0).

## 5.9.8 sub-ring <id> mrp-domainID

Set an MRP domain ID for the given Sub-Ring ID.

### Format

```
sub-ring <id> mrp-domainID {<id> |  
                                default-domainID}
```

### Mode

Global Config

### <id>

sub-ring <id>: Specify the Sub-Ring ID whose settings you want to configure.

### <id>

Enter an MRP domainID for the given Sub-Ring ID.  
The ID has to be 16 bytes long and contain only printable characters.

### default-domainID

Enter the default MRP domainID for the given Sub-Ring ID.  
The MRP domainID will be set to 255.255.255.255.255.255  
255.255.255.255.255.255.255.255

### 5.9.9 sub-ring delete-ring

Delete all existing Sub-Rings IDs or a specific Sub-Ring ID.

#### Format

```
sub-ring delete-ring {all-ids | <id>}
```

#### Mode

Global Config

#### all-ids

Delete all existing Sub-Ring IDs.

#### <id>

Delete the given Sub-Ring ID. Format: a number in the range 1-2147483647 ( $2^{31} - 1$ ). An ID of 0 is invalid.

### 5.9.10 sub-ring new-ring

Create a new Sub-Ring ID. The configuration will consist of default parameters and its operation will be disabled.

#### Format

```
sub-ring new-ring <id>
```

#### Mode

Global Config

#### <id>

Enter a new Sub-Ring ID. Format: a number in the range 1-2147483647 ( $2^{31} - 1$ ). An ID of 0 is invalid.

## 6 CLI Commands: Security

This chapter provides a detailed explanation of the Security commands. The following Security CLI commands are available in the software Switching Package. Use the security commands to configure security settings for login users and port users.

The commands are divided into these different groups:

- ▶ Show commands are used to display device settings, statistics and other information.
- ▶ Configuration Commands are used to configure features and options of the switch. For every configuration command there is a show command that will display the configuration setting.



# 6.1 Security Commands

## 6.1.1 authentication login

This command creates an authentication login list. The `<listname>` is up to 15 alphanumeric characters and is not case sensitive. Up to 10 authentication login lists can be configured on the switch. When a list is created, the authentication method “local” is set as the first method.

When the optional parameters “Option1”, “Option2” and/or “Option3” are used, an ordered list of methods are set in the authentication login list. If the authentication login list does not exist, a new authentication login list is first created and then the authentication methods are set in the authentication login list. The maximum number of authentication login methods is three. The possible method values are `local`, `radius` and `reject`.

The value of `local` indicates that the user’s locally stored ID and password are used for authentication. The value of `radius` indicates that the user’s ID and password will be authenticated using the RADIUS server. The value of `reject` indicates the user is never authenticated.

To authenticate a user, the authentication methods in the user’s login will be attempted in order until an authentication attempt succeeds or fails.

**Note:** The default login list included with the default configuration can not be changed.

**Note:** When assigning a list to the 'admin' account, include an authentication method that allows administrative access even when remote authentication is unavailable.

### Format

```
authentication login <listname> [method1 [method2  
[method3]]]
```

### Mode

```
Global Config
```

**■ no authentication login**

This command deletes the specified authentication login list.

You will be unable to delete if any of the following conditions are true:

- ▶ The login list name is invalid or does not match an existing authentication login list
- ▶ The specified authentication login list is assigned to any user or to the non configured user for any component
- ▶ The login list is the default login list included with the default configuration and was not created using 'authentication login'.  
The default login list cannot be deleted.

**Format**

```
no authentication login <listname>
```

**Mode**

```
Global Config
```



## 6.1.2 authorization network radius

Use this command to enable the switch to accept VLAN assignment by the RADIUS server.

### Format

```
authorization network radius
```

### Mode

```
Privileged EXEC
```

## ■ no authorization network radius

Use this command to disable the switch to accept VLAN assignment by the RADIUS server.

### Format

```
no authorization network radius
```

### Mode

```
Global Config
```

## 6.1.3 clear dot1x statistics

This command resets the 802.1X statistics for the specified port or for all ports.

### Format

```
clear dot1x statistics {<slot/port> | all}
```

### Mode

```
Privileged EXEC
```

### 6.1.4 clear radius statistics

This command is used to clear all RADIUS statistics.

#### Format

```
clear radius statistics
```

#### Mode

Privileged EXEC

### 6.1.5 dot1x defaultlogin

This command assigns the authentication login list to use for non-configured users for 802.1X port security. This setting is over-ridden by the authentication login list assigned to a specific user if the user is configured locally. If this value is not configured, users will be authenticated using local authentication only.

#### Format

```
dot1x defaultlogin <listname>
```

#### Mode

Global Config

## 6.1.6 dot1x dynamic-vlan enable

Use this command to enable the switch to create VLANs dynamically when a RADIUS-assigned VLAN does not exist in the switch.

### Default

```
disabled
```

### Format

```
dot1x dynamic-vlan enable
```

### Mode

```
Global Config
```

## ■ no dot1x dynamic-vlan enable

Use this command to disable the switch to create VLANs dynamically when a RADIUS-assigned VLAN does not exist in the switch.

### Default

```
disabled
```

### Format

```
no dot1x dynamic-vlan enable
```

### Mode

```
Global Config
```

## 6.1.7 dot1x guest-vlan

This command configures VLAN as guest vlan on an interface. The command specifies an active VLAN as an IEEE 802.1x guest VLAN. The range is 1 to the maximum VLAN ID supported by the platform.

### Format

```
dot1x guest-vlan <vlan-id>
```

### Mode

```
Interface Config
```

### <vlan-id>

Enter an existing VLAN ID.

## ■ no dot1x guest-vlan

This command is used to disable Guest VLAN for the port.

### Format

```
no dot1x guest-vlan
```

### Mode

```
Global Config
```

## 6.1.8 dot1x initialize

This command begins the initialization sequence on the specified port. This command is only valid if the control mode for the specified port is 'auto'. If the control mode is not 'auto' an error will be returned.

### Format

```
dot1x initialize <slot/port>
```

### Mode

Privileged EXEC

## 6.1.9 dot1x login

This command assigns the specified authentication login list to the specified user for 802.1X port security. The <user> parameter must be a configured user and the <list-name> parameter must be a configured authentication login list.

### Format

```
dot1x login <user> <listname>
```

### Mode

Global Config

## 6.1.10 dot1x mac-auth-bypass

This command enables the MAC-authorized-bypass on that interface.

### Default

```
disabled
```

### Format

```
dot1x mac-auth-bypass
```

### Mode

```
Interface Config
```

## ■ no dot1x mac-auth-bypass

This command disables the MAC-authorized-bypass on that interface.

### Default

```
disabled
```

### Format

```
no dot1x mac-auth-bypass
```

### Mode

```
Interface Config
```

## 6.1.11 dot1x max-req

This command sets the maximum number of times the authenticator state machine on this port will transmit an EAPOL EAP Request/Identity frame before timing out the supplicant. The <count> value must be in the range 1 - 10.

### Default

2

### Format

```
dot1x max-req <count>
```

### Mode

Interface Config

### ■ no dot1x max-req

This command sets the maximum number of times the authenticator state machine on this port will transmit an EAPOL EAP Request/Identity frame before timing out the supplicant.

### Format

```
no dot1x max-req
```

### Mode

Interface Config

## 6.1.12 dot1x max-users

Use this command to set the maximum number of clients supported on an interface when MAC-based 802.1X authentication is enabled on the port. The count value is in the range 1-16 and the default value is 16.

### Default

16

### Format

```
dot1x max-users <count>
```

### Mode

Interface Config

### ■ no dot1x max-users

The 'no' form of this command resets the maximum number of clients allowed to its default value of 16.

### Format

```
no dot1x max-users
```

### Mode

Interface Config



## 6.1.13 dot1x port-control

This command sets the authentication mode to be used on the specified port. The control mode may be one of the following.

- ▶ `force-unauthorized`: The authenticator PAE unconditionally sets the controlled port to unauthorized. Thus the port is always blocked.
- ▶ `force-authorized`: The authenticator PAE unconditionally sets the controlled port to authorized. Thus the port is always opened.
- ▶ `auto`: The authenticator PAE sets the controlled port mode to reflect the outcome of the authentication exchanges between the supplicant, authenticator and the authentication server. The port mode is controlled by the protocol.
- ▶ `mac-based`: Enable MAC-based 802.1X authentication on the port.

### Default

```
force-authorized
```

### Format

```
dot1x port-control {force-unauthorized | force-authorized | auto | mac-based}
```

### Mode

```
Interface Config
```

### ■ no dot1x port-control

This command sets the port-control mode for the specified port to the default mode (`force-authorized`).

### Format

```
no dot1x port-control
```

### Mode

```
Interface Config
```

## 6.1.14 dot1x port-control all

This command sets the authentication mode to be used on all ports. The control mode may be one of the following.

- ▶ `force-unauthorized`: The authenticator PAE unconditionally sets the controlled port to unauthorized. Thus the ports are always blocked.
- ▶ `force-authorized`: The authenticator PAE unconditionally sets the controlled port to authorized. Thus the ports are always open.
- ▶ `auto`: The authenticator PAE sets the controlled port mode to reflect the outcome of the authentication exchanges between the supplicant, authenticator and the authentication server. The port mode is controlled by the protocol.
- ▶ `mac-based`: Enable the MAC-based 802.1X authentication on the port.

### Default

```
force-authorized
```

### Format

```
dot1x port-control all {force-unauthorized | force-authorized | auto | mac-based}
```

### Mode

```
Global Config
```

### ■ no dot1x port-control all

This command sets the port-control mode for all the ports to the default mode (`force-authorized`).

### Format

```
no dot1x port-control all
```

### Mode

```
Global Config
```

### 6.1.15 dot1x re-authenticate

This command begins the re-authentication sequence on the specified port. This command is only valid if the control mode for the specified port is 'auto'. If the control mode is not 'auto' an error will be returned.

#### Format

```
dot1x re-authenticate <slot/port>
```

#### Mode

```
Privileged EXEC
```

### 6.1.16 dot1x re-authentication

This command enables re-authentication of the supplicant for the specified port.

#### Default

```
disabled
```

#### Format

```
dot1x re-authentication
```

#### Mode

```
Interface Config
```

#### ■ no dot1x re-authentication

This command disables re-authentication of the supplicant for the specified port.

#### Format

```
no dot1x re-authentication
```

#### Mode

```
Interface Config
```

## 6.1.17 dot1x safe-vlan

Use this command to enable the safe-vlan assignment on the switch.

**Note:** This command is available for the RS20/RS30/RS40, RSB20, MS20/MS30, RSR20/RSR30, MACH100, MACH1000, PowerMICE, MACH4000, OCTOPUS devices.

### Default

disabled

### Format

```
dot1x safe-vlan
```

### Mode

Global Config

## ■ no dot1x safe-vlan

Use this command to disable the safe-vlan assignment on the switch.

### Default

disabled

### Format

```
no dot1x safe-vlan
```

### Mode

Global Config

## 6.1.18 dot1x system-auth-control

This command is used to enable the dot1x authentication support on the switch. By default, the authentication support is disabled. While disabled, the dot1x configuration is retained and can be changed, but is not activated.

### Default

```
disabled
```

### Format

```
dot1x system-auth-control
```

### Mode

```
Global Config
```

## ■ no dot1x system-auth-control

This command is used to disable the dot1x authentication support on the switch.

### Format

```
no dot1x system-auth-control
```

### Mode

```
Global Config
```

## 6.1.19 dot1x timeout

This command sets the value, in seconds, of the timer used by the authenticator state machine on this port. Depending on the token used and the value (in seconds) passed, various timeout configurable parameters are set. The following tokens are supported.

- ▶ **reauth-period**: Sets the value, in seconds, of the timer used by the authenticator state machine on this port to determine when re-authentication of the supplicant takes place. The reauth-period must be a value in the range 1 - 65535.

- ▶ **quiet-period:** Sets the value, in seconds, of the timer used by the authenticator state machine on this port to define periods of time in which it will not attempt to acquire a supplicant. The quiet-period must be a value in the range 0 - 65535.
- ▶ **tx-period:** Sets the value, in seconds, of the timer used by the authenticator state machine on this port to determine when to send an EAPOL EAP Request/Identity frame to the supplicant. The quiet-period must be a value in the range 1 - 65535.
- ▶ **supp-timeout:** Sets the value, in seconds, of the timer used by the authenticator state machine on this port to timeout the supplicant. The supp-timeout must be a value in the range 1 - 65535.
- ▶ **server-timeout:** Sets the value, in seconds, of the timer used by the authenticator state machine on this port to timeout the authentication server. The supp-timeout must be a value in the range 1 - 65535.

## Defaults

```
reauth-period: 3600 seconds
quiet-period: 60 seconds
tx-period: 30 seconds
supp-timeout: 30 seconds
server-timeout: 30 seconds
```

## Format

```
dot1x timeout {{reauth-period <seconds>} | {quiet-
period <seconds>} | {tx-period <seconds>} | {supp-
timeout <seconds>} | {server-timeout <seconds>}}
```

## Mode

```
Interface Config
```

### ■ **no dot1x timeout**

This command sets the value, in seconds, of the timer used by the authenticator state machine on this port to the default values. Depending on the token used, the corresponding default values are set.

## Format

```
no dot1x timeout {reauth-period | quiet-period |
tx-period | supp-timeout | server-timeout}
```

## Mode

```
Interface Config
```

## 6.1.20 dot1x timeout guest-vlan-period

Use this command to configure the timeout value for the guest-vlan-period. The time, in seconds, for which the authenticator waits to see if any EAPOL packets are received on a port before authorizing the port and placing the port in the guest vlan (if configured). The guest vlan timer is only relevant when guest vlan has been configured on that specific port.

Default guest-vlan-period: 90 seconds.

### Default

90

### Format

```
dot1x timeout guest-vlan-period <seconds>
```

### Mode

Interface Config

### <seconds>

Enter an integer in the range of 1-300.

### ■ no dot1x timeout guest-vlan-period

The 'no' form of this command resets the timeout value for the guest-vlan-period to its default value (90 seconds).

### Format

```
no dot1x timeout guest-vlan-period
```

### Mode

Interface Config

## 6.1.21 dot1x unauthenticated-vlan

Use this command to configure the unauthenticated VLAN associated with the specified interface. The unauthenticated VLAN ID can be a valid VLAN ID from 0 to maximum supported VLAN ID. The unauthenticated VLAN must be statically configured in the VLAN database to be operational. By default, the unauthenticated VLAN is 0, i.e. invalid and not operational.

### Default

0

### Format

```
dot1x unauthenticated-vlan <vlan-id>
```

### Mode

Interface Config

### <vlan-id>

Enter an existing VLAN ID.

### ■ no dot1x unauthenticated-vlan

The 'no' form of this command resets the value for the unauthenticated VLAN to its default value.

### Format

```
no dot1x unauthenticated-vlan
```

### Mode

Interface Config



## 6.1.22 dot1x user

This command adds the specified user to the list of users with access to the specified port or all ports. The <user> parameter must be a configured user.

### Format

```
dot1x user <user> {<slot/port> | all}
```

### Mode

```
Global Config
```

### ■ no dot1x user

This command removes the user from the list of users with access to the specified port or all ports.

### Format

```
no dot1x user <user> {<slot/port> | all}
```

### Mode

```
Global Config
```

## 6.1.23 ip ssh protocol

Use this command to configure the IP secure shell (SSH) parameters, the first and the optional second SSH protocol level).

Possible settings: v1, v2 or v1 & v2.

### Format

```
ip ssh [protocol <protocollevel1>
        [<protocollevel2>]]
```

### Default

```
2 1
```

### Mode

Privileged Exec

### <protocollevel1>

Enter the first SSH Protocol Level (Version).

Possible values: 1, 2

### <protocollevel2>

Optionally enter the second SSH Protocol Level (Version).

Possible values: 1, 2

### ■ no ip ssh

This command sets IP secure shell (SSH) parameters to default value.

### Format

```
no ip ssh
```

### Mode

Privileged Exec

## 6.1.24 radius accounting mode

This command is used to enable the RADIUS accounting function.

### Default

```
disabled
```

### Format

```
radius accounting mode
```

### Mode

```
Global Config
```

### ■ no radius accounting mode

This command is used to set the RADIUS accounting function to the default value - i.e. the RADIUS accounting function is disabled.

### Format

```
no radius accounting mode
```

### Mode

```
Global Config
```

## 6.1.25 radius server host

This command is used to configure the RADIUS authentication and accounting server.

If the 'auth' token is used, the command configures the IP address to use to connect to a RADIUS authentication server. Up to 3 servers can be configured per RADIUS client. If the maximum number of configured servers is reached, the command will fail until one of the servers is removed by executing the no form of the command. If the optional <port> parameter is

used, the command will configure the UDP port number to use to connect to the configured RADIUS server. In order to configure the UDP port number, the IP address must match that of a previously configured RADIUS authentication server. The port number must lie between 1 - 65535, with 1812 being the default value.

If the 'acct' token is used, the command configures the IP address to use for the RADIUS accounting server. Only a single accounting server can be configured. If an accounting server is currently configured, it must be removed from the configuration using the no form of the command before this command succeeds. If the optional <port> parameter is used, the command will configure the UDP port to use to connect to the RADIUS accounting server. The IP address specified must match that of a previously configured accounting server. If a port is already configured for the accounting server then the new port will replace the previously configured value. The port must be a value in the range 1 - 65535, with 1813 being the default value.

### Format

```
radius server host {auth | acct} <ipaddr> [<port>]
```

### Mode

```
Global Config
```

#### ■ no radius server host

This command is used to remove the configured RADIUS authentication server or the RADIUS accounting server. If the 'auth' token is used, the previously configured RADIUS authentication server is removed from the configuration. Similarly, if the 'acct' token is used, the previously configured RADIUS accounting server is removed from the configuration. The <ipaddr> parameter must match the IP address of the previously configured RADIUS authentication / accounting server.

### Format

```
no radius server host {auth | acct} <ipaddress>
```

### Mode

```
Global Config
```

## 6.1.26 radius server key

This command is used to configure the shared secret between the RADIUS client and the RADIUS accounting / authentication server. Depending on whether the 'auth' or 'acct' token is used, the shared secret will be configured for the RADIUS authentication or RADIUS accounting server. The IP address provided must match a previously configured server. When this command is executed, the secret will be prompted. The secret must be an alphanumeric value not exceeding 20 characters.

### Format

```
radius server key {auth | acct} <ipaddr>
```

### Mode

```
Global Config
```

## 6.1.27 radius server msgauth

This command enables the message authenticator attribute for a specified server.

### Default

```
radius server msgauth <ipaddr>
```

### Mode

```
Global Config
```

## 6.1.28 radius server primary

This command is used to configure the primary RADIUS authentication server for this RADIUS client. The primary server is the one that is used by default for handling RADIUS requests. The remaining configured servers are only used if the primary server cannot be reached. A maximum of three servers can be configured on each client. Only one of these servers can be configured as the primary. If a primary server is already configured prior to this command being executed, the server specified by the IP address used in this command will become the new primary server. The IP address must match that of a previously configured RADIUS authentication server.

### Format

```
radius server primary <ipaddr>
```

### Mode

```
Global Config
```

## 6.1.29 radius server retransmit

This command sets the maximum number of times a request packet is retransmitted when no response is received from the RADIUS server. The retries value is an integer in the range of 1 to 15.

### Default

4

### Format

```
radius server retransmit <retries>
```

### Mode

Global Config

### ■ no radius server retransmit

This command sets the maximum number of times a request packet is re-transmitted, when no response is received from the RADIUS server, to the default value, i.e. 10.

### Format

```
no radius server retransmit
```

### Mode

Global Config

### 6.1.30 radius server timeout

This command sets the timeout value (in seconds) after which a request must be retransmitted to the RADIUS server if no response is received. The timeout value is an integer in the range of 1 to 30.

#### Default

6

#### Format

```
radius server timeout <seconds>
```

#### Mode

Global Config

#### ■ no radius server timeout

This command sets the timeout value (in seconds) after which a request must be retransmitted to the RADIUS server if no response is received, to the default value, i.e. 6.

#### Format

```
no radius server timeout
```

#### Mode

Global Config

### 6.1.31 show radius accounting

This command is used to display the configured RADIUS accounting mode, accounting server and the statistics for the configured accounting server.

#### Format

```
show radius accounting [statistics <ipaddr>]
```

#### Mode

Privileged EXEC and User EXEC



If the optional token 'statistics <ipaddr>' is not included, then only the accounting mode and the RADIUS accounting server details are displayed.

**Mode**

Enabled or disabled

**IP Address**

The configured IP address of the RADIUS accounting server

**Port**

The port in use by the RADIUS accounting server

**Secret Configured**

Yes or No

If the optional token 'statistics <ipaddr>' is included, the statistics for the configured RADIUS accounting server are displayed. The IP address parameter must match that of a previously configured RADIUS accounting server. The following information regarding the statistics of the RADIUS accounting server is displayed.

**Accounting Server IP Address**

IP Address of the configured RADIUS accounting server

**Round Trip Time**

The time interval, in hundredths of a second, between the most recent Accounting-Response and the Accounting-Request that matched it from the RADIUS accounting server.

**Requests**

The number of RADIUS Accounting-Request packets sent to this accounting server. This number does not include retransmissions.

**Retransmission**

The number of RADIUS Accounting-Request packets retransmitted to this RADIUS accounting server.

**Responses**

The number of RADIUS packets received on the accounting port from this server.

**Malformed Responses**

The number of malformed RADIUS Accounting-Response packets received from this server. Malformed packets include packets with an

invalid length. Bad authenticators and unknown types are not included as malformed accounting responses.

**Bad Authenticators**

The number of RADIUS Accounting-Response packets containing invalid authenticators received from this accounting server.

**Pending Requests**

The number of RADIUS Accounting-Request packets sent to this server that have not yet timed out or received a response.

**Timeouts**

The number of accounting timeouts to this server.

**Unknown Types**

The number of RADIUS packets of unknown types, which were received from this server on the accounting port.

**Packets Dropped**

The number of RADIUS packets received from this server on the accounting port and dropped for some other reason.

## 6.1.32 show authentication

This command displays the ordered authentication methods for all authentication login lists.

### Format

```
show authentication
```

### Mode

```
Privileged EXEC and User EXEC
```

### Authentication Login List

This displays the authentication login listname.

### Method 1

This displays the first method in the specified authentication login list, if any.

### Method 2

This displays the second method in the specified authentication login list, if any.

### Method 3

This displays the third method in the specified authentication login list, if any.

### 6.1.33 show authentication users

This command displays information about the users assigned to the specified authentication login list. If the login is assigned to non-configured users, the user “default” will appear in the user column.

#### Format

```
show authentication users <listname>
```

#### Mode

Privileged EXEC and User EXEC

#### User

This field displays the user assigned to the specified authentication login list.

#### Component

This field displays the component (User or 802.1X) for which the authentication login list is assigned.

### 6.1.34 show dot1x

This command is used to show a summary of the global dot1x configuration, summary information of the dot1x configuration for a specified port or all ports, the detailed dot1x configuration for a specified port and the dot1x statistics for a specified port - depending on the tokens used.

#### Format

```
show dot1x [{summary {<slot/port> | all} | {detail  
<slot/port>} | {statistics <slot/port>}]
```

#### Mode

Privileged EXEC and User EXEC

If none of the optional parameters are used, the global dot1x configuration summary is displayed.

**Administrative mode**

Indicates whether authentication control on the switch is enabled or disabled.

**VLAN Assignment Mode**

Indicates whether the VLAN Assignment Mode is enabled or disabled.

**Dynamic VLAN Creation Mode**

Indicates whether the Dynamic VLAN Creation Mode is enabled or disabled.

**Safe VLAN Mode**

Indicates whether the Safe VLAN Mode is enabled or disabled.

If the optional parameter 'summary {<slot/port> | all}' is used, the dot1x configuration for the specified port or all ports are displayed.

**Port**

The interface whose configuration is displayed.

**Control Mode**

The configured control mode for this port. Possible values are  
`force-unauthorized | force-authorized | auto | mac-based`

**Operating Control Mode**

The control mode under which this port is operating. Possible values are  
`authorized | unauthorized`

**Reauthentication Enabled**

Indicates whether re-authentication is enabled on this port

**Key Transmission Enabled**

Indicates if the key is transmitted to the supplicant for the specified port

If the optional parameter 'detail <slot/port>' is used, the detailed dot1x configuration for the specified port are displayed.

**Port**

The interface whose configuration is displayed

## Protocol Version

The protocol version associated with this port. The only possible value is 1, corresponding to the first version of the dot1x specification.

## PAE Capabilities

The port access entity (PAE) functionality of this port. Possible values are Authenticator or Supplicant.

## Control Mode

Display the state of the Control Mode. Possible values: auto, forceauthorized, ....

## Authenticator PAE State

Current state of the authenticator PAE state machine. Possible values are Initialize, Disconnected, Connecting, Authenticating, Authenticated, Aborting, Held, ForceAuthorized, and ForceUnauthorized.

## Backend Authentication State

Current state of the backend authentication state machine. Possible values are Request, Response, Success, Fail, Timeout, Idle, and Initialize.

## Quiet Period

The timer used by the authenticator state machine on this port to define periods of time in which it will not attempt to acquire a supplicant. The value is expressed in seconds and will be in the range 0 and 65535.

## Transmit Period

The timer used by the authenticator state machine on the specified port to determine when to send an EAPOL EAP Request/Identity frame to the supplicant. The value is expressed in seconds and will be in the range of 1 and 65535.

## Guest VLAN ID

Display the Guest VLAN ID. Default value: 0.

## Guest VLAN Period (secs)

Display the Guest VLAN Period. Default value: 90 seconds.

## Supplicant Timeout

The timer used by the authenticator state machine on this port to timeout the supplicant. . The value is expressed in seconds and will be in the range of 1 and 65535.

## Server Timeout

The timer used by the authenticator on this port to timeout the authentication server. The value is expressed in seconds and will be in the range of 1 and 65535.

## Maximum Requests

The maximum number of times the authenticator state machine on this port will retransmit an EAPOL EAP Request/Identity before timing out the supplicant. The value will be in the range of 1 and 10.

## VLAN Id

Display the VLAN Id.

## VLAN Assigned Reason

Display the state of the VLAN Assigned Reason parameter.  
Possible values: RADIUS, Not Assigned, ....

## Reauthentication Period

The timer used by the authenticator state machine on this port to determine when reauthentication of the supplicant takes place. The value is expressed in seconds and will be in the range of 1 and 65535.

## Reauthentication Enabled

Indicates if reauthentication is enabled on this port. Possible values are 'True" or "False".

## Key Transmission Enabled

Indicates if the key is transmitted to the supplicant for the specified port. Possible values are True or False.

## Control Direction

Indicates the control direction for the specified port or ports. Possible values are both or in.

## Maximum Users

Display the value of Maximum Users.

**Unauthenticated VLAN ID**

Display the value of Unauthenticated VLAN ID

**Session Timeout**

Display the value of Session Timeout

**Session Termination Action**

Display the value of Session Termination Action

**MAC-Authorized-Bypass**

Display the value of MAC-Authorized-Bypass

If the optional parameter 'statistics <slot/port>' is used, the dot1x statistics for the specified port are displayed.

**Port**

The interface whose statistics are displayed.

**EAPOL Frames Received**

The number of valid EAPOL frames of any type that have been received by this authenticator.

**EAPOL Frames Transmitted**

The number of EAPOL frames of any type that have been transmitted by this authenticator.

**EAPOL Start Frames Received**

The number of EAPOL start frames that have been received by this authenticator.

**EAPOL Logoff Frames Received**

The number of EAPOL logoff frames that have been received by this authenticator.

**Last EAPOL Frame Version**

The protocol version number carried in the most recently received EAPOL frame.

**Last EAPOL Frame Source**

The source MAC address carried in the most recently received EAPOL frame.



**EAP Response/Id Frames Received**

The number of EAP response/identity frames that have been received by this authenticator.

**EAP Response Frames Received**

The number of valid EAP response frames (other than resp/id frames) that have been received by this authenticator.

**EAP Request/Id Frames Transmitted**

The number of EAP request/identity frames that have been transmitted by this authenticator.

**EAP Request Frames Transmitted**

The number of EAP request frames (other than request/identity frames) that have been transmitted by this authenticator.

**Invalid EAPOL Frames Received**

The number of EAPOL frames that have been received by this authenticator in which the frame type is not recognized.

**EAP Length Error Frames Received**

The number of EAPOL frames that have been received by this authenticator in which the frame type is not recognized.

**6.1.35 show dot1x users**

This command displays 802.1X port security user information for locally configured users.

**Format**

```
show dot1x users <slot/port>
```

**Mode**

Privileged EXEC and User EXEC

**User**

Users configured locally to have access to the specified port.

## 6.1.36 show dot1x clients

This command displays 802.1X port security client information for locally configured clients.

### Format

```
show dot1x clients <slot/port>
```

### Mode

Privileged EXEC

### Logical Interface

Display the Logical Interface.

### Interface

Display the Interface.

### User Name

Display the User Name.

### Supp MAC Address

Display the Supp MAC Address.

### Session Time

Display the Session Time.

Value range: ....

### Vlan Id

Display the Vlan Id.

Possible values: ....

### Vlan Assigned Reason

Display the Vlan Assigned Reason.

Possible values: RADIUS, ....

### Session Timeout

Display the Session Timeout.

Value range: ....

### Session Termination Action

Display the Session Termination Action.

Possible values: Reauthenticate, ....

## 6.1.37 show ip ssh

This command displays the IP secure shell (SSH) information.

### Format

```
show ip ssh
```

### Mode

Privileged EXEC

### Administrative Mode

Display the SSH administrative mode setting.

Possible values: Disabled, Enabled.

### Protocol Levels

Display the SSH protocol levels setting.

Possible values: Versions 1 and 2, Version 1, Version 2  
(default setting: Versions 1 and 2).

### SSH Sessions Currently Active

Display the number of SSH sessions being currently set up.

Possible values: 1..5.

### Max SSH Sessions Allowed

Display the max. number of SSH sessions that can be set up simultaneously.

Possible values: 1..5 (default setting: 5).

### SSH Timeout

Display the SSH timeout in minutes.

Possible values: 1..160 (default setting: 5).

## 6.1.38 show radius

This command is used to display the various RADIUS configuration items for the switch as well as the configured RADIUS servers. If the optional token 'servers' is not included, the following RADIUS configuration items will be displayed.

### Format

```
show radius [servers]
```

### Mode

Privileged EXEC and User EXEC

### Primary Server IP Address

Indicates the configured server currently in use for authentication

### Number of configured servers

The configured IP address of the authentication server

### Max number of retransmits

The configured value of the maximum number of times a request packet is retransmitted

### Timeout Duration

The configured timeout value, in seconds, for request re-transmissions

### Accounting Mode

Yes or No

If the optional token 'servers' is included, the following information regarding the configured RADIUS servers is displayed.

### IP Address

IP Address of the configured RADIUS server

### Port

The port in use by this server

### Type

Primary or secondary

### Secret Configured

Yes / No

### 6.1.39 show radius statistics

This command is used to display the statistics for RADIUS or configured server . To show the configured RADIUS server statistic, the IP Address specified must match that of a previously configured RADIUS server. On execution, the following fields are displayed.

#### Format

```
show radius statistics [ipaddr]
```

#### Mode

Privileged EXEC and User EXEC

If ip address is not specified than only Invalid Server Address field is displayed. Otherwise other listed fields are displayed.

#### Invalid Server Addresses

The number of RADIUS Access-Response packets received from unknown addresses.

#### Server IP Address

#### Round Trip Time

The time interval, in hundredths of a second, between the most recent Access-Reply | Access-Challenge and the Access-Request that matched it from the RADIUS authentication server.

#### Access Requests

The number of RADIUS Access-Request packets sent to this server. This number does not include retransmissions.

#### Access Retransmission

The number of RADIUS Access-Request packets retransmitted to this RADIUS authentication server.

#### Access Accepts

The number of RADIUS Access-Accept packets, including both valid and invalid packets, which were received from this server.

**Access Rejects**

The number of RADIUS Access-Reject packets, including both valid and invalid packets, which were received from this server.

**Access Challenges**

The number of RADIUS Access-Challenge packets, including both valid and invalid packets, which were received from this server.

**Malformed Access Responses**

The number of malformed RADIUS Access-Response packets received from this server. Malformed packets include packets with an invalid length. Bad authenticators or signature attributes or unknown types are not included as malformed access responses.

**Bad Authenticators**

The number of RADIUS Access-Response packets containing invalid authenticators or signature attributes received from this server.

**Pending Requests**

The number of RADIUS Access-Request packets destined for this server that have not yet timed out or received a response.

**Timeouts**

The number of authentication timeouts to this server.

**Unknown Types**

The number of RADIUS packets of unknown types, which were received from this server on the authentication port.

**Packets Dropped**

The number of RADIUS packets received from this server on the authentication port and dropped for some other reason.

## 6.1.40 show users authentication

This command displays all user and all authentication login information. It also displays the authentication login list assigned to the default user.

### Format

```
show users authentication
```

### Mode

```
Privileged EXEC
```

### User

This field lists every user that has an authentication login list assigned.

### System Login

This field displays the authentication login list assigned to the user for system login.

### 802.1x Port Security

This field displays the authentication login list assigned to the user for 802.1X port security.

## 6.1.41 users login

This command assigns the specified authentication login list to the specified user for system login. The `<user>` must be a configured `<user>` and the `<listname>` must be a configured login list.

If the user is assigned a login list that requires remote authentication, all access to the interface from all CLI, web, and telnet sessions will be blocked until the authentication is complete.

**Note:** Note that the login list associated with the 'admin' user can not be changed to prevent accidental lockout from the switch.

### Format

```
users login <user> <listname>
```

### Mode

```
Global Config
```

### user

Enter user name.

### listname

Enter an alphanumeric string of not more than 15 characters.

**Note:** When assigning a list to the 'admin' account, include an authentication method that allows administrative access even when remote authentication is unavailable (use 'authentication login `<listname>` [`method1` [`method2` [`method3`]]]').



## 6.2 HTTP Commands

### 6.2.1 ip http secure-port

This command is used to set the sslt port where port can be 1-65535 and the default is port 443.

#### Default

443

#### Format

```
ip http secure-port <portid>
```

#### Mode

Privileged EXEC

#### ■ no ip http secure-port

This command is used to reset the sslt port to the default value.

#### Format

```
no ip http secure-port
```

#### Mode

Privileged EXEC

## 6.2.2 ip http secure-protocol

This command is used to set protocol levels (versions). The protocol level can be set to TLS1, SSL3 or to both TLS1 and SSL3.

### Default

SSL3 and TLS1

### Format

```
ip http secure-protocol [SSL3] [TLS1]
```

### Mode

Privileged EXEC

### 6.2.3 ip http server

This command enables access to the switch's graphical user interface (web-based interface) via a web browser. When access is enabled, the user can login to the switch from the web-based interface. When access is disabled, the user cannot login to the switch's web server.

Disabling the web-based interface takes effect immediately. All interfaces are effected.

**Note:** First enable HTTP before enabling HTTPS.  
First disable the HTTPS web server before disabling HTTP.  
See "ip https server" on page 557.

#### Default

enabled

#### Format

```
ip http server
```

#### Mode

Privileged EXEC

#### ■ no ip http server

This command disables access to the switch's graphical user interface (web-based interface) via a web browser. When access is disabled, the user cannot login to the switch's web server.

#### Format

```
no ip http server
```

#### Mode

Privileged EXEC

## 6.2.4 show ip http

This command displays the http settings for the switch.

### Format

```
show ip http
```

### Mode

Privileged EXEC and User EXEC

### Secure-Server Administrative Mode

This field indicates whether the administrative mode of secure HTTP is enabled or disabled.

### Secure Protocol Level

The protocol level may have the values of SSL3, TSL1, or both SSL3 and TSL1.

### Secure Port

This field specifies the port configured for SSLT.

### HTTP Mode

This field indicates whether the HTTP mode is enabled or disabled.

## 6.2.5 ip https server

This command is used to turn on the HTTPS server 3.

This command enables access to the switch's graphical user interface (web-based interface) via a web browser. When access is enabled, the user can login to the switch from the web interface. When access is disabled, the user cannot login to the switch's web server.

**Note:** First enable HTTP before enabling HTTPS.

First disable the HTTPS web server before disabling HTTP.

See "ip http server" on page 555.

### Default

disabled

### Format

```
ip https server
```

### Mode

Privileged EXEC

### ■ no ip https server

This command is used to turn off the HTTPS server 3.

This command disables access to the switch's graphical user interface (web-based interface) via a web browser. When access is disabled, the user cannot login to the switch's web server.

### Format

```
no ip https server
```

### Mode

Privileged EXEC

## 6.2.6 ip https port

This command is used to set the HTTPS listening port. The acceptable range is 1-65535. The default is 443

**Note:** After this setting, re-enable the HTTPS server. See “ip http server” on page 555.

### Default

443

### Format

```
ip https port <port_no>
```

### Mode

Privileged EXEC

### ■ no ip https port

This command is used to reset the https port to the default value.

### Format

```
no ip https port
```

### Mode

Privileged EXEC

## 6.2.7 ip https certgen

Use this command to generate an X509/PEM certificate in-place.

### Format

```
ip https certgen
```

### Mode

Privileged EXEC

## 6.2.8 show ip https

This command displays the status of the HTTPS server (status of the server and port number).

### Format

```
show ip https
```

### Mode

Privileged EXEC and User EXEC

### HTTPS Mode

Displays the status of the HTTPS server (enabled, disabled).

### HTTPS Port

Displays the port number of the HTTPS server (default: 443).





## 7 Appendix- VLAN Example

LAN switches can segment networks into logically defined virtual workgroups. This logical segmentation is commonly referred to as a virtual LAN (VLAN). This logical segmentation of devices provides better LAN administration, security, and management of broadcast activity over the network. Virtual LANs have become an integral feature of switched LAN solutions.

**The VLAN example below demonstrates a simple VLAN configuration.**

If a single port is a member of VLANs 2, 3 and 4, the port expects to see traffic tagged with either VLAN 2, 3 or 4.

The PVID (Port Virtual Identification) could be something entirely different, for example '12' and things would still work fine, just so incoming traffic was tagged.

Example:

Project A = (VLAN2, ports 1,2)

Project B = (VLAN3, ports 3,4)

Project C = (VLAN4, ports 5,6)

Project P = (VLAN 9, port 7)

VLAN	Command
create VLAN 2	vlan database vlan 2 exit config interface 1/1 vlan participation include 2 exit interface 1/2 vlan participation include 2 exit

*Table 16: Creating VLANs*

VLAN	Command
create VLAN 3	<pre> vlan database vlan 3 exit config interface 0/3 vlan participation include 3 exit interface 0/4 vlan participation include 3 exit </pre>
create VLAN 4	<pre> vlan database vlan 4 exit config interface 0/5 vlan participation include 4 exit interface 0/6 vlan participation include 4 exit </pre>
create VLAN 9	<pre> vlan database vlan 9 exit config interface 0/1 vlan participation include 9 exit interface 0/2 vlan participation include 9 exit interface 0/3 vlan participation include 9 exit interface 0/4 vlan participation include 9 exit interface 0/5 vlan participation include 9 exit interface 0/6 vlan participation include 9 exit interface 0/7 vlan participation include 9 exit </pre>

*Table 16: Creating VLANs*

## 7.1 SOLUTION 1

All traffic entering the ports is tagged traffic. Since the traffic is tagged, the PVID configuration for each port is not a concern.

- ▶ The network card configuration for devices on Project A must be set to tag all traffic with 'VLAN 2'
- ▶ The network card configuration for devices on Project B must be set to tag all traffic with 'VLAN 3'
- ▶ The network card configuration for devices on Project C must be set to tag all traffic with 'VLAN 4'
- ▶ The network card configuration for devices on Project P must be set to tag all traffic with 'VLAN 9'



## 7.2 SOLUTION 2

The network card configuration for devices on Project A, B and C should be set to NOT tag traffic.

To take care of these untagged frames configure the following:

- ▶ vlan pvid 2 (in interface 0/1)
- ▶ vlan pvid 2 (in interface 0/2)
- ▶ vlan pvid 3 (in interface 0/3)
- ▶ vlan pvid 3 (in interface 0/4)
- ▶ vlan pvid 4 (in interface 0/5)
- ▶ vlan pvid 4 (in interface 0/6)



## 8 Glossary

### Numerics

**802.1D.** The IEEE designator for Spanning Tree Protocol (STP). STP, a link management protocol, is part of the 802.1D standard for media access control bridges. Using the spanning tree algorithm, STP provides path redundancy while preventing endless loops in a network. An endless loop is created by multiple active paths between stations where there are alternate routes between hosts. To establish path redundancy, STP creates a logical tree that spans all of the switches in an extended network, forcing redundant paths into a standby, or blocked, state. STP allows only one active path at a time between any two network devices (this prevents the loops) but establishes the redundant links as a backup if the initial link should fail. If STP costs change, or if one network segment in the STP becomes unreachable, the spanning tree algorithm reconfigures the spanning tree topology and reestablishes the link by activating the standby path. Without spanning tree in place, it is possible that both connections may be simultaneously live, which could result in an endless loop of traffic on the LAN.

**802.1P.** The IEEE protocol designator for Local Area Network (LAN). This Layer 2 network standard improves support of time critical traffic, and limits the extent of high bandwidth multicast traffic within a bridged LAN. To do this, 802.1P defines a methodology for introducing traffic class priorities. The 802.1P standard allows priority to be defined in all 802 MAC protocols (Ethernet, Token Bus, Token Ring), as well as in FDDI. For protocols (such as Ethernet) that do not contain a priority field, 802.1P specifies a method for indicating frame priority based on the new fields defined in the 802.1Q (VLAN) standard.

**802.1Q VLAN.** The IEEE protocol designator for Virtual Local Area Network (VLAN). This standard provides VLAN identification and quality of service (QoS) levels. Four bytes are added to an Ethernet frame to allow eight priority levels (QoS) and to identify up to 4096 VLANs. See “VLAN” on page 580 for more information.

### A

**Address Resolution Protocol.** An Internet Protocol that dynamically maps Internet addresses to physical (hardware) addresses on a LAN.

**Advanced Network Device Layer/Software.** Hirschmann term for the Device Driver level.

**Aging.** When an entry for a node is added to the lookup table of a switch, it is given a timestamp. Each time a packet is received from a node, the timestamp is updated. The switch has a user-configurable timer that erases the entry after a certain length of time with no activity from that node.

### **Application Programming**

**Interface.** An API is an interface used by an programmer to interface with functions provided by an application.

**AVL tree.** Binary tree having the property that for any node in the tree, the difference in height between the left and right subtrees of that node is no more than 1.

## **B**

**BPDU.** See “Bridge Protocol Data Unit” on page 568.

**BootP.** See “Bootstrap Protocol.” on page 568.

**Bootstrap Protocol.** An Internet protocol that enables a diskless workstation to discover its own IP address, the IP address of a BootP server on the network, and a file to be loaded into memory to boot the machine. This enables the workstation to boot without requiring a hard or floppy disk drive.

**Bridge Protocol Data Unit.** BPDU is the IEEE 802.1D MAC Bridge Management protocol that is the

standard implementation of STP (Spanning Tree Protocol). It uses the STP algorithm to insure that physical loops in the network topology do not result in logical looping of network traffic. Using one bridge configured as root for reference, the BPDU switches one of two bridges forming a network loop into standby mode, so that only one side of a potential loop passes traffic. By examining frequent 802.1d configuration updates, a bridge in the standby mode can switch automatically into the forward mode if the other bridge forming the loop fails.

## **C**

**Checksum.** A simple error-detection scheme in which each transmitted message is identified with a numerical value based on the number of set bits in the message. The receiving station then applies a formula to the message and checks to make sure the accompanying numerical value is the same. If not, the receiver can assume that the message has been corrupted.

**CLI.** See “Command Line Interface” on page 568.

**Command Line Interface.** CLI is a line-item interface for configuring systems.

**Complex Programmable Logic Device.** CPLD is a programmable circuit on which a logic network can



be programmed after its construction.

**CPLD.** See “Complex Programmable Logic Device.” on page 568.

## D

**DAPI.** See “Device Application Programming Interface” on page 569.

**Device Application Programming Interface.** DAPI is the software interface that facilitates communication of both data and control information between the Application Layer and HAPI, with support from System Support.

**DHCP.** See “Dynamic Host Configuration Protocol.” on page 569.

**Differentiated Services.** Diffserv is a protocol for specifying and controlling network traffic by class so that certain types of traffic get precedence - for example, voice traffic, which requires a relatively uninterrupted flow of data, might get precedence over other kinds of traffic. Differentiated Services is the most advanced method for managing traffic in terms of what is called Class of Service (CoS). Unlike the earlier mechanisms of 802.1P tagging and Type of Service (ToS), Differentiated Services avoids simple priority tagging and depends on more complex policy or rule

statements to determine how to forward a given network packet. An analogy is made to travel services, in which a person can choose among different modes of travel - train, bus, airplane - degree of comfort, the number of stops on the route, standby status, the time of day or period of year for the trip, and so forth. For a given set of packet travel rules, a packet is given one of 64 possible forwarding behaviors - known as per hop behaviors (PHBs). A six-bit field, known as the Differentiated Services Code Point (DSCP), in the Internet Protocol (Internet Protocol) header specifies the per hop behavior for a given flow of packets. Differentiated Services and the Class of Service approach provide a way to control traffic that is both more flexible and more scalability than the Quality of Service approach.

**Diffserv.** See “Differentiated Services.” on page 569..

**Dynamic Host Configuration Protocol.** DHCP is a protocol for assigning dynamic IP addresses to devices on a network. With dynamic addressing, a device can have a different IP address every time it connects to the network. In some systems, the device's IP address can even change while it is still connected. DHCP also supports a mix of static and dynamic IP addresses. Dynamic addressing simplifies network administration because the software tracks IP

addresses rather than requiring an administrator to manage the task. A new computer can be added to a network without the hassle of manually assigning it a unique IP address.

## E

**EEPROM.** See “Electronically Erasable Programmable Read Only Memory” on page 570.

**Electronically Erasable Programmable Read Only Memory.** EEPROM is also known as Flash memory. This is re-programmable memory.

## F

**Fast STP.** A high-performance Spanning Tree Protocol. See “STP” on page 579 for more information.

**FIFO.** First In First Out.

**Flash Memory.** See “EEPROM” on page 570.

**Flow Control.** The process of adjusting the flow of data from one network device to another to ensure that the receiving device can handle all of the incoming data. This is particularly important where the sending device is capable of sending data much faster than the receiving device can receive it. There are many flow control mechanisms. One of the most common flow control protocols for

asynchronous communication is called xon-xoff. In this case, the receiving device sends a an “xoff” message to the sending device when its buffer is full. The sending device then stops sending data. When the receiving device is ready to receive more data, it sends an “xon” signal.

**Forwarding.** When a frame is received on an input port on a switch, the address is checked against the lookup table. If the lookup table has recorded the destination address, the frame is automatically forwarded on an output port.

**Frame Check Sequence.** The extra characters added to a frame for error detection and correction. FCS is used in X.25, HDLC, Frame Relay, and other data link layer protocols.

## G

**GARP.** See “Generic Attribute Registration Protocol.” on page 571.

**GARP Information Propagation.**

GIP is the propagation of information between GARP participants for the same application in a bridge is carried out by a GIP component.

**GARP Multicast Registration Protocol.** GMRP provides a mechanism that allows Bridges and end stations to dynamically register (and subsequently, de-register)

Group membership information with the MAC Bridges attached to the same LAN segment, and for that information to be disseminated across all Bridges in the Bridged LAN that support Extended Filtering Services. The operation of GMRP relies upon the services provided by the GARP.

**GARP VLAN Registration**

**Protocol.** GVRP allows workstations to request admission to a particular VLAN for multicast purposes.

**GE.** See “Gigabit Ethernet” on page 571.

**General Purpose Chip-select Machine.** GPCM provides interfacing for simpler, lower-performance memory resources and memory mapped-devices. The GPCM does not support bursting and is used primarily for boot-loading.

**Generic Attribute Registration**

**Protocol.** GARP provides a generic attribute dissemination capability that is used by participants in GARP Applications (called GARP Participants) to register and de-register attribute values with other GARP Participants within a Bridged LAN. The definition of the attribute types, the values that they can carry, and the semantics that are associated with those values when registered are specific to the

operation of the GARP Application concerned.

**Gigabit Ethernet.** A high-speed Ethernet connection.

**GIP.** See “GARP Information Propagation” on page 570.

**GMRP.** See “GARP Multicast Registration Protocol” on page 570.

**GPCM.** See “General Purpose Chip-select Machine” on page 571.

**GVD.** GARP VLAN Database.

**GVRP.** See “GARP VLAN Registration Protocol.” on page 571.

**H**

**.h file.** Header file in C code. Contains function and coding definitions.

**HAPI.** See “Hardware Abstraction Programming Interface” on page 571.

**Hardware Abstraction**

**Programming Interface.** HAPI is the module that contains the NP specific software that interacts with the hardware.

**hop count.** The number of routers that a data packet passes through on its way to its destination.

**I**

**ICMP.** See “Internet Control Message Protocol” on page 572.

**IGMP.** See “Internet Group Management Protocol” on page 572.

**IGMP Snooping.** A series of operations performed by intermediate systems to add logic to the network to optimize the flow of multicast traffic; these intermediate systems (such as Layer 2 switches) listen for IGMP messages and build mapping tables and associated forwarding filters, in addition to reducing the IGMP protocol traffic. See “Internet Group Management Protocol” on page 572 for more information.

### **Internet Control Message**

**Protocol.** ICMP is an extension to the Internet Protocol (IP) that supports packets containing error, control, and informational messages. The PING command, for example, uses ICMP to test an Internet connection.

### **Internet Group Management**

**Protocol.** IGMP is the standard for IP Multicasting on the Internet. IGMP is used to establish host memberships in particular multicast groups on a single network. The mechanisms of the protocol allow a host to inform its local router, using Host Membership Reports, that it wants to receive messages addressed to a specific multicast group. All hosts conforming to Level 2 of the IP Multicasting specification require IGMP.

**IP.** See “Internet Protocol” on page 572.

**IP Multicasting.** Sending out data to distributed servers on the MBone (Multicast Backbone). For large amounts of data, IP Multicast is more efficient than normal Internet transmissions because the server can broadcast a message to many recipients simultaneously. Unlike traditional Internet traffic that requires separate connections for each source-destination pair, IP Multicasting allows many recipients to share the same source. This means that just one set of packets is transmitted for all the destinations.

**Internet Protocol.** The method or protocol by which data is sent from one computer to another on the Internet. Each computer (known as a host) on the Internet has at least one IP address that uniquely identifies it among all other computers on the Internet. When you send or receive data (for example, an e-mail note or a Web page), the message gets divided into little chunks called packets. Each of these packets contains both the sender's Internet address and the receiver's address. Any packet is sent first to a gateway computer that understands a small part of the Internet. The gateway computer reads the destination address and forwards the packet to an adjacent gateway that in turn reads the destination address and so forth across the Internet until one

gateway recognizes the packet as belonging to a computer within its immediate neighborhood or domain. That gateway then forwards the packet directly to the computer whose address is specified.

Because a message is divided into a number of packets, each packet can, if necessary, be sent by a different route across the Internet. Packets can arrive in a different order than they were sent. The Internet Protocol just delivers them. It's up to another protocol, the Transmission Control Protocol (TCP) to put them back in the right order. IP is a connectionless protocol, which means that there is no continuing connection between the end points that are communicating. Each packet that travels through the Internet is treated as an independent unit of data without any relation to any other unit of data. (The reason the packets do get put in the right order is because of TCP, the connection-oriented protocol that keeps track of the packet sequence in a message.) In the Open Systems Interconnection (OSI) communication model, IP is in Layer 3, the Networking Layer. The most widely used version of IP today is IP version 4 (IPv4). However, IP version 6 (IPv6) is also beginning to be supported. IPv6 provides for much longer addresses and therefore for the possibility of many more Internet users. IPv6 includes the capabilities of IPv4 and any

server that can support IPv6 packets can also support IPv4 packets.

## J

**Joint Test Action Group.** An IEEE group that specifies test framework standards for electronic logic components.

**JTAG.** See “Joint Test Action Group” on page 573.

## L

**LAN.** See “Local Area Network” on page 574.

**LDAP.** See “Lightweight Directory Access Protocol” on page 573.

**Lightweight Directory Access Protocol.** A set of protocols for accessing information directories. LDAP is based on the standards contained within the X.500 standard, but is significantly simpler. Unlike X.500, LDAP supports TCP/IP, which is necessary for any type of Internet access. Although not yet widely implemented, LDAP should eventually make it possible for almost any application running on virtually any computer platform to obtain directory information, such as e-mail addresses and public keys. Because LDAP is an open protocol, applications need not worry about the type of server hosting the directory.

**Learning.** The bridge examines the Layer 2 source addresses of every frame on the attached networks (called listening) and then maintains a table, or cache, of which MAC addresses are attached to each of its ports.

**Link-State.** In routing protocols, the declared information about the available interfaces and available neighbors of a router or network. The protocol's topological database is formed from the collected link-state declarations.

**LLDP.** The IEEE 802.1AB standard for link layer discovery in Ethernet networks provides a method for switches, routers and access points to advertise their identification, configuration and capabilities to neighboring devices that store the data in a MIB (management information base). Link layer discovery allows a network management system to model the topology of the network by interrogating the MIB databases in the devices.

**Local Area Network.** A group of computers that are located in one area and are connected by less than 1,000 feet of cable. A typical LAN might interconnect computers and peripherals on a single floor or in a single building. LANs can be connected together, but if modems and telephones connect two or more LANs, the larger network constitutes

what is called a WAN or Wide Area Network.

## M

**MAC.** (1) Medium Access Control. In LANs, the sublayer of the data link control layer that supports medium-dependent functions and uses the services of the physical layer to provide services to the logical link control (LLC) sublayer. The MAC sublayer includes the method of determining when a device has access to the transmission medium. (2) Message Authentication Code. In computer security, a value that is a part of a message or accompanies a message and is used to determine that the contents, origin, author, or other attributes of all or part of the message are as they appear to be. (*IBM Glossary of Computing Terms*)

### **Management Information Base.**

When SNMP devices send SNMP messages to the management console (the device managing SNMP messages), it stores information in the MIB.

**MBONE.** See “Multicast Backbone” on page 575.

**MDC.** Management Data Clock.

**MDI.** Management Data Interface.

**MDIO.** Management Data Input/Output.

**MDIX.** Management Dependent Interface Crossover.

**MIB.** See “Management Information Base” on page 574.

**MOSPF.** See “Multicast OSPF” on page 575.

**MPLS.** See “Multi-Protocol Label Switching” on page 575.

**Multicast Backbone.** The MBONE is a virtual network. It is layered on top of portions of the physical Internet to support routing of IP multicast packets since that function has not yet been integrated into many production routers. The network is composed of islands that can directly support IP multicast, such as multicast LANs like Ethernet, linked by virtual point-to-point links called “tunnels”. The tunnel endpoints are typically workstation-class machines having operating system support for IP multicast and running the “mrouted” multicast routing daemon.

**Multicasting.** To transmit a message to specific recipients across a network. A simple example of multicasting is sending an e-mail message to a mailing list. Teleconferencing and videoconferencing also use multicasting, but require more robust protocols and networks. Standards are being developed to support multicasting over a TCP/IP network such as the Internet. These standards, IP Multicast and Mbone,

will allow users to easily join multicast groups. Note that multicasting refers to sending a message to a select group whereas broadcasting refers to sending a message to everyone connected to a network. The terms multicast and narrowcast are often used interchangeably, although narrowcast usually refers to the business model whereas multicast refers to the actual technology used to transmit the data.

**Multicast OSPF.** With a MOSPF specification, an IP Multicast packet is routed based both on the packet's source and its multicast destination (commonly referred to as source/destination routing). As it is routed, the multicast packet follows a shortest path to each multicast destination. During packet forwarding, any commonality of paths is exploited; when multiple hosts belong to a single multicast group, a multicast packet will be replicated only when the paths to the separate hosts diverge. See “P” on page 577 for more information.

**Multiplexing.** A function within a layer that interleaves the information from multiple connections into one connection.

### **Multi-Protocol Label Switching.**

An initiative that integrates Layer 2 information about network links (bandwidth, latency, utilization) into Layer 3 (IP) within a particular

autonomous system—or ISP—in order to simplify and improve IP-packet exchange. MPLS gives network operators a great deal of flexibility to divert and route traffic around link failures, congestion, and bottlenecks. From a QoS standpoint, ISPs will better be able to manage different kinds of data streams based on priority and service plan. For instance, those who subscribe to a premium service plan, or those who receive a lot of streaming media or high-bandwidth content can see minimal latency and packet loss. When packets enter into a MPLS-based network, Label Edge Routers (LERs) give them a label (identifier). These labels not only contain information based on the routing table entry (i.e., destination, bandwidth, delay, and other metrics), but also refer to the IP header field (source IP address), Layer 4 socket number information, and differentiated service. Once this classification is complete and mapped, different packets are assigned to corresponding Labeled Switch Paths (LSPs), where Label Switch Routers (LSRs) place outgoing labels on the packets. With these LSPs, network operators can divert and route traffic based on data-stream type and Internet-access customer.

**MT-RJ connector.** A type of fiber-optic cable jack that is similar in shape and concept to a standard telephone jack, enabling duplex

fiber-optic cables to be plugged into compatible devices as easily as plugging in a telephone cable.

**MUX.** See “Multiplexing” on page 575.

## N

**NM.** Network Module.

**nm.** Nanometer (1 x 10<sup>9</sup>) meters.

**NP.** Network Processor.

## O

### **Open Systems Interconnection.**

OSI is a seven (7) layer architecture model for communications systems developed by the ISO for the interconnection of data communications systems. Each layer uses and builds on the services provided by those below it.

**Operating System Application Programming Interface.** OSAPI is a module within the System Support software that provides a set of interfaces to OS support functions.

**OS.** Operating System.

**OSAPI.** See “Operating System Application Programming Interface” on page 576.

**OSI.** See “Open Systems Interconnection” on page 576.



### P

**PDU.** See “Protocol Data Unit” on page 577.

**PHY.** The OSI Physical Layer: The physical layer provides for transmission of cells over a physical medium connecting two ATM devices. This physical layer is comprised of two sublayers: the Physical Medium Dependent (PMD) sublayer, and the Transmission Convergence (TC) sublayer.

**PMC.** Packet Mode Channel.

**Port Mirroring.** Also known as a roving analysis port. This is a method of monitoring network traffic that forwards a copy of each incoming and outgoing packet from one port of a network switch to another port where the packet can be studied. A network administrator uses port mirroring as a diagnostic tool or debugging feature, especially when fending off an attack. It enables the administrator to keep close track of switch performance and alter it if necessary. Port mirroring can be managed locally or remotely. An administrator configures port mirroring by assigning a port from which to copy all packets and another port where those packets will be sent. A packet bound for or heading away from the first port will be forwarded onto the second port as well. The administrator places a protocol analyzer on the port receiving the

mirrored data to monitor each segment separately. The analyzer captures and evaluates the data without affecting the client on the original port. The monitor port may be a port on the same SwitchModule with an attached RMON probe, a port on a different SwitchModule in the same hub, or the SwitchModule processor. Port mirroring can consume significant CPU resources while active. Better choices for long-term monitoring may include a passive tap like an optical probe or an Ethernet repeater.

**Protocol Data Unit.** PDU is a packet of data passed across a network. The term implies a specific layer of the OSI model and a specific protocol.

### Q

**QoS.** See “Quality of Service” on page 577.

**Quality of Service.** QoS is a networking term that specifies a guaranteed level of throughput. Throughput is the amount of data transferred from one device to another or processed in a specified amount of time - typically, throughputs are measured in bytes per second (Bps).

## R

### **Real-Time Operating System.**

RTOS is a component of the OSAPI module that abstracts operating systems with which other systems can interface.

**RFC.** Request For Comment.

**RMON.** Short for remote monitoring, a network management protocol that allows network information to be gathered at a single workstation. Whereas SNMP gathers network data from a single type of Management Information Base (MIB), RMON 1 defines nine additional MIBs that provide a much richer set of data about network usage. For RMON to work, network devices, such as hubs and switches, must be designed to support it. The newest version of RMON, RMON 2, provides data about traffic at the network layer in addition to the physical layer. This allows administrators to analyze traffic by protocol.

**RP.** Rendezvous Point. Used with IP Multicast.

**RPU.** Remote Power Unit.

**RTOS.** See “Real-Time Operating System” on page 578.

## S

**SDL.** Synchronous Data Link.

**Simple Network Management Protocol.** SNMP is the protocol governing network management and the monitoring of network devices and their functions. It is not necessarily limited to TCP/IP networks. The versions have the following differences:

*SNMPv1* (full): Security is based on community strings.

*SNMPsec* (historic): Security is based on parties. Few, if any, vendors implemented this version of the protocol, which is now largely forgotten.

*SNMPv2p* (historic): For this version, much work was done to update the SNMPv1 protocol and the SMIv1, and not just security. The result was updated protocol operations, new protocol operations and data types, and party-based security from SNMPsec.

*SNMPv2c* (experimental): This version of the protocol is called community string-based SNMPv2. It is an update of the protocol operations and data types of SNMPv2p, and uses community-based security from SNMPv1.

*SNMPv2u* (experimental): This version of the protocol uses the protocol operations and data types of SNMPv2c and security based on users.

*SNMPv2\** (experimental): This version combined the best features

of SNMPv2p and SNMPv2u. (It is also called SNMPv2star.) The documents defining this version were never published as RFCs.

*SNMPv3* (proposed): This version of the protocol is a combination of user-based security and the protocol operations and data types from SNMPv2p and support for proxies. The security is based on that found in SNMPv2u and SNMPv2\*, and updated after much review. The documents defining this protocol will soon be published as RFCs.

**SimpleX signaling.** SX is one of IEEE 802.3's designations for media. For example, 1000SX indicates 1000 gigabit Ethernet over "short haul" or "short wavelength" optical fiber.

**SMC1.** A model of Serial Management Controller from Motorola.

**SMII.** Serial Media Independent Interface.

**SNMP.** See "Simple Network Management Protocol" on page 578.

**SODIMM.** Small Outline Dual Inline Memory Module.

**SRAM.** Static Random Access Memory.

**STP.** Spanning Tree Protocol. See "802.1D" on page 567 for more information.

## T

**TBI.** Ten Bit Interface.

**Telnet.** A character-based UNIX application that enables users with a Telnet server account to log on to a UNIX computer and utilize its resources.

**TFTP.** See "Trivial File Transfer Protocol" on page 579.

### **Trivial File Transfer Protocol.**

TFTP is a simple form of the File Transfer Protocol (FTP). TFTP uses the User Datagram Protocol (UDP, a direct protocol used to communicate datagrams over a network with little error recovery) and provides no security features. It is often used by servers to boot diskless workstations, X-terminals, and routers.

**Trunking.** The process of combining a set of trunks that are traffic-engineered as a unit for the establishment of connections between switching systems in which all of the communications paths are interchangeable.

## U

**UPM.** User Programmable Machine.

**UPMA.** The first of two UPMs in Motorola's MPC855T processor.

**UPMB.** The second of two UPMs in Motorola's MPC855T processor.

**USP.** An abbreviation that represents Unit, Slot, Port.

## V

### **Virtual Local Area Network.**

Operating at the Data Link Layer (Layer 2 of the OSI model), the VLAN is a means of parsing a single network into logical user groups or organizations, as if they physically resided on a dedicated LAN segment of their own. In reality, this virtually defined community may have individual members peppered across a large, extended LAN. The VLAN identifier is part of the 802.1Q tag, which is added to an Ethernet frame by an 802.1Q-compliant switch or router. Devices recognizing 802.1Q-tagged frames maintain appropriate tables to track VLANs. The first three bits of the 802.1Q tag are used by 802.1P to establish priority for the packet.

**VLAN.** See “Virtual Local Area Network” on page 580.

**vMAN.** Virtual Metropolitan Area Network.

## W

**WAN.** See “Wide Area Network” on page 580.

**Web.** Also known as World-Wide Web (WWW) or W3. An Internet

client-server system to distribute information, based upon the hypertext transfer protocol (HTTP).

**Wide Area Network.** A WAN is a computer network that spans a relatively large geographical area. Typically, a WAN consists of two or more local-area networks (LANs).

## X

**X.500.** A directory standard that enables applications like e-mail to access information that can either be central or distributed. The benefit of a directory is the ability to minimize the impact on the user of changes to a network. The standard is broken down under subsequent standards, as follows:

*X.501* Models

*X.509* Authentication framework

*X.511* Abstract service definition

*X.518* Procedures for distributed operation

*X.519* Protocol specifications

*X.520* Selected attribute types

*X.521* Selected object types

**XModem.** One of the most popular file transfer protocols (FTPs). Xmodem is fairly effective at detecting errors. It sends blocks of data together with a checksum and then waits for acknowledgment of the block's receipt. The waiting

slows down the rate of data transmission considerably, but it ensures accurate transmission. Xmodem can be implemented either in software or in hardware. Many modems, and almost all communications software packages, support Xmodem. However, it is useful only at relatively slow data transmission speeds (less than 4,800 bps). Enhanced versions of Xmodem that work at higher transmission speeds are known as Ymodem and Zmodem.



## 9 Index

- A**
- addport 177
  - address-conflict 296
  - adminmode 178
  - arc 458
  - areaid 25
  - authentication login 511
  - authorization network radius 513
  - auto-disable reason 179
  - auto-disable timer 180
  - auto-negotiate 181
  - auto-negotiate all 182
- B**
- boot skip-aca-on-boot 297, 297
  - bridge address-learning 103
  - bridge address-relearn detect operation 104
  - bridge address-relearn detect threshold 104
  - bridge aging-time 105
  - bridge duplex-mismatch-detect operation 106
  - bridge fast-link-detection 106
  - bridge framesize 56
  - bridge vlan-learning 107
  - broadcasts
    - broadcast storm recovery mode 261, 262, 264
- C**
- cable-crossing 183
  - cablestatus 298
  - classofservice dot1pmapping 87
  - classofservice ip-dscp-mapping 88
  - classofservice trus 89
  - clear arp-table-switch 299
  - clear commands
    - clear arp-table-switch 299
    - clear config 300
    - clear pass 302
    - clear traplog 303, 304
    - clear vlan 304
  - clear config 300
  - clear config factory 300
  - clear counters 300
  - clear dot1x statistics 513
  - clear eventlog 298
  - clear hiper-ring 301
  - clear igmpsnooping 301
  - clear inlinepower 398
  - clear link-aggregation 303
  - clear lldp config all 340
  - clear mac-addr-table 302
  - clear pass 302
  - clear port-sec 484
  - clear radius statistics 514
  - clear ring-coupling 304
  - clear sfp-white-list 313
  - clear signal-contact 303
  - clear traplog 304
  - clear vlan 304
  - Competence Center 593
  - config commands
    - config lags adminmode 197
    - config lags linktrap 198
    - config lags name 199
    - config loginsession 285
    - config port admin-mode 255, 256
    - config port linktrap 257, 258
    - config port physical-mode 260
    - config switchconfig broadcast 261, 262, 264
    - config switchconfig flowcontrol 265, 266
    - config users add 290, 291
    - config users delete 289, 290, 291
    - config users passwd 292
    - config vlan add 267
    - config vlan delete 267
    - config vlan garp jointime 199, 200, 201, 202, 203, 204, 205
    - config vlan garp leavealltime 207
    - config vlan garp leavetime 206
    - config vlan interface acceptframe 269, 270, 275
    - config vlan name 272
    - config vlan participation 273, 274
    - config vlan ports ingressfilter 271, 276
    - config vlan ports pvid 277, 279
    - config vlan ports tagging 278, 280
  - config port autoneg 199
  - config switchconfig flowcontrol 265, 266
  - config users delete 289, 290, 291, 292
  - config users passwd 289, 290, 291, 292
  - config vlan delete 267
  - config vlan ports acceptframe 279
  - config vlan ports ingressfilter 270, 275, 276, 277
  - configuration reset 300

config-watchdog	305	dot1x port-control	521
copy	305	dot1x port-control all	522
copy nvram clibanner	311	dot1x re-authenticate	523
copy nvram startup-config	313	dot1x re-authentication	523
copy system bootcode	313	dot1x safe-vlan	524
copy system image	313	dot1x system-auth-control	525
copy system running-config	313	dot1x timeout	525
copy nvram capture	308	dot1x user	529
copy nvram capture aca		duplex settings	260
capture	308	dvlan-tunnel ethertype	94
copy nvram clibanner	308		
copy nvram errorlog	309	<b>E</b>	
copy nvram script	309	ethernet-ip	120
copy nvram traplog	310		
copy system running-config	310	<b>F</b>	
		fast-hiper-ring	469
<b>D</b>		flow control	265, 266
debug tcpdump filter delete	84	frame acceptance mode	269, 270, 275
debug tcpdump filter list	83		
debug tcpdump filter show	83	<b>G</b>	
debug tcpdump help	81	Global Config Mode	45
debug tcpdump start cpu	81	GVRP	
debug tcpdump start cpu filter	82	join time	199, 200, 201, 202, 203, 204,
debug tcpdump stop	82	205	
deleteport	185	leave time	206
deleteport all	185		
device configuration commands	201	<b>H</b>	
device-status connection-error	314	hiper-ring	463
device-status monitor	315	hiper-ring mode	463
DHCP server configuration example	490	hiper-ring port primary	464
dhcp-relay	486, 487	hiper-ring port secondary	464
dhcp-server addr-probe	494	hiper-ring recovery-delay	465
dhcp-server operation	495		
dhcp-server pool add	495	<b>I</b>	
dhcp-server pool delete	500	iec61850-mms	121
dhcp-server pool disable	500	IEEE 802.1Q	269, 270, 275
dhcp-server pool enable	500	ingress filtering	271, 276
dhcp-server pool modify hirschmann-device		inlinepower (Global Config)	397
499		inlinepower (Interface Config)	398
dhcp-server pool modify mode	496	inlinepower budget slot	400
dhcp-server pool modify option	498	inlinepower threshold slot	401
dhcp-server pool modify leasetime	499	inlinepower trap slot	401
digital-input	107	Interface Config Mode	46
digital-output	109	inventory	231, 232, 233, 235, 236, 237, 239,
dip-switch operation	186	240,	511
disconnect	285	ip http secure-port	553
dot1x defaultlogin	514	ip http secure-protocol	554
dot1x dynamic-vlan enable	515	ip http server	555
dot1x guest-vlan	516	ip https certgen	558
dot1x initialize	517	ip https port	558
dot1x login	517	ip https server	557
dot1x mac-auth-bypass	518	ip ssh protocol	530
dot1x max-req	519		
dot1x max-users	520		



**J**

join time 199, 200, 201, 202, 203, 204, 205

**L**

## LAGs

enabling or disabling 197

link traps 198

name 199

summary information 244

leave time 206, 207

Line Config Mode 46

Link Aggregation(802.3ad) Commands 97

link aggregations. See LAGs

## link traps

interface 257, 258

LAG 198

link-aggregation 196

link-aggregation adminmode 197

link-aggregation linktrap 198

link-aggregation name 199

link-aggregation staticcapability 97

lldp 336

LLDP - Link Layer Discovery Protocol 324

lldp admin-state 340

lldp chassis tx-interval 339

lldp config chassis admin-state 337

lldp config chassis notification-interval 337

lldp config chassis re-init-delay 338

lldp config chassis tx-delay 338

lldp config chassis tx-hold-mult 339

lldp fdb-mode 341

lldp hm-mode 341

lldp max-neighbors 342

lldp med 343

lldp med al 344

lldp med confignotification 344

lldp med confignotification all 345

lldp med faststartrepeatcount 346

lldp med transmit-tlv 347

lldp med transmit-tlv all 348

lldp notification 349

lldp tlv gmrp 352

lldp tlv igmp 352

lldp tlv link-aggregation 349

lldp tlv mac-phy-config-state 349

lldp tlv max-frame-size 350

lldp tlv mgmt-addr 350

lldp tlv pnio 350

lldp tlv pnio-alias 351

lldp tlv pnio-mrp 351

lldp tlv port-desc 351

lldp tlv portsec 353

lldp tlv port-vlan 352

lldp tlv protocol 353

lldp tlv ptp 353

lldp tlv sys-cap 354

lldp tlv sys-desc 354

lldp tlv sys-name 354

lldp tlv vlan-name 355

logging buffered 164

logging buffered wrap 165

logging cli-command 166

logging console 167

logging host 168

logging host reconfigure 169

logging host remove 169

logging snmp-requests get operation 169

logging snmp-requests get severity 170

logging snmp-requests set operation 170

logging snmp-requests set severity 171

logging syslog 171

logging syslog port 172

logical slot/port 26

logout 316

logout command 316

**M**

mac notification (Global Config) 190

mac notification (Interface Config) 191

macaddr 25

macfilter 187

macfilter adddest 188

macfilter adddest all 189

media-module 184

media-module remove 184

mode dvlan-tunnel 95

monitor session 192

monitor session mode 194

monitor session source/destination 195

mrp current-domain 455

mrp delete-domain 457

mrp new-domain 457

**N**

name 355

network javascriptmode 123

network mgmt\_vlan 85

network mgmt-access add 124

network mgmt-access delete 124

network mgmt-access modify 125

network mgmt-access operation 126

network mgmt-access status 126

network parms 127

network priority 128

network protocol 127

no dhcp-relay 486

no lldp 336

no sntp 361

- no snmp anycast address 362, 363, 369
- no snmp client server 365
- no snmp client server primary 366, 367, 368
- no storm-control broadcast 261
  
- P**
- passwords
  - changing user 292
  - resetting all 302
- PDUUs 199, 200, 201, 202, 203, 204, 205, 207
- ping 316
- ping command 314, 315, 316, 317
- PoE - Power over Ethernet 396
- Port monitor 402
- port-monitor (Global Config) 407
- port-monitor (Interface Config) 407
- port-monitor action 408
- port-monitor condition crc-fragment (Global Config) 413
- port-monitor condition crc-fragment (Interface Config) 413
- port-monitor condition link-flap (Global Config) 412
- port-monitor condition link-flap (Interface Config) 412
- port-monitor overload-detection (Global Config) 409
- port-monitor overload-detection (Interface Config) 409
- ports
  - administrative mode 255, 256
  - frame acceptance mode 269, 270, 275
  - information 243
  - ingress filtering 271, 276
  - link traps 257, 258
  - physical mode 260
  - tagging 278, 280
  - VLAN IDs 277, 279
  - VLAN information 251
- port-sec action 480
- port-sec allowed-ip 481
- port-sec allowed-ip add 481
- port-sec allowed-ip remove 482
- port-sec allowed-mac 482
- port-sec allowed-mac add 483
- port-sec allowed-mac remove 483
- port-sec mode 479
- Privileged Exec Mode 45
- profinetio 129
- Protocol Data Units. See PDUUs
- PTP - Precision Time Protocol 371
- ptp clock-mode 377
- ptp operation 378
- ptp sync-lower-bound 378
- ptp sync-upper-bound 379
- ptp v1 burst 385
- ptp v1 operation 385
- ptp v1 preferred-master 379
- ptp v1 re-initialize 380
- ptp v1 subdomain-name 380
- ptp v1 sync-interval 381
- ptp v2bc announce-interval 386
- ptp v2bc announce-timeout 387
- ptp v2bc asymmetry 389
- ptp v2bc delay-mechanism 387
- ptp v2bc domain 383
- ptp v2bc network-protocol 388
- ptp v2bc operation 386
- ptp v2bc pdelay-interval 388
- ptp v2bc priority1 382
- ptp v2bc priority2 382
- ptp v2bc sync-interval 387
- ptp v2bc utc-offset 383
- ptp v2bc utc-offset-valid 383
- ptp v2bc v1-compatibility-mode 388
- ptp v2bc vlan 384
- ptp v2bc vlan-priority 384
- ptp v2tc asymmetry 389
- ptp v2tc delay-mechanism 389
- ptp v2tc management 390
- ptp v2tc multi-domain-mode 390
- ptp v2tc network-protocol 391
- ptp v2tc operation 391
- ptp v2tc pdelay-interval 392
- ptp v2tc power-tlv-check 394
- ptp v2tc primary-domain 392
- ptp v2tc profile 393
- ptp v2tc sync-local-clock 395
- ptp v2tc syntonization 393
- ptp v2tc vlan 394
- ptp v2tc vlan-priority 395
  
- R**
- radius accounting mode 531
- radius server host 531
- radius server key 533
- radius server msgauth 533
- radius server primary 534
- radius server retransmit 535
- radius server timeout 536
- reboot 320
- reload 322
- reset system command 320, 322
- ring-coupling 474
- ring-coupling config 475
- ring-coupling net-coupling 476
- ring-coupling operation 476

ring-coupling port	477	set prompt	130
ring-coupling redundancy-mode	477	show	52
rmon-alarm add	199	show address-conflict	52
rmon-alarm delete	200	show arc	459
rmon-alarm disable	201	show arp switch	53, 59
rmon-alarm enable	200	show authentication	58, 539
rmon-alarm modify falling-event	204	show authentication users	540
rmon-alarm modify interval	202	show auto-disable brief	229
rmon-alarm modify mib-variable	201	show auto-disable reasons	230
rmon-alarm modify rising-event	204	show boot skip-aca-on-boot	297, 297
rmon-alarm modify sample-type	203	show bridge address-learning	53
rmon-alarm modify startup-alarm	203	show bridge address-relearn-detect	54
rmon-alarm modify thresholds	202	show bridge aging-time	54
		show bridge duplex-mismatch-detect	55
		show bridge fast-link-detection	55
		show bridge framesize	55
		show bridge vlan-learning	56
		show classofservice dot1pmapping	90
		show classofservice ip-dscp-mapping	91
		show classofservice trust	92
		show commands	
		show inventory	231, 232, 233, 235, 236,
			237,
			239, 240, 511
		show lags summary	244
		show loginsession	286
		show port	243
		show stats switch detailed	60, 62, 68
		show switchconfig	245, 246, 247, 248
		show users	287
		show vlan detailed	248
		show vlan interface	251
		show vlan summary	251
		show config-watchdog	57
		show device-status	57
		show dhcp-relay	486, 488
		show dhcp-server	492
		show dhcp-server operation	493
		show dhcp-server pool	494
		show dhcp-server port	493
		show digital-input	112, 115
		show digital-input all	114
		show digital-input config	113
		show digital-output	116, 119
		show digital-output all	118
		show digital-output config	117
		show dip-switch	231
		show dot1x	540
		show dot1x clients	546
		show dot1x users	545
		show dvlan-tunnel	96
		show ethernet-ip	131, 134
		show eventlog	59
		show fast-hiper-ring	467
<b>S</b>			
Schulungsangebot	593		
script apply	173		
script delete	174		
script list	174		
script show	175		
script validate	175		
selftest ramtest	226		
selftest reboot-on-error	228		
selftest reboot-on-hdxerror	227		
serial timeout	130		
session-limit	102		
sessions			
closing	285, 316		
displaying	286		
session-timeout	103		
set garp timer join	205		
set garp timer leave	206		
set garp timer leaveall	207		
set gmrp adminmode	208		
set gmrp forward-all-groups	211		
set gmrp forward-unknown	212		
set gmrp interfacemode	209, 210		
set igmp	213, 214		
set igmp aging-time-unknown	214		
set igmp automatic-mode	215		
set igmp forward-all	216		
set igmp forward-unknown	217		
set igmp groupmembershipinterval	219		
set igmp interfacemode	220		
set igmp lookup-interval-unknown	220		
set igmp lookup-resp-time-unknown	221		
set igmp maxresponse	222		
set igmp querier max-response-time	223		
set igmp querier protocol-version	223		
set igmp querier status	224		
set igmp querier tx-interval	224		
set igmp query-ports-to-filter	225		
set igmp static-query-port	218		
set pre-login-banner text	226		

show fast-hiper-ring current-id	468	show port-monitor	403, 404
show garp	232	show port-monitor brief	405
show gmrp configuration	232	show port-monitor crc-fragment	406
show hiper-ring	462	show port-monitor link-flap	406
show hiper-ring info	463	show port-sec mode	478
show iec61850-mms	122	show port-sec port	478
show igmpsnooping	233	show ptp	371
show inlinepower	396	show ptp configuration	374
show inlinepower port	396	show ptp operation	374
show inlinepower slot	399	show ptp port	375
show interface	60	show ptp status	376
show interface ethernet	62	show radius	548
show interface switchport	69	show radius accounting	536
show interface utilization	70	show radius statistics	549
show inventory	271	show reboot	321
show ip http	556	show reload	323
show ip https	559	show ring-coupling	472
show ip ssh	547	show rmon-alarm	245
show link-aggregation	244	show running-config	76
show link-aggregation brief	98	show selftest	246
show lldp	324	show serial	134
show lldp chassis tx-interval	327	show signal-contact	73
show lldp config	324	show slot	75
show lldp config chassis	325	show snmp-access	135
show lldp config chassis admin-state	325	show snmpcommunity	136
show lldp config chassis notification-interval	325	show snmptrap	137
show lldp config chassis re-init-delay	326	show sntp	356
show lldp config chassis tx-delay	326	show sntp anycast	358
show lldp config chassis tx-hold-mult	326	show sntp client	358
show lldp config port	328	show sntp operation	359
show lldp config port tlv	329	show sntp server	360
show lldp med	330	show sntp status	360
show lldp med interface	331	show sntp time	361
show lldp med local-device detail	332	show spanning-tree	417
show lldp med remote-device	333	show spanning-tree brief	419
show lldp med remote-device detail	334	show spanning-tree interface	420
show lldp remote-data	334	show spanning-tree mst detailed	421
show logging	71	show spanning-tree mst port detailed	422
show login-session	286, 293	show spanning-tree mst port summary	425
show mac notification	240	show spanning-tree mst summary	426
show mac-addr-table	72	show spanning-tree summary	427
show mac-filter-table gmrp	235	show spanning-tree vlan	428
show mac-filter-table igmpsnooping	236	show storm-control	247
show mac-filter-table multicast	237	show storm-control limiters port	248
show mac-filter-table static	238	show sub-ring	501
show mac-filter-table staticfiltering	239	show switchconfig	105
show mac-filter-table stats	240	show sysinfo	77, 92, 93
show monitor session	242	show telnet	138
show mrp	453	show telnetcon	139
show mrp current domain	454	show temperature	80
show network	105, 131	show trapflags	140
show network mgmt-access	133	show users	287
show port	243, 265, 266	show users authentication	551
		show vlan	248

show vlan brief	251	spanning-tree forward-time	436, 438
show vlan port	251	spanning-tree guard loop	437
show voice vlan	253	spanning-tree guard none	438
show voice vlan interface	254	spanning-tree guard root	439
shutdown	255	spanning-tree hello-time	440
shutdown all	256	spanning-tree hold-count	441
signal-contact	317	spanning-tree max-age	442
signal-contact connection-error	317	spanning-tree max-hops	443
slot/port	26	spanning-tree mst	444
snmp trap link-status	257	spanning-tree mst instance	448
snmp trap link-status all	258	spanning-tree mst priority	446
snmp-access global	141, 142	spanning-tree mst vlan	447
snmp-access version v3-encryption	142	spanning-tree port mode	449
snmp-server	81, 144	spanning-tree port mode all	450
snmp-server community	145	spanning-tree stp-mrp-mode	451
snmp-server community ipaddr	147	spanning-tree tcnguard	452
snmp-server community ipmask	148	speed	260
snmp-server community mode	149	speeds	260
snmp-server community ro	150	statistics	
snmp-server community rw	150	switch, related 201 commands	60, 62, 68
snmp-server contact	146	storm-control broadcast	261
snmp-server enable traps	151	storm-control broadcast (port-related)	263
snmp-server enable traps linkmode	154	storm-control egress-limit	263
snmp-server enable traps multiusers	155	storm-control egress-limiting	261
snmp-server enable traps port-sec	156	storm-control flowcontrol	265
snmp-server enable traps stpmode	157	storm-control flowcontrol per port	266
snmp-server location	150	storm-control ingress-limit	264
snmp-server sysname	151	storm-control ingress-limiting	262
snmptrap	158	storm-control ingress-mode	262, 264
snmptrap ipaddr	159	sub-ring mode	503
snmptrap mode	160	sub-ring mrp-domainID	507
snmptrap snmpversion	161	sub-ring operation	504
SNTP - Simple Network Time Protocol	356	sub-ring port	505
sntp anycast address	362	sub-ring protocol	504
sntp anycast transmit-interval	362	sub-ring ring-name	505
sntp anycast vlan	363	sub-ring vlan	506
sntp client accept-broadcast	363	Sub-Ring Commands	501
sntp client disable-after-sync	364	sub-ring delete-ring	508
sntp client offset	364	sub-ring new-ring	508
sntp client request-interval	365	switch	
sntp client server primary	366	information, related 201 commands	245,
sntp client server secondary	367	246,	247, 248
sntp client threshold	368	inventory	231, 232, 233, 235, 236, 237,
sntp operation	369	239,	240, 511
sntp server disable-if-local	370	resetting	320, 322
sntp time system	370	statistics, related 201 commands	60, 62,
spanning-tree	429	68	
spanning-tree auto-edgeport	430	System Information and Statistics Commands	85
spanning-tree bpduguard	431	System Utilities	296, 511
spanning-tree bpdumigrationcheck	259	system utilities	296–316
spanning-tree configuration name	432		
spanning-tree configuration revision	433		
spanning-tree edgeport	434		
spanning-tree forceversion	435		

- T**
- tagging 278, 280
  - telnet 99
    - sessions, closing 285, 316
    - sessions, displaying 286
  - telnetcon maxsessions 162
  - telnetcon timeout 163
  - temperature 319
  - traceroute 299
  - transport input telnet 100
  - transport output telnet 101
  - trap log
    - clearing 303, 304
  - trunks. See LAGs
- U**
- User Account Management Commands 285
  - user account management commands
    - 201 commands 285
  - User Exec Mode 45
  - users
    - adding 290, 291
    - deleting 289, 290, 291
    - displaying 287
    - passwords 292, 302
  - users access 290
  - users defaultlogin 288
  - users login 289, 552
  - users name 291
  - users passwd 292
  - users snmpv3 accessmode 293
  - users snmpv3 authentication 294
  - users snmpv3 encryption 295
  - utilization alarm-threshold 80
- V**
- vlan 267
  - vlan acceptframe 269, 270
  - vlan ingressfilter 271
  - VLAN Mode 45
  - vlan name 272
  - vlan participation 273
  - vlan participation all 274
  - vlan port acceptframe all 275
  - vlan port ingressfilter all 276
  - vlan port priority all 92
  - vlan port pvid all 277
  - vlan port tagging all 278
  - vlan priority 93
  - vlan pvid 279
  - vlan tagging 280
  - vlan0-transparent-mode 268
  - VLANs
    - adding 267
    - changing the name of 272
    - deleting 267
    - details 248
    - frame acceptance mode 269, 270, 275
    - IDs 277, 279
    - ingress filtering 271, 276
    - jointime 199, 200, 201, 202, 203, 204, 205
    - leave all time 207
    - leave time 206
    - participation in 273, 274
    - port information 251
    - resetting parameters 304
    - summary information 251
    - tagging 278, 280
    - voice vlan (Global Config Mode) 281
    - voice vlan (Interface Config Mode) 282
    - voice vlan auth 284
- W**
- Web connections, displaying 286

# Further support

## ■ Technical Questions

For technical questions, please contact any Hirschmann dealer in your area or Hirschmann directly..

You will find the addresses of our partners on the Internet at <http://www.hirschmann.com>

Contact our support at <https://hirschmann-support.belden.eu.com>

You can contact us

in the EMEA region at:

- ▶ Tel.: +49 (0)1805 14-1538
- ▶ E-mail: [hac.support@belden.com](mailto:hac.support@belden.com)

in the America region at:

- ▶ Tel.: +1 (717) 217-2270
- ▶ E-mail: [inet-support.us@belden.com](mailto:inet-support.us@belden.com)

in the Asia-Pacific region at:

- ▶ Tel.: +65 6854 9860
- ▶ E-mail: [inet-ap@belden.com](mailto:inet-ap@belden.com)

## ■ Hirschmann Competence Center

The Hirschmann Competence Center is ahead of its competitors:

- ▶ Consulting incorporates comprehensive technical advice, from system evaluation through network planning to project planning.
- ▶ Training offers you an introduction to the basics, product briefing and user training with certification.  
The current technology and product training courses can be found at <http://www.hicomcenter.com>
- ▶ Support ranges from the first installation through the standby service to maintenance concepts.

With the Hirschmann Competence Center, you have decided against making any compromises. Our client-customized package leaves you free to choose the service components you want to use.

Internet:<http://www.hicomcenter.com>



**HIRSCHMANN**

---

A **BELDEN** BRAND