Print Pocket



A Pentair Company

Hoffman Enclosures Inc. 2100 Hoffman Way Anoka, MN 55303–1745 (763) 422–2211 Tel www.hoffmanonline.com

- 1. Verify you have all the parts needed to install the print pocket.
 - Print pocket (with tape adhered to back)
 - Tube of adhesive
- 2. Determine desired print pocket location, and examine the surface for contaminants such as dust or oil. Dust should be removed by wiping surface with water dampened rag. For oil or grease, the surface should be wiped using a rag dampened with mineral spirits or isopropyl alcohol. After removing contaminants, thoroughly dry the surface using a clean, dry rag to remove moisture or flashing solvents.

A CAUTION

When using flammable solvent, care should be used in the proper disposal and handling of these materials.

- 3. Using the tube of adhesive sealant provided, apply sealant to the sides of the print pocket. Dispense a 3/16 inch diameter bead of adhesive from the upper to the lower corner along center of each side flange. Adhesive sealant bead should end before contacting double face adhesive tape along lower flange.
- 4. Remove protective backing from double faced tape along bottom of print pocket. Position the print pocket in the desired location, pressing the bottom edge firmly to assure good adhesion of double face adhesive to both substrates. With light pressure, slide finger along both side flanges to form a consistent film thickness of adhesive sealant along these flanges. Adhesive sealant will skin over in approximately fifteen minutes, with full cure occurring in twenty-four hours. Refrain from placing heavy objects or large quantities of documents in print pocket for at least twenty-four hours.

Rev. A 103397

© 2002 Hoffman Enclosures Inc.

P/N 55223001

87568182



RSPSupply - 1-888-532-2706 - www.RSPSupply.com/p-3684-Hoffman-A20