

TECHNICAL DATA

Fluke TRM50 Coaxial Feed-through BNC Male to BNC Female Cable Terminator



Product overview: Fluke TRM50 Coaxial Feed-through BNC Male to BNC Female Cable Terminator

TRM50 Coaxial Feed-through BNC male to BNC female Cable Terminator.

Specifications: Fluke TRM50 Coaxial Feed-through BNC Male to BNC Female Cable Terminator

Specifications	
Impedance	50 Ohm
Max Voltage over ground	1000 V CAT III
Max power	1 W

Ordering information



Fluke TRM50



Fluke. *Keeping your world up and running.®*

Fluke Corporation
PO Box 9090, Everett, WA 98206 U.S.A.

For more information call:
In the U.S.A. (800) 443-5853
In Canada (800) 36-FLUKE
From other countries +1 (425) 446-5500
www.fluke.com

©2024 Fluke Corporation.
Specifications subject to change without notice.
02/2024

**Modification of this document is not permitted
without written permission from Fluke Corporation.**