1885855

https://www.phoenixcontact.com/us/products/1885855

Please be informed that the data shown in this PDF document is generated from our Online Catalog. Please find the complete data in the user documentation. Our General Terms of Use for Downloads are valid.

Adapter plates 2 mm thick, for panel cutouts of HC-B 24 size, including 1.5 mm flat gasket, size 1



Commercial Data

Item number	1885855
Packing unit	1 pc
Minimum order quantity	5 pc
Note	Made to Order (non-returnable)
Sales Key	AB01
Product Key	ABLAZD
Catalog Page	Page 49 (C-2-2013)
GTIN	4017918178604
Weight per Piece (including packing)	88.2 g
Weight per Piece (excluding packing)	87.63 g
Customs tariff number	39269097
Country of origin	DE

PHŒNIX

1885855

https://www.phoenixcontact.com/us/products/1885855

PHŒNIX CONTACT

Technical Data

Notes

Safety note WARNING: The connectors may not be hugged in or disconnected under load (parcing the warning or improper use may damage persons and/or property. • WARNING: Commission property Manching or improper use may damage persons and/or property. • WARNING: One unission defective products inmage. Decommission defective products may install and oparate the product. They must observe the following safety must observe the following safety products. They must observe the following safety products. They must observe the following safety must observe the following safety provent chargies: The relevant symbol on the packtaging indicates that only personnel familia with the basics of electrical engineering. They must able to recognize and provent chargies: The relevant symbol on the packtaging indicates that only personnel familia with electrical engineering are allowed to install and operate the product. • The products are suitable for applications in plant, controller, and electrical elevice engineering. • When operating the connectors in outdoor applications, they must be separately protected against environmental influences. • Assembled products may not be manipulated or improper opened. • Only use maining connectors that are specified in the technical data of the standards listed (e.g. the onselited in the product accessories online at phoenkocntact.com/products). • When operating voltages > 50 V AC, conductive connector housings must be grounded • For operating voltages > 50 V AC, conductive connector housings must be grounded • For operating voltages > 50 V AC, conductive connector housings must be grounded • Only use tools reconnector with third-party manufactures, the corresponding technica	Safety note	
The products must be regularity inspected for damage. Decommission defective products immediately. Replace damaged products. Repairs are not possible. • WARNING: Only electrically qualified personnel may install and operate the product. They must beserve the following safety notes. The qualified personnel may install and operate the product. They must be dance in conception allowed to install and operate the product. • The products are suitable for applications in plant, controller, and electrical device engineering. • When operating the connectors in outdoor applications, they must be separately protected against environmental influences. • Assembled products may not be manipulated or improperly opened. • Only use mating connectors that are specified in the technical data of the standards tisted (e.g. the ones listed in the product accessories online at phoenixcontact.com/products). • When using the product in direct connection with third party manufactures, the use is responsible. • For operating voltages > 50 V AC, conductive connector housings must be grounded • Ensure that the product: • Only use rotation • Only the product in connection with third party manufactures, the use is responsible. • On the product • On the product on onthe download page at phoenix contact comproducts must be observed for this product.	Safety note	disconnected under load. Ignoring the warning or improper use
operate the product. They must be able to recognize and prevent danger. The relevant symbol on the packaging indicates that only personnel must be the product. and dectrical device engineering. allowed to install and operate the product. and dectrical device engineering. allowed to install and operate the product. and dectrical device engineering. and dectrical device engineering. allowed to install and operate the product. and dectrical device engineering. and and prevent damage. and dectrical device engineering. and and the standard sited (e.g. the ones listed in the product accessories online at phoenixcontact.com/products). and of the standards listed (e.g. the ones listed in the product accessories online at product and recometor functional ground has been properly connected. and order the corresponding technical data. You will find information: a On the product a On the product a On the product a On the product		The products must be regularly inspected for damage. Decommission defective products immediately. Replace
and electrical device engineering. • When operating the connectors in outdoor applications, they must be separately protected against environmental influences. • Assembled products may not be manipulated or improperly opened. • Only use mating connectors that are specified in the technical data of the standards listed (e.g., the ones listed in the product accessories online at phoenixcontact.com/products). • When using the product in direct connector with third-party manifacturers, the user is responsible. • For operating voltages > 50 V AC, conductive connector housings must be grounded • Ensure that the protective or functional ground has been properly connected. • VDE 1010/137 § 411.1.3.2 and DIN EN 60 204/11.98 § 14.1.3 are applicable when combining several circuits in a cable and/or connector • Observe the corresponding technical data. You will find information: • On the product • On the product and phoenixcontact.com/products must be observed to the prohomixcontact.com/products must be observed of the product and phoenixcontact.com/products • On the supplied		operate the product. They must observe the following safety notes. The qualified personnel must be familiar with the basics of electrical engineering. They must be able to recognize and prevent danger. The relevant symbol on the packaging indicates that only personnel familiar with electrical engineering are
must be separately protected against environmental influences. • Assembled products may not be manipulated or improperly opened. • Only one mating connectors that are specified in the technical data of the standards listed (e.g. the ones listed in the product accessories online at phoenixcontact.com/products). • When using the product in direct connection with third-party manufacturers, the user is responsible. • For operating voltages > 50 V AC, conductive connector housings must be grounded • For operating voltages > 50 V AC, conductive connector housings must be grounded • Torsure that the protective or functional ground has been properly connected. • VDE 0100/1.97 § 411.1.3.2 and DIN EN 60 204/11.98 § 14.1.3 are applicable when combining several circuits in a cable and/or connector • Observe the corresponding technical data. You will find information: • On the product • On the product • Online at phoenixcontact.com/products under the product • Only use tools recommended by Phoenix Contact • Only use tools recommended by Phoenix Contact • The installation notes/Design In documents online on the download page at phoenixcontact.com/products must be observed for this product. • Use a protective cap to protect connectors that are not in use. The suitable accessories are available online in the accessory section of the product at phoenixcontact.com/products • Only use the connector only when it is fully plugged in.		
opened. • Only use mating connectors that are specified in the technical data of the standards listed (e.g. the ones listed in the product accessories online at phoenixcontact.com/products). • When using the product in direct connection with third-party manufacturers, the user is responsible. • For operating voltages > 50 V AC, conductive connector housings must be grounded • Ensure that the protective or functional ground has been properly connector • VDE 0100/1.97 § 411.1.3.2 and DIN EN 60 204/11.98 § 14.1.3 are applicable when combining several circuits in a cable and/or connector • Observe the corresponding technical data. You will find information: • On the product • Only use tools recommended by Phoenix Contact • Only use tools recommended by Phoenix contact. • Use a protective cap to protect connectors that are not in use. The suitable accessories are available online in the accessory section of the product at phoenixcontact.com/products • Use a protective cap to protect connectors that are not in use. The suitable accessories are available online in the accessory section of the product at phoenixcontact. • Operate the connector only when it is fully plugged in.		
data of the standards listed (e.g. the ones listed in the product accessories online at phoenixcontact.com/products). • When using the product in direct connection with third-party manufacturers, the user is responsible. • For operating voltages > 50 V AC, conductive connector housings must be grounded • Ensure that the protective or functional ground has been properly connected. • VDE 0100/1.97 § 411.1.3.2 and DIN EN 60 204/11.98 § 14.1.3 are applicable when combining several circuits in a cable and/or connector • Observe the corresponding technical data. You will find information: • On the product • On the product • On the supplied documentation • On the supplied documentation • Onling as the ontest, Design In documents online on the download page at phoenixcontact. com/products must be observed for this product. • Only use tools recommended by Phoenix Contact • One product or the product on the download page at phoenixcontact. com/products must be observed for this product. • Only use tools recommended by Phoenix Contact • One product at phoenixcontact. com/products must be observed for this product. • Use a protective cap to protect connectors that are not in use. The suitable accessories are available online in the accessory section of the product at phoenixcontact.com/products • Operate the connector only when it is fully plugged in. • Ensure that when laying the cable, the tensile load on the		
manufacturers, the user is responsible. • For operating voltages > 50 V AC, conductive connector housings must be grounded • Ensure that the protective or functional ground has been properly connected. • VDE 0100/1.97 § 411.1.3.2 and DIN EN 60 204/11.98 § 14.1.3 are applicable when combining several circuits in a cable and/or connector on the product • Observe the corresponding technical data. You will find information: • O the product • On the packing label • In the supplied documentation • Only use tools recommended by Phoenix Contact • The installation notes/Design In documents online on the download page at phoenixcontact.com/products must be observed for this product. • Use a protective cap to protect connectors that are not in use. • Use a protective cap to protect connectors that are not in use. • Operate the connector only when it is fully plugged in. • Ensure that when laying the cable, the tensile load on the		data of the standards listed (e.g. the ones listed in the product
housings must be grounded • Ensure that the protective or functional ground has been properly connected. • VDE 0100/1.97 § 411.1.3.2 and DIN EN 60 204/11.98 § 14.1.3 are applicable when combining several circuits in a cable and/or connector • VDE 0100/1.97 § 411.1.3.2 and DIN EN 60 204/11.98 § 14.1.3 are applicable when combining several circuits in a cable and/or connector • Observe the corresponding technical data. You will find information: • On the product • On the product • Online at phoenixcontact.com/products under the product • Only use tools recommended by Phoenix Contact • Only use tools recommended by Phoenix Contact • Only use tools recommended by Phoenix Contact • The installation notes/Design In documents online on the download page at phoenixcontact.com/products must be observed for this product. • Use a protective cap to protect connectors that are not in use. The suitable accessories are available online in the accessory section of the product at phoenixcontact.com/products • Operate the connector only when it is fully plugged in. • Ensure that when laying the cable, the tensile load on the		
properly connected. • VDE 0100/1.97 § 411.1.3.2 and DIN EN 60 204/11.98 § 14.1.3 are applicable when combining several circuits in a cable and/or connector • Observe the corresponding technical data. You will find information: • O In the product • On the product • On the supplied documentation • Only use tools recommended by Phoenix Contact • Only use tools recommended by Phoenix Contact • The installation notes/Design In documents online on the download page at phoenixcontact.com/products must be observed for this product. • Use a protective cap to protect connectors that are not in use. The suitable accessories are available online in the accessory section of the product at phoenixcontact.com/products • Operate the connector only when it is fully plugged in. • Ensure that when laying the cable, the tensile load on the		
are applicable when combining several circuits in a cable and/or connector · Observe the corresponding technical data. You will find information: o On the product o On the packing label o In the supplied documentation o Online at phoenixcontact.com/products under the product · Only use tools recommended by Phoenix Contact · The installation notes/Design In documents online on the download page at phoenixcontact.com/products must be observed for this product. · Use a protective cap to protect connectors that are not in use. The suitable accessories are available online in the accessory section of the product at phoenixcontact.com/products · Operate the connector only when it is fully plugged in. · Ensure that when laying the cable, the tensile load on the		
 information: On the product On the packing label In the supplied documentation Online at phoenixcontact.com/products under the product Only use tools recommended by Phoenix Contact Only use tools recommended by Phoenix contact The installation notes/Design In documents online on the download page at phoenixcontact.com/products must be observed for this product. Use a protective cap to protect connectors that are not in use. The suitable accessories are available online in the accessory section of the product at phoenixcontact.com/products Operate the connector only when it is fully plugged in. Ensure that when laying the cable, the tensile load on the 		are applicable when combining several circuits in a cable and/or
The installation notes/Design In documents online on the download page at phoenixcontact.com/products must be observed for this product. Use a protective cap to protect connectors that are not in use. The suitable accessories are available online in the accessory section of the product at phoenixcontact.com/products Operate the connector only when it is fully plugged in. Ensure that when laying the cable, the tensile load on the		information: o On the product o On the packing label o In the supplied documentation
download page at phoenixcontact.com/products must be observed for this product. • Use a protective cap to protect connectors that are not in use. The suitable accessories are available online in the accessory section of the product at phoenixcontact.com/products • Operate the connector only when it is fully plugged in. • Ensure that when laying the cable, the tensile load on the		Only use tools recommended by Phoenix Contact
The suitable accessories are available online in the accessory section of the product at phoenixcontact.com/products • Operate the connector only when it is fully plugged in. • Ensure that when laying the cable, the tensile load on the		download page at phoenixcontact.com/products must be
Ensure that when laying the cable, the tensile load on the		The suitable accessories are available online in the accessory
		Operate the connector only when it is fully plugged in.



1885855

https://www.phoenixcontact.com/us/products/1885855

st	tandards.
	Observe the minimum bending radius of the cable. Lay the able without twisting it.
ar wa	The connector warms up in normal operation. Depending on the mbient conditions, the surface of the connector can continue to varm up. In this case, the user is responsible for posting rarnings (e.g. DIN EN ISO 13732-1:2008-12).

Product properties

Туре	VC1
Product type	Adapter plate
Seal present	yes

Dimensions

Dimensional drawing	$\begin{array}{c} 42.8 \\ 40 \\ 33.5 \\ \hline \\ $
Width	3.5 mm
Height	43 mm
Length	141 mm

Material specifications

Material	V2A
Seal material	NBR


Environmental and real-life conditions

Ambient conditions		
Degree of protection	IP65	
	IP65	

1885855

https://www.phoenixcontact.com/us/products/1885855

Drawings



Dimensional drawing

JPHŒNIX



https://www.phoenixcontact.com/us/products/1885855




Classifications

ECLASS

ECLASS-11.0	27440201
ECLASS-12.0	27440201
ECLASS-13.0	27440201

ETIM

	ETIM 8.0	EC002309	
UN	UNSPSC		
	UNSPSC 21.0	31261500	



1885855

https://www.phoenixcontact.com/us/products/1885855



Environmental Product Compliance

China RoHS	Environmentally friendly use period: unlimited = EFUP-e
	No hazardous substances above threshold values

Phoenix Contact 2023 © - all rights reserved https://www.phoenixcontact.com

Phoenix Contact USA 586 Fulling Mill Road Middletown, PA 17057, United States (+717) 944-1300 info@phoenixcon.com